

# SAF, CLM Cluster Node Unavailable

Ericsson Centralized User Database

OPERATING INSTRUCTION

**Copyright**

© Ericsson AB 2016-2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Alarm Description	1
1.2	Prerequisites	2
<b>2</b>	<b>Procedure</b>	<b>3</b>
2.1	Procedure for CUDB Systems Deployed on Native BSP 8100	3
2.2	Procedure for CUDB Systems Deployed on a Cloud Infrastructure	3
	<b>Glossary</b>	<b>5</b>
	<b>Reference List</b>	<b>7</b>



SAF, CLM Cluster Node Unavailable



# 1 Introduction

This document concerns alarm handling for the SAF, CLM Cluster Node Unavailable alarm.

## 1.1 Alarm Description

This alarm is related to Service Availability Forum (SAF). Refer to COM SA, CLM Cluster Node Unavailable, Reference [4].

The possible alarm causes and the corresponding fault reasons, fault locations, and impacts are described in Table 1.

Table 1 Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Communication failure with the reported node.	Failure in the reported node or the communication path.	Unknown.	Unknown.	Cluster capacity, redundancy, or both is reduced.
The High Availability (HA) configuration of the cluster is incorrect.	The Operating System (OS) and middleware layer is incorrectly configured.	Design fault.	Design of the OS layer, or the middleware layer, or both.	Cluster capacity or redundancy is reduced.

The alarm attributes are listed and explained in Table 2.

Table 2 Alarm Attributes

Attribute Name	Attribute Value
Auto Cease	Yes
Module	SAF
Error Code	10
Timestamp First	Date and time when the alarm was raised for the first time.
Repeated Counter	Number which indicates how many times the alarm was raised.
Timestamp Last	Date and time of the most recent alarm raised.
Resource ID	.1.3.6.1.4.1.193.169.9.10.<length>.<NOI>
Alarm Model Description	CLM Cluster Node Unavailable, SAF
Alarm Active Description	SAF platform: Cluster Node Unavailable@<NON>
ITU Alarm Event Type	equipmentAlarm (5)
ITU Alarm Probable Cause	equipmentMalfunction (514)
ITU Alarm Perceived Severity	(3) – Critical



Attribute Name	Attribute Value
Originating Source IP	Node IP where the alarm was raised.
Sequence Number	Number which indicates order in which alarms are raised.

For further information about attribute descriptions, refer to [CUDB Node Fault Management Configuration Guide, Reference \[1\]](#).

In Table 2, the indicated variables are as follows:

- `<NON>` is the Notifying Object Name that indicates where the component that generates the alarm is. For example:

`PL_2_9`

- `<NOI>` is the Notifying Object Identifier. It corresponds to `<NON>` in a dot-separated, ASCII-decimal-encoded, character-per-character format. For example:

`80.76.95.50.95.57` for `PL_2_9`

- `<length>` is the number of characters in `<NON>`, which is equivalent to the number of octets in `<NOI>`. In the previous example, `<length>` is 6.

## 1.2 Prerequisites

This section provides information on the documents, tools and conditions that apply to the procedure.

### 1.2.1 Documents

Before starting this procedure, ensure that you have read the following documents:

- Configuration section of [CUDB Node Fault Management Configuration Guide, Reference \[1\]](#), regarding alarm configuration.
- System Safety Information, Reference [5].
- Personal Health and Safety Information, Reference [6].

### 1.2.2 Tools

Not applicable.

### 1.2.3 Conditions

Not applicable.



## 2 Procedure

This section describes the procedure to follow when this alarm is received.

### 2.1 Procedure for CUDB Systems Deployed on Native BSP 8100

In case the alarm is raised on a system deployed on native Blade Server Platform 8100 (BSP 8100), do the following:

1. Follow the instructions specified in [COM SA, CLM Cluster Node Unavailable](#), Reference [4].
2. If the alarm remains, consult the next level of maintenance support. Further actions are outside the scope of this Operating Instruction (OPI).

### 2.2 Procedure for CUDB Systems Deployed on a Cloud Infrastructure

In case the alarm is raised on a system deployed on a cloud infrastructure, do the following:

1. Follow the instructions specified in [COM SA, CLM Cluster Node Unavailable](#), Reference [4].
2. If no application-level problems are detected, check if there are any issues in the cloud infrastructure.
3. In the case of an infrastructure activity involving compute host reinstallation/failure/shutdown or reboot, perform the steps of the “Actions in the Case of Infrastructure Activities” section in [Virtualized CUDB Virtual Machine Recovery](#), Reference [2].
4. If the alarm remains, consult the next level of maintenance support. Further actions are outside the scope of this OPI.



SAF, CLM Cluster Node Unavailable



## Glossary

For the terms, definitions, acronyms and abbreviations used in this document, refer to [CUDB Glossary of Terms and Acronyms](#), Reference [3].



SAF, CLM Cluster Node Unavailable



## Reference List

### **CUDB Documents**

- [1] CUDB Node Fault Management Configuration Guide
- [2] Virtualized CUDB Virtual Machine Recovery
- [3] CUDB Glossary of Terms and Acronyms

### **Other Ericsson Documents**

- [4] COM SA, CLM Cluster Node Unavailable
- [5] System Safety Information
- [6] Personal Health and Safety Information