

Lock Backup Scheduler

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Lock Backup Scheduler	1





1 Description

This instruction describes how to lock the backup scheduler. It prevents scheduled backups from occurring. The scheduler can be locked to disable periodic backups during maintenance windows.

If the backup scheduler is locked, it must be unlocked before scheduled backups can run again, refer to [Unlock Backup Scheduler](#).

2 Procedure

2.1 Lock Backup Scheduler

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - Attribute `adminState` is UNLOCKED.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the `BrmBackupScheduler` managed object, for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,BrM=1,BrmBackupManager=SYSTEM_DATA,BrmBackupScheduler=SYSTEM_DATA
```

2. Enter Config mode:

```
(BrmBackupScheduler=SYSTEM_DATA)>configure
```

3. Lock the backup scheduler:

```
(config-BrmBackupScheduler=SYSTEM_DATA)>adminState=LOCKED
```



Attention!

Risk of data loss or data corruption.

Locking the backup scheduler cancels any ongoing scheduled backup.

Note: The value of the `adminState` attribute cannot be cleared by the `no adminState` ECLI command

4. Commit the change:

```
(config-BrmBackupScheduler=SYSTEM_DATA)>commit
```

5. Verify that the backup scheduler is locked:

```
(BrmBackupScheduler=SYSTEM_DATA)>show
```

The following is an example output:

```
BrmBackupScheduler=SYSTEM_DATA
  adminState=LOCKED
[...]
  schedulerState=DISABLED <read-only>
[...]
```