

vDicos, Diameter Peer Node Disabled

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2015–2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Alarm Description	1
2	Procedure	1
2.1	Handle Alarm vDicos, Diameter Peer Node Disabled	1



vDicos, Diameter Peer Node Disabled



1 Alarm Description

The alarm is raised when a Diameter peer node has been disabled, either administratively or by the system because of a fault.

Table 1 vDicos, Diameter Peer Node Disabled Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
Diameter peer node disabled	The Diameter peer node has been disabled	Diameter peer node disabled	Peer node configuration	The communication with the peer node is lost

The alarm is cleared automatically when alarm *vDicos, Diameter Own Node Disabled* is raised. Alarms for peer nodes related to the own node are cleared and a new alarm is raised for the own node.

2 Procedure

2.1 Handle Alarm vDicos, Diameter Peer Node Disabled

Prerequisites

- This instruction references the following documents:
 - *Data Collection Guideline*
- No tools are required.
- The following conditions must apply:
 - The alarm is raised.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Contact the network or node administrator. Is the node administratively disabled for maintenance reasons?

Yes: Proceed with Step 8.



No: Continue with the next step.

2. Navigate to the *DIA-CFG-NeighbourNode* managed object, for example:

```
>dn ManagedElement=NODE06ST,XYZFunction=xyz,DIA-CFG-App  
lication=DIA,DIA-CFG-StackContainer=abc,DIA-CFG-PeerNo  
deContainer=abc,DIA-CFG-NeighbourNode=node12.ericsson  
.com\23abc
```

3. Enable the Diameter peer node:

```
(DIA-CFG-NeighbourNode=node12.ericsson.com\23abc) >con  
figure
```

```
(config-DIA-CFG-NeighbourNode=node12.ericsson.com\23ab  
c) >enabled=true
```

```
(config-DIA-CFG-NeighbourNode=node12.ericsson.com\23  
abc) >commit
```

4. Verify the setting:

```
(DIA-CFG-NeighbourNode=node12.ericsson.com\23abc) >show  
enabled
```

```
enabled=true
```

5. Is the alarm cleared?

Yes: Proceed with Step 8.

No: Continue with the next step.

6. Perform data collection, refer to *Data Collection Guideline*.
7. Consult the next level of maintenance support. Further actions are outside the scope of this instruction.
8. Job is completed.