

Change Maximum Transmission Unit Size

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2015, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Change Maximum Transmission Unit Size	1



Change Maximum Transmission Unit Size



1 Description

This instruction describes how to change the Maximum Transmission Unit (MTU) size.

Default is 1452 bytes, as the system internal IPv6 tunnels add an overhead of 48 bytes.

The default value works for the widest variety of available Ethernet switching infrastructure hardware and there is in general no need to deviate from the default value.

Note: Changing the value in-service requires a cluster reboot, causing an interruption of service.

2 Procedure

2.1 Change Maximum Transmission Unit Size

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The new MTU size is known.
 - The user has the System Security Administrator role.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to *EvipParam* managed object, for example:

```
>ManagedElement=NODE06ST,Transport=1,Evip=1,EvipParams=1,EvipParam=mtu
```

2. Enter Config mode:



```
(EvipParam=mtu) >configure
```

3. Change the MTU size, for example:

```
(config-EvipParam=mtu) >value=1280
```

4. Commit the setting:

```
(config-EvipParam=mtu) >commit
```

5. Open up a console connection to SC-1, for example:

```
ssh root@<hostname>
```

6. Perform a cluster reboot:



Attention!

Risk of system malfunction or traffic disturbance.

Service is interrupted during a cluster reboot.

```
SC-1:~ #cmw-cluster-reboot
```

The following output is shown:

```
Do you really want to reboot the entire cluster (yes/no)?
```

7. Enter `yes` to reboot.
8. Verify the MTU size of the traffic interface:

```
SC-1:~ #ifconfig alb_tr
```

The following is an example output:

```
alb_tr  Link encap:UNSPEC  =>
HWaddr FE-80-00-00-00-00-00-00-00-00-00-00-00-00-00-00-00
      inet addr:10.118.160.53  P-t-P:10.118.160.53  Mask:255.255.255.255
      inet6 addr: 2001:1b70:4292:8207::51/128 Scope:Global
      inet6 addr: fe80::3e19:7dff:fe0e:ab0c/64 Scope:Link
      UP POINTOPOINT RUNNING NOARP  MTU:1280  Metric:1
      RX packets:0 errors:0 dropped:0 overruns:0 frame:0
      TX packets:19954 errors:4 dropped:4 overruns:0 carrier:0
      collisions:4 txqueuelen:0
      RX bytes:0 (0.0 b)  TX bytes:9443431 (9.0 Mb)
```

9. Verify the MTU size of the authentication interface:

```
SC-1:~ #ifconfig alb_aut
```

The following is an example output:



```
alb aut    Link encap:UNSPEC =>
HWaddr FE-80-00-00-00-00-00-00-00-00-00-00-00-00-00-00-00
      inet addr:10.118.160.43  P-t-P:10.118.160.43  Mask:255.255.255.255
      inet6 addr: fe80::3e19:7dff:fe0e:ab0c/64 Scope:Link
      inet6 addr: 2001:1b70:4292:8207::43/128 Scope:Global
      UP POINTOPOINT RUNNING NOARP  MTU:1280  Metric:1
      RX packets:0 errors:0 dropped:0 overruns:0 frame:0
      TX packets:2 errors:0 dropped:0 overruns:0 carrier:0
      collisions:0 txqueuelen:0
      RX bytes:0 (0.0 b)  TX bytes:232 (232.0 b)
```