

Set Automatic Export of Scheduled Backups

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Set Automatic Export of Scheduled Backups	1





1 Description

This instruction describes how to set automatic export of scheduled backups.

Setting automatic export of scheduled backups prevents that these are lost through manual or automated deletion. Scheduled backups can then always be retrieved from an external file storage.

By default the exporting of scheduled backups is disabled.

Exported scheduled backups are not deleted from the local persistent storage media. For information on how to enable automatic deletion of manual backups, refer to *Enable Automatic Deletion of Manual Backups*.

2 Procedure

2.1 Set Automatic Export of Scheduled Backups

Prerequisites

- No documents are required.
- No tools are required.
- The following condition must apply:
 - The backup scheduler is set up and unlocked.

Note: If the backup scheduler is locked, any ongoing scheduled export is cancelled and no alarm is raised.
 - The backup type is known.
 - The Uniform Resource Locator (URI) of the remote location that receives the exported scheduled backups is known. Only SSH File Transfer Protocol (SFTP) URIs are supported, for example, `sftp://<user_id>@<hostname_or_ip_address>/<remote_destination_directory>`
 - The SFTP user password is known (optional for servers that do not require a password).



- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the *BrmBackupScheduler* managed object, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, BrM=1, BrmBackupManager=SYSTEM_DATA, BrmBackupScheduler=SYSTEM_DATA
```

2. Enter Config mode:

```
(BrmBackupScheduler=SYSTEM_DATA) >configure
```

3. Set the URI of the location where scheduled backups are exported, for example:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >autoExportUri=sftp://hostuser1@host1/home/hostuser1/
```

Note: Only SFTP URIs are supported. The syntax is `sftp://<user_id>@<hostname_or_ip_address>/<remote_destination_directory>`

The value of attribute `autoExportUri` cannot be cleared using ECLI command `no autoExportUri`.

4. Is a URI password required?

Yes: Continue with the next step.

No: Proceed with Step 6.

5. Set the URI password used for exporting scheduled backups, for example:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >autoExportPassword="hostuser1pw" cleartext
```

6. Enable export of scheduled backups:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >autoExport=ENABLED
```

Note: The value of attribute `autoExport` cannot be cleared using ECLI command `no autoExport`.

7. Commit the change:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >commit
```

8. Verify the change:

```
(BrmBackupScheduler=SYSTEM_DATA) >show
```



The following is an example output:

```
BrmBackupScheduler=SYSTEM_DATA
autoExport=ENABLED
autoExportPassword="1:kkfYDdhqZNDRQ2HY62/ZsJyt1A2UaVN/"
autoExportUri="sftp://hostuser1@host1/home/hostuser1/"
```