

# Delete SNMP Target

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	Delete SNMP Target	1



Delete SNMP Target



# 1 Description

This instruction describes how to delete a Simple Network Management Protocol (SNMP) target. An SNMP target can be deleted when it is no longer needed to send SNMP notifications to a given management system. This could be, for example, as a result of replanning.

## 2 Procedure

### 2.1 Delete SNMP Target

#### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The SNMP target to delete is known and according to the network IP plan.
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps

1. Navigate to the *Snmp* managed object, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, SysM=1, Snmp=1
```

2. To find the SNMP target to be deleted, show the existing SNMP targets:

```
(Snmp=1) >show -v
```

The following is an example output:



```
Snmp=1
  operationalState=ENABLED
  agentAddress
    host="0.0.0.0"
    port=161
  SnmpTargetV3=OSS_v3
```

In this example, the SNMP target `SnmpTargetV3=OSS_v3` is to be deleted.

3. Enter Config mode:

```
(Snmp=1) >configure
```

4. Delete the SNMP target, for example:

```
(config-Snmp=1) >no SnmpTargetV3=OSS_v3
```

5. Commit the change:

```
(config-Snmp=1) >commit
```

6. Verify that the SNMP target is deleted:

```
(Snmp=1) >show -v
```

```
Snmp=1
  operationalState=ENABLED
  agentAddress
    host="0.0.0.0"
    port=161
```

The SNMP target has been deleted.