

# Change Port Number of FTP over TLS

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	Change Port Number of FTP over TLS	1



Change Port Number of FTP over TLS



# 1 Description

This instruction describes how to change the port number of FTP over TLS.

## 2 Procedure

### 2.1 Change Port Number of FTP over TLS

#### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The new port number to use is known and is not used by another application.
  - An Ericsson Command-Line Interface (ECLI) in exec mode is in progress.

---

---

#### Attention!



Risk of system malfunction or traffic disturbance.

---

---

Ensure that the selected new port number is not already in use by another application.

#### Steps

1. Navigate to the `FtpTlsServer` MO, for example:

```
>dn ManagedElement=1,SystemFunctions=1,SysM=1,FileTPM=1,FtpServer=1,FtpTlsServer=1
```

2. Enter Config mode:



```
(FtpTlsServer=1)>configure
```

3. Set the new port number, for example:

```
(config-FtpTlsServer=1)>port=2211
```

4. Commit the settings:

```
(config-FtpTlsServer=1)>commit
```

5. Verify the settings:

```
(FtpTlsServer=1)>show
```

The following is an example output:

```
FtpTlsServer=1  
[...]  
    port=2211
```