

# Unlock Backup Scheduler

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	Unlock Backup Scheduler	1





# 1 Description

This instruction describes how to unlock the backup scheduler. It allows scheduled backups to run.

## 2 Procedure

### 2.1 Unlock Backup Scheduler

#### Prerequisites

- No documents are required.
- No tools are required.
- The following condition must apply:
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps

1. Navigate to the *BrmBackupScheduler* managed object, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, BrM=1, BrmBackupManager=SYSTEM_DATA, BrmBackupScheduler=SYSTEM_DATA
```

2. Enter Config mode:

```
(BrmBackupScheduler=SYSTEM_DATA) >configure
```

3. Unlock the backup scheduler:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >adminState=UNLOCKED
```

**Note:** The value of the `adminState` attribute cannot be cleared by the `no adminState` ECLI command.

4. Commit the change:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >commit
```



5. Verify that the backup scheduler is unlocked:

```
(BrmBackupScheduler=SYSTEM_DATA) >show -v
```

The following is an example output:

```
BrmBackupScheduler=SYSTEM_DATA  
  adminState=UNLOCKED <default>  
[...]  
  brmBackupSchedulerId="SYSTEM_DATA"  
  maxStoredScheduledBackups=4  
[...]
```