

Start Threshold Monitoring Job

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Introduction	1
1.1	Prerequisites	1
2	Procedure	3



Start Threshold Monitoring Job



1 Introduction

This document describes how to start a threshold monitoring job. A threshold monitoring job is started to enable the reporting of threshold alarms for the corresponding measurement types. This is usually done when the managed element is operational and manageable as part of the normal operations.

1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

1.1.1 Conditions

The following conditions must apply:

- The job name is known.
The job name is POT_Thr_Job in this document.
- `currentJobState` for the job is STOPPED.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.



Start Threshold Monitoring Job



2 Procedure

To start a threshold monitoring job:

1. Navigate to the **PmJob** Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,Pm=1,PmJob=POT_Thr_Job
```

2. Enter Config mode:

```
(PmJob=POT_Thr_Job)>configure
```

3. Set the PmJob state to ACTIVE:

```
(config-PmJob=POT_Thr_Job)>requestedJobState=ACTIVE
```

4. Commit the PmJob MO configuration:

```
(config-PmJob=POT_Thr_Job)>commit
```

5. Verify the result:

```
(PmJob=POT_Thr_Job)>show -v
```

The following is an example output:

```
PmJob=POT_Thr_Job
compressionType=[] <empty>
currentJobState=ACTIVE <read-only>
granularityPeriod=FIFTEEN_MIN <default>
jobControl=FULL <default> <read-only>
jobGroup=[] <empty>
jobPriority=MEDIUM <default>
jobType=THRESHOLDJOB
pmJobId="POT_Thr_Job"
reportContentGeneration=CHANGED_ONLY <default>
reportingPeriod=FIFTEEN_MIN <default>
requestedJobState=ACTIVE <default>
MeasurementReader=POT_mr
```

Note: An alarm notification is issued at the end of the reporting period if **thresholdHigh** in the **PmThresholdMonitoring** MO has been exceeded.