

CUSTOMER LINE AND OUTGOING TRUNK CONDUCTORS
VOLTMETER TESTS USING MASTER TEST FRAME
NO. 5 CROSSBAR OFFICES

42

1. GENERAL

PAGE

1.01 This section describes the method of making voltmeter tests on customer line and outgoing trunk conductors using the master test frame voltmeter test circuit SD-25792-01 in No. 5 crossbar offices.

and polarity of the tip and ring conductors from the distant trunk circuit. . . .

13

1.02 This section is reissued to include the operation of the SCO key at the master test frame to prevent transmitter noise from interfering with transmission while performing tests on customer lines. This reissue does not affect Equipment Test Lists.

1.04 Customer lines served by a 1A line concentrator are tested the same as nonconcentrated lines. An exception to this is the test terminations. Usually, one test termination is provided for each concentrator trunk group. If a line test is made to the test termination, the normal test indication will be a 33-kilohm shunt at the remote unit. Also, when making either Test A or B in this section and it is necessary to test an individual concentrator trunk, the concentrator control circuit must be blocked according to the method described in Section 067-105-502. When this is done, a test call originated in the master test frame (MTF) will connect the line called through the concentrator trunk desired.

1.03 The tests covered are:

PAGE

A. Continuity Test of Customer Line Conductors Equipped With Cold-Cathode-Tube Type Telephone Sets: This test checks the operation of the tube in cold-cathode-tube type telephone sets.

3

Caution: Do not block 1A line concentrator trunks busy any longer than necessary when making tests on individual trunks.

B. Tests for Trouble Conditions—Customer Line or Outgoing Trunk Conductors: This test checks the line or trunk conductors for foreign battery, resistance, crosses, or capacity.

5

1.05 **Lettered Steps:** A letter a, b, c, etc, added to a step number in Part 4 of this section indicates an action which may or may not be required depending on local conditions. The condition under which a lettered step or a series of lettered steps should be made is given in the ACTION column, and all steps governed by the same condition are designated by the same letter within a test. Where a condition does not apply, all steps designated by that letter should be omitted.

C. Metallic Meter Test—Outgoing Trunk Conductors: This test checks that, when the ammeter is connected to the tip and ring conductors in a metallic circuit, the distant trunk circuit is advanced to off-normal.

12

1.06 The manner of selecting some circuits and test conditions at the MTF and its associated circuits varies depending on the apparatus options furnished with these circuits. Therefore, where variable means of selection are provided, precise instructions for the selection of circuits and test

D. Continuity and Polarity Test—Outgoing Trunk Conductors: This test checks the continuity

NOTICE

Not for use or disclosure outside the Bell System except under written agreement

SECTION 218-245-501

conditions are not given. Precise instructions for the use of these variable means are given in Section 218-106-301.

1.07 The location statement, At MTF—, is used to refer to all apparatus located on the four basic bays of the MTF.

2. APPARATUS

All Tests

2.01 If access is through the master test control circuit for testing customer line conductors, the following is required:

- (a) Master test control circuit, SD-25800-01

- (b) MTF voltmeter test circuit, SD-25792-01.

2.02 If access is through the T1 or T2 jack of the voltmeter test circuit for testing customer line or outgoing trunk conductors, the following is required:

- (a) MTF voltmeter test circuit, SD-25792-01

- (b) Patching cord, P3F cord, 4 feet long, equipped with one 309 plug and one 310 plug (3P12A cord).

3. PREPARATION

STEP	ACTION	VERIFICATION
-------------	---------------	---------------------

All Tests

Note: Refer to paragraphs 1.06 and 1.07.

- | | | |
|---|---|-------------------------|
| 1 | At MTF—
Restore all keys and switches. | |
| 2 | Momentarily operate RL key. | All lamps extinguished. |

Customer Line Conductor Tests Via Master Test Control Circuit

- | | | |
|---|--|--|
| 3 | Select office designation of line under test. | |
| 4 | Select A through D digits as required for directory number of line being tested. | |
| 5 | Select special marker 0 or 1. | |
| 6 | Select LT class of test. | |
| 7 | ◆Operate SCO key.◆ | |
| 8 | Momentarily operate ST key. | LT, MRL lamps lighted.
BY lamp <i>not</i> lighted.
S lamp lighted. |
| 9 | ◆Restore SCO key.◆ | |

STEP	ACTION	VERIFICATION
Customer Line Conductor Tests Via Plugging-up Line Circuit, Permanent Signal Holding Trunk Circuit, or Common Overflow Trunk Circuit		
10	◆Operate SCO key.◆	
11	Patch T1 or T2 jack of voltmeter test circuit to L jack of plugging-up line circuit or T jack of trunk circuit.	BY1 or BY2 lamps <i>not</i> lighted.
12	◆Restore SCO key.◆	

Outgoing Trunk Conductor Tests

13	◆Operate SCO key.◆	
14	Patch T1 or T2 jack of voltmeter test circuit to T jack of trunk circuit associated with outgoing trunk being tested.	BY1 OR BY2 lamp <i>not</i> lighted.
15	◆Restore SCO key.◆	

4. METHOD

STEP	ACTION	VERIFICATION
A. Continuity Test of Customer Line Conductors Equipped With Cold-Cathode-Tube Type Telephone Sets		
	<i>Note:</i> If line under test is seized while being tested, proceed immediately to Step 24a.	
13	Operate VMT1/VMT2 key. <i>Note:</i> VMT1 and T1 REV keys should be used when access is through T2 jack on master test control circuit. VMT2 and T2 REV keys should be used when access is through T2 jack.	Steady voltmeter reading of less than 67 volts (120-volt scale). <i>Note 1:</i> This voltmeter reading of less than 67 volts indicates that the conductor insulation resistance is more than 50,000 ohms. It should be noted whether the reading is above or below 45 volts. <i>Note 2:</i> A steady voltmeter reading of more than 67 volts indicates that the conductor insulation resistance is less than 50,000 ohms, in which case, this test should not be made.
14	Restore VMT1/VMT2 key.	
15	Operate -STA (negative station) key.	

STEP	ACTION	VERIFICATION
16	Operate VMT1/VMT2 key.	<p>When voltmeter reading obtained in Step 13 for conductor being tested is between 0 and 45 volts— Steady voltmeter reading of more than 17 volts (120-volt scale) indicates that the station tested for is connected and the tube is operative.</p> <p>When voltmeter reading obtained in Step 13 for conductor being tested is between 45 and 67 volts— Steady voltmeter reading of more than 24 volts (120-volt scale) indicates that the station tested for is connected and the tube is operative.</p> <p>Note: If two stations of the same polarity are connected to the same conductor as on an 8-party line, this test checks that at least one station of the polarity tested for is connected, but does not distinguish between one and two stations.</p>
17	Restore VMT1/VMT2 key.	
18	Operate +STA (positive station) key.	
19	Repeat Steps 16 and 17.	
20	Restore +STA key.	
21	Operate T1 REV/T2 REV key.	
22	Repeat Steps 13 through 20.	
23	Restore T1 REV/T2 REV key.	
24a	If line under test is seized while being tested— Operate T key.	
	Note: If line seized is arranged for range extension, operate LOLP key.	
25a	Inform customer that testing is being performed and stop testing.	
26	Momentarily operate RL key.	
27	Restore all keys and switches not required in next test.	
28	Remove patching cord, if used and if not required in next test.	

STEP	ACTION	VERIFICATION
------	--------	--------------

B. Tests for Trouble Conditions—Customer Line or Outgoing Trunk Conductors

Note 1: If line under test is seized while being tested, proceed immediately to Step 34a.

Note 2: When testing for trouble conditions on outgoing trunk conductors, make arrangements to have the trunk conductors opened at the distant end until the test, or series of tests, is completed.

Test of Foreign Battery on Ring Conductor

16 Operate FEMF key.

17 Operate VMT1/VMT2 key.

Note: VMT1 and T1 REV keys should be used when access is through T1 jack or master test control circuit. VMT2 and T2 REV keys should be used when access is through T2 jack.

18 Restore VMT1/VMT2, FEMF keys.

No steady voltmeter reading.

Note: If there is a steady voltmeter reading to the right of 0 volt, the conductor is crossed to negative voltage. If the reading is to the left, the cross is to positive voltage, at which time the VM REV key should be operated for verification and then restored.

Test for Foreign Battery on Tip Conductor

19 Operate T1 REV/T2 REV key.

20 Repeat Steps 16 through 18.

21 Restore T1 REV/T2 REV key.

Test for Ring Conductor Resistance to Ground

22 Operate VMT1/VMT2 key.

Steady voltmeter reading.

Note: Tables A, B, C, and D should be used to determine the resistance. Operate the AM, 1000, or 20,000 key as required to obtain the reading which is closest to midscale.

23 Restore VMT1/VMT2 key; if operated, restore AM, 1000, or 20,000 key.

Test for Tip Conductor Resistance to Ground

24 Operate T1 REV/T2 REV key.

STEP

ACTION

VERIFICATION

TABLE A

100,000-OHM METER RESISTANCE
120- OR 150-VOLT SCALE
20,000; 1000; AM KEYS NONOPERATED

METER READING VOLTS	RESISTANCE — OHMS TEST BATTERY VOLTAGE		
	99	100	101
100		0	1,000
98	1,020	2,040	3,061
96	3,125	4,166	5,208
94	5,319	6,382	7,446
92	7,608	8,695	9,782
90	10,000	11,110	12,220
88	12,500	13,640	14,770
86	15,120	16,280	17,440
84	17,860	19,050	20,240
82	20,730	21,950	23,170
80	23,750	25,000	26,250
78	26,920	28,200	29,490
76	30,260	31,580	32,890
74	33,780	35,130	36,490
72	37,500	38,890	40,280
70	41,430	42,860	44,280
68	45,590	47,060	48,530
66	50,000	51,510	53,030
64	54,690	56,250	57,810
62	59,680	61,290	62,900
60	65,000	66,670	68,330
58	70,690	72,410	74,140
56	76,780	78,570	80,360
54	83,330	85,180	87,040
52	90,380	92,310	94,230
50	98,000	100,000	102,000
48	106,200	108,300	110,400
46	115,200	117,400	119,600
44	125,000	127,300	129,500
42	135,700	138,100	140,500
40	147,500	150,000	152,500
38	160,500	163,200	165,800
36	175,000	177,800	180,600
34	191,200	194,100	197,100
32	209,400	212,500	215,600
30	230,000	233,300	236,700
28	253,600	257,100	260,700
26	280,800	284,600	288,500
24	312,500	316,700	320,800
22	350,000	354,500	359,100
20	395,000	400,000	405,000
18	450,000	455,600	461,100
16	518,700	525,000	531,300
14	607,100	614,300	621,400
12	725,000	733,300	741,700
10	890,000	900,000	910,000
8	1,137,000	1,150,000	1,162,000
6	1,550,000	1,367,000	1,583,000
4	2,375,000	2,400,000	2,425,000
2	4,850,000	4,900,000	4,950,000

TABLE B

20,000-OHM METER RESISTANCE
20- OR 30-VOLT SCALE
20,000 KEY OPERATED
1000; AM KEYS NONOPERATED

METER READING VOLTS	RESISTANCE — OHMS TEST BATTERY VOLTAGE		
	19.4	20	20.6
20		0	600
19.6		408	1,020
19.2	208	838	1,458
18.8	638	1,276	1,914
18.4	1,086	1,739	2,392
18.0	1,556	2,222	2,888
17.6	2,046	2,727	3,410
17.2	2,558	3,255	3,954
16.8	3,096	3,809	4,524
16.4	3,658	4,390	5,122
16.0	4,250	5,000	5,750
15.6	4,872	5,641	6,410
15.2	5,526	6,315	7,106
14.8	6,236	7,027	7,838
14.4	6,944	7,777	8,612
14.0	7,714	8,571	9,428
13.6	8,530	9,411	10,290
13.2	9,394	10,300	11,210
12.8	10,310	11,250	12,260
12.4	11,290	12,260	13,280
12.0	12,330	13,330	14,330
11.6	13,450	14,480	15,520
11.2	14,640	15,710	16,790
10.8	15,930	17,040	18,150
10.4	17,310	18,460	19,620
10.0	18,800	20,000	21,200
9.6	20,420	21,670	22,920
9.2	22,170	23,480	24,780
8.8	24,090	25,450	26,820
8.4	26,190	27,620	29,050
8.0	28,500	30,000	31,500
7.6	31,050	32,630	34,210
7.2	33,890	35,360	37,220
6.8	37,060	38,820	40,590
6.4	40,620	42,500	44,380
6.0	44,670	46,670	48,670
5.6	49,290	51,430	53,570
5.2	54,620	56,920	59,230
4.8	60,830	63,330	65,830
4.4	68,180	70,910	73,640
4.0	77,000	80,000	83,000
3.6	87,780	91,110	94,450
3.2	101,200	105,000	108,800
2.8	118,600	122,900	127,100
2.4	141,700	146,700	151,700
2.0	174,000	180,000	186,000
1.6	222,500	230,000	237,500
1.2	303,300	313,300	323,300
0.8	465,000	480,000	495,000
0.4	950,000	980,000	1,010,000

STEP

ACTION

VERIFICATION

TABLE C

1000-OHM METER RESISTANCE
30-VOLT SCALE
1000 KEY OPERATED
20,000; AM KEYS NONOPERATED

METER READING VOLTS	RESISTANCE — OHMS TEST BATTERY VOLTAGE		
	19.4	20	20.6
20.0		0	30
19.6		20	51
19.2	10	42	73
18.8	32	63	96
18.4	54	87	120
18.0	78	111	144
17.6	102	136	171
17.2	128	163	198
16.8	155	190	226
16.4	183	220	256
16.0	213	250	288
15.6	244	282	321
15.2	276	316	355
14.8	312	351	392
14.4	347	389	431
14.0	386	428	471
13.6	427	471	515
13.2	470	515	561
12.8	516	563	613
12.4	565	613	661
12.0	617	667	717
11.6	672	724	776
11.2	732	786	839
10.8	796	852	907
10.4	865	925	981
10.0	940	1,000	1,060
9.6	1,021	1,083	1,146
9.2	1,109	1,174	1,239
8.8	1,205	1,273	1,341
8.4	1,310	1,381	1,452
8.0	1,425	1,500	1,575
7.6	1,553	1,632	1,711
7.2	1,694	1,778	1,861
6.8	1,853	1,941	2,029
6.4	2,031	2,125	2,219
6.0	2,233	2,333	2,433
5.6	2,464	2,571	2,679
5.2	2,731	2,846	2,962
4.8	3,042	3,167	3,292
4.4	3,409	3,545	3,682
4.0	3,850	4,000	4,150
3.6	4,389	4,556	4,722
3.2	5,062	5,250	5,438
2.8	5,929	6,143	6,357
2.4	7,083	7,333	7,583
2.0	8,700	9,000	9,300
1.6	11,130	11,500	11,880
1.2	15,170	15,670	16,170
.8	23,250	24,000	24,750
.4	47,500	49,000	50,500

TABLE D

200-OHM METER RESISTANCE
300-MILLIAMMETER SCALE
AM KEY OPERATED
20,000; 1000 KEYS NONOPERATED

METER READING MILLIAMPERES	RESISTANCE — OHMS CENTRAL OFFICE BATTERY VOLTAGE		
	47	48.5	50
250			0
245			4.1
240		2.1	8.8
235	0	6.4	12.8
230	4.3	10.9	17.4
225	8.9	15.6	22.2
220	13.6	20.5	27.3
215	18.6	25.6	32.6
210	23.8	31.0	38.1
205	29.3	36.6	43.9
200	35.0	42.5	50.0
195	41.0	48.7	56.4
190	47.4	55.1	63.2
185	54.1	62.2	70.3
180	61.1	69.4	77.8
175	68.6	77.1	85.7
170	76.5	84.5	94.1
165	84.9	93.9	103.0
160	93.8	103.1	112.5
155	103.2	112.9	122.6
150	113.3	123.3	133.3
145	124.1	134.5	144.8
140	135.7	146.4	157.1
135	148.2	159.3	170.4
130	161.5	173.1	184.6
125	176.0	188.0	200.0
120	191.7	204.2	216.7
115	208.7	221.7	234.8
110	227.3	240.9	254.6
105	247.6	261.8	276.2
100	270.0	285.0	300.0
95	294.7	310.5	326.3
90	322.2	338.9	355.6
85	352.9	370.6	388.2
80	387.5	406.2	425.0
75	426.7	446.7	466.7
70	471.4	492.9	514.3
65	523.1	546.2	569.2
60	583.3	608.3	633.3
55	654.6	681.8	709.1
50	740.0	770.0	800.0
45	844.0	878.0	911.0
40	975.0	1013.0	1050.0
35	1143.0	1186.0	1229.0
30	1367.0	1417.0	1487.0
25	1680.0	1740.0	1800.0
20	2150.0	2225.0	2300.0
15	2933.0	3033.0	3133.0
10	4500.0	4650.0	4800.0
5	9200.0	9500.0	9800.0
0			

STEP

ACTION

VERIFICATION

TABLE E

**BALLISTIC DEFLECTIONS USING 100,000-OHM METER RESISTANCE
20,000; 1000; AM KEYS NONOPERATED**

These values are approximate and are based on zero customer loop

TYPE OF LINE	EQUIPMENT ON LINE	INFINITE OHMS	BALLISTIC DEFLECTION OF POINTER INSULATION RESISTANCE OF LINE			
			500,000 OHMS	200,000 OHMS	100,000 OHMS	50,000 OHMS
Individual Line	No. 68A (1400 ohms) ringer with 1-mf capacitance bridged across line	50	53	57	63	72
Individual Line	No. 8AA (1000 ohms) ringer with 2-mf capacitance bridged across line	77	74	73	74	78
2-Party Message Rate or 2-Party Flat Rate	No. 68AA (1000 ohms) or No. 68A (1400 ohms) ringer in series with 1-mf capaci- tance legged from one side of line to ground	25	35	45	57	70
2-Party	No. 8AA (1000 ohms) ringer in series with 2-mf capaci- tance legged from one side of line to ground	39	46	53	62	72
4-Party Semiselective	No. 68A (1400 ohms) ringer in series with 1-mf capaci- tance, two stations legged from one side of line to ground	40	46	53	62	72
4-Party Semiselective	No. 8AA (1000 ohms) ringer in series with 2-mf capaci- tance, two stations legged from one side of line to ground	55	59	63	69	76
4-Party Full Selective	85-type relay 1 station	30	38	47	57	70
	in series with 2 stations	51	54	58	65	73
	0.5-mf capaci- 3 stations	67	66	67	70	76
	tance bridged 4 stations	79	76	74	75	79
4-Party Full Selective	85-type relay 1 station	50	53	57	63	72
	in series with 2 stations	78	75	73	74	78
	0.5-mf capaci- 3 stations	97	90	85	83	83
	tance bridged 4 stations	110	101	94	89	86
19- and 22- Gauge Cable	5 miles	22	32	42	55	68
	10 miles	38	44	51	60	71
	15 miles	49	53	58	64	73
	20 miles	57	59	63	68	75
	25 miles	64	65	67	72	77
	30 miles	69	70	71	74	78
24-Gauge Cable	5 miles	21	31	42	55	68
	10 miles	35	42	50	59	71
	15 miles	45	50	56	63	73
	20 miles	53	56	60	67	75
	25 miles	59	61	65	71	76
	30 miles	64	66	68	72	77

STEP	ACTION	VERIFICATION
25	Repeat Steps 22 and 23.	
26	Restore T1 REV/T2 REV key.	
Test for Tip-to-Ring Conductor Resistance		
27	Operate G key.	
28	Repeat Steps 22 and 23.	
29	Restore G key.	
Test for Capacity on Tip and Ring Conductors		
30	Operate G, T1 REV/T2 REV, VMT1/VMT2 keys.	
	Note: Do not proceed with this test until there is a steady voltmeter reading indicating that the line or outgoing trunk conductors are fully charged.	
31	Restore T1 REV/T2 REV key.	Momentary (ballistic) voltmeter deflection returning to a steady reading.
		Note: The degree of the momentary voltmeter deflection depends on the ring conductor capacity and insulation resistance. To determine the insulation resistance from the steady reading, use Table A. To determine the correct degree of momentary deflection, use Table E.
32	Operate T1 REV/T2 REV key.	Momentary (ballistic) voltmeter deflection returning to a steady reading.
		Note 1: The degree of the momentary voltmeter deflection depends on the tip conductor capacity and insulation resistance. To determine the insulation resistance from the steady reading, use Table A. To determine the correct degree of momentary deflection, use Table E.
		Note 2: When testing outgoing trunk conductors, the degree of the momentary deflections in Steps 31 and 32 should be equal.
33	Restore G, T1 REV/T2 REV, VMT1/VMT2 keys.	

SECTION 218-245-501

STEP	ACTION	VERIFICATION
34a	If line under test is seized while being tested— Operate T key. <i>Note:</i> If seized line is arranged for range extension, operate LOLP key.	
35a	Inform customer that testing is being performed and stop testing.	
36	Momentarily operate RL key.	
37	Restore all keys and switches not required in next test.	
38	Remove patching cord, if used and if not required in next test.	

C. Metallic Meter Test—Outgoing Trunk Conductors

Note: If line under test is seized while being tested, proceed immediately to Step 20a.

Caution: To protect the milliammeter, a check for foreign battery on the tip and ring conductors (see Test B) should be made before proceeding with this test.

16	Operate RG, FEMF, AM keys.	
17	Operate VMT1/VMT2 key. <i>Note:</i> VMT1 and T1 REV keys should be used when access is through T1 jack or master test control circuit. VMT2 and T2 REV keys should be used when access is through T2 jack.	Steady ammeter reading. <i>Note:</i> If there is a steady ammeter reading to the left of 0 milliampere, operate the T1 REV/T2 REV key.
18	Restore AM key.	Steady voltmeter reading indicating proper voltage and polarity. <i>Note:</i> If there is a steady voltmeter reading to the left of 0 volt, operate or restore the T1 REV/T2 REV key.
19	Restore FEMF, RC, VMT1/VMT2, T1 REV/T2 REV keys.	
20a	If line under test is seized while being tested— Operate T key.	

STEP	ACTION	VERIFICATION
	<i>Note:</i> If seized line is arranged for range extension, operate LOLP key.	
21a	Inform customer that testing is being performed and stop testing.	
22	Restore all keys and switches not required in next test.	
23	Remove patching cord, if used and if not required in next test.	
D. Continuity and Polarity Test—Outgoing Trunk Conductors		
	<i>Note:</i> If trunk is seized while being tested, proceed immediately to Step 19a.	
16	Operate RG, FEMF keys.	
17	Operate VMT1/VMT2 key.	Steady voltmeter reading indicating proper voltage and polarity.
	<i>Note:</i> VMT1 and T1 REV keys should be used when access is through T1 jack or master test control circuit. VMT2 and T2 REV keys should be used when access is through T2 jack.	<i>Note:</i> If there is a steady voltmeter reading to the left of 0 volt, operate T1 REV/T2 REV key.
18	Restore FEMF, RC, VMT1/VMT2, T1 REV/T2 REV keys.	
19a	If line under test is seized while being tested—Operate T key.	
	<i>Note:</i> If seized line is arranged for range extension operate LOLP key.	
20a	Inform customer that testing is being performed and stop testing.	
21	Restore all keys and switches.	
22	Remove patching cord, if used.	

