

Passport 15000, 20000

Site Requirements and Preparation Guide

241-1501-205

Passport 15000, 20000

Site Requirements and Preparation Guide

Publication: 241-1501-205

Document status: Standard

Document version: 5.2S2

Document date: February 2004

Copyright © 2004 Nortel Networks.

All Rights Reserved.

Printed in Canada

NORTEL NETWORKS, the globemark design, the NORTEL NETWORKS corporate logo, and Passport are trademarks of Nortel Networks.

ADC is a registered trademark of ADC Telecommunications, Inc.

AMP, MATE-N-LOK, and Z-PACK are trademarks of AMP of Canada, Ltd.

Astec, Helios, MFA150, and Advanced Power Systems are trademarks of Astec Advanced Power Systems. EdgeLink is a trademark of Telco Systems.

VT100 is a trademark of Digital Equipment Corporation.

Publication history

March 2004

5.2S2 Standard

General availability. Contains information on Passport 15000 and Passport 20000 for the PCR5.2 release.

Contents

About this document **15**

Who should read this document and why 15

What you need to know 15

What's new in this document 16

 16-port OC-3/STM-1 POS and ATM FP with PEC NTHW44 17

 An additional version of the lower and upper cooling units 17

 Enclosing a NEBS 2000 frame with doors and side panels 18

 Voice services processor 3 with optical TDM interface
 (2pOC3ChSmlrVsp3) 18

 Y-protection for dual 16-port OC-3/STM-1 POS and ATM FPs 18

Related documents 19

How to get more help 19

Chapter 1

Safety information **21**

Personal safety 22

Safe equipment handling 23

 Moving the frame safely 24

 Avoiding equipment damage from static electricity 24

 Installing the switch safely 26

Storing and transporting circuit cards 28

Compliance with electrical and safety standards 28

Chapter 2

Planning considerations **29**

Task flow of planning considerations 29

 Task flow navigation 31

- Adding a switch to an anchored NEBS 2000 frame 32
- Assess air filter maintenance 33
- Assess cable management 35
 - Task flow of cable management assessment 35
 - Determining your cable density 37
 - Managing high-density cabling 40
 - Managing low-density cabling 42
 - Managing very high-density coax cabling 43
 - Placing a fiber management unit for cable slack 45
 - Using custom-made processor card or system cables 47
- Assess environmental requirements 49
 - Operational environment 49
 - Power dissipation 51
 - Bulk heat dissipation 52
 - Prerequisites for your earthquake zone and application 53
- Assess power cable location 54
 - Ceiling requirements 54
 - Flooring requirements 54
- Assess the location of a Passport 15000 or 20000 55
 - General guidelines for placing the equipment 55
 - Equipment size and weight 58
 - Front and rear access to switch hardware 72
- Assess the location of a system of ac rectifiers 74
- Assess the locations of peripheral equipment 76
 - Choosing the user interface equipment 76
 - Choosing the network management computer for a Passport 15000 or 20000 77
 - Deciding where to place local user interface equipment 78
 - Deciding where to place a sparing or a fanout panel 78
 - Deciding where to place interworking equipment 80
 - Interworking with an EdgeLink 100 80
 - Interworking with a Shasta 5000 82
 - Deciding which external BIP alarms to connect 82
 - Using a connection to a gigabit Ethernet port on NTHW84 83
- Assess spare parts storage and selection 83

Spare processor cards	84
Spare cooling units or cooling unit parts	84
Kits of spare parts for a Passport 15000 or 20000	85
Assess timing requirements	85
Plan for the use of an equivalent mounting apparatus	87
Dimensions and weight rating for the alternate rack	88
Rack and cabinet specifications	88
Electromagnetic compatibilities for an alternative mounting apparatus	91
Cooling considerations	91
Preparing your site's source of power	93
Grounding the switch hardware	93

Chapter 3

Site preparation

95

Task flow of site preparation	95
Task flow navigation	95
Before you begin	96
Safety precautions	96
Tools and equipment required	96
Using the NEBS floor template	97
Raised floor openings for processor cables	99
Preparing the floor for anchor holes	101
Task flow of preparing the floor	101
Checking the floor	104
Common procedure used for drilling any floor	105
When adding extended cable management brackets to a NEBS 2000 frame	111
When adding a door to a NEBS 2000 frame	111
Marking the footprint and the anchor holes on the floor	112
When anchoring NEBS 2000 frames side-by-side	116
When anchoring ac rectifiers near a Passport	118

Chapter 4

Power and grounding preparation

119

Power architecture	120
--------------------	-----

- Passport 15000-VSS power architecture 121
- Power requirements 121
 - Redundant power feeds 122
 - Power input through tapping a main 122
 - Power input from a system of ac rectifiers 123
 - Passport 15000-VSS power requirements 125
- Power distribution and consumption 125
 - Sample calculation of maximum input current 130
 - Passport 15000-VSS power distribution 131
- Preparation for installing power and ground cables 131
 - Allowing for voltage drop over distance 133
 - About restricted and non-restricted sites 135
 - Labeling the power feeds in CPE or a CO 136
 - Grounding the frame in CPE or a CO 138
 - Grounding when not using a NEBS 2000 frame 141
 - Grounding when using ac rectifiers as a power source 141
 - Prerequisites to installing dc power input cables 141
- Power cable specifications 143
 - Power cable specifications for a fully provisioned shelf 144
 - Power cable specifications for a partially provisioned shelf 146
 - Power cable specifications with a polyvalent assembly 147
 - Power cable specifications with an ETSI assembly 149
 - Power cable specifications when using ac rectifiers 152
- Power and ground cabling overview 153
 - Grounding topologies 153
 - General grounding rules for IBN and CBN topologies 156
- Grounding the frame and communication links 157
 - Grounding a Passport 157
 - Grounding the communication links 157

Chapter 5

Standards and compliance considerations 159

- Product safety/regulatory 160
- Grounding standards 161
- Powering standards 161

Electromagnetic compatibilities	162
Electrical fast transient	162
Electrostatic discharge (ESD)	162
Electromagnetic emissions	162
Electromagnetic immunity (EMI)	163
Acoustic noise compliance	163
Interconnect compliance	163
Quality compliance	163
Material and manufacturing	163
Other standards	163
Astec MFA150 standards and compliances	164

Appendix	
Grounding topologies	165

List of figures

- Figure 1 Task flow of planning considerations 30
- Figure 2 Task flow of cable management assessment 36
- Figure 3 A dual-drawer fiber management unit 45
- Figure 4 Airflow directions of upper and lower cooling units in an NTRU04 57
- Figure 5 Clearance to swing a door open on a NEBS 2000 frame 73
- Figure 6 A shelf assembly in a rack, isometric front view 90
- Figure 7 Task flow of site preparation 95
- Figure 8 NEBS 2000 footprint measurements 98
- Figure 9 Task flow of preparing the floor for anchor holes 102
- Figure 10 Anchoring to a raised floor with removable tiles 108
- Figure 11 Drilling a raised floor without removable tiles 109
- Figure 12 Anchor in a concrete floor 110
- Figure 13 MFA150 power system of five rectifiers for two Passport 15000 or 20000 shelves 124
- Figure 14 Grounding an NTRU04 frame to a ground window 140
- Figure 15 Polyvalent power-and-ground assembly A0834143 149
- Figure 16 ETSI power-and-ground assembly A0834149 151
- Figure 17 IBN grounding 154
- Figure 18 CBN grounding 155
- Figure 19 Mesh-BN bonding network 166
- Figure 20 Mesh-IBN isolated bonding network 167
- Figure 21 Star-IBN isolated bonding network 168

List of tables

Table 1	Combinations of BIMs in a BIP	33
Table 2	Determining cable density by the number and type of cards	38
Table 3	Diameters of processor card cables	38
Table 4	Operational environment specifications for a Passport 15000 or 20000	49
Table 5	Operational environment specifications for a Passport 15000-VSS	50
Table 6	Operational environment specifications for a Passport 15000 with a Shasta 5000	51
Table 7	Power budget for a Passport 15000 or 20000 shelf assembly (fully provisioned)	52
Table 8	Base weight of a frame shipped with one Passport 15000 switch (shelf)	60
Table 9	Base weight of a frame shipped with two Passport 15000 switches (shelves)	61
Table 10	Base weight of a frame shipped with one Passport 20000 switch (shelf)	62
Table 11	Base weight of a frame shipped with two Passport 20000 switches (shelves)	63
Table 12	Weight of optional or additional Passport 15000 or 20000 parts	65
Table 13	Weights of a frame with a Passport 15000-VSS	68
Table 14	Weights of a frame with a Passport 15000 and a Shasta 5000	68
Table 15	Weight of Passport 15000 shelf-based parts that are installed in a 23-inch EIA rack	69
Table 16	Weight of Passport 20000 shelf-based parts that are installed in a 23-inch EIA rack	70
Table 17	Optional and to-be-determined weights for a Passport 15000 or 20000 in a 23-inch EIA rack	71
Table 18	Cable lengths between an EdgeLink 100 and a Passport 15000 or 20000	81
Table 19	Passport 15000 and 20000 shelf air temperature rise	92
Table 20	Frame anchoring kits	115
Table 21	Power consumption for hardware parts for a Passport 15000 or 20000	127
Table 22	Power feed sizes	135

Table 23	Cable identification, North America	137
Table 24	Cable identification, Germany	137
Table 25	Cable identification, United Kingdom	138
Table 26	Cable identification, Japan	138
Table 27	Feed codes of the BIP BIMs, rear view	142
Table 28	North American ratings for cable	145

About this document

The following topics are discussed in this section:

- “Who should read this document and why” (page 15)
- “What you need to know” (page 15)
- “What’s new in this document” (page 16)
- “Related documents” (page 19)
- “How to get more help” (page 19)

Who should read this document and why

This document is intended for use by enterprise or central office planning personnel who have experience in facilities planning and are familiar with the Passport 15000 or 20000.

What you need to know

Installation and planning personnel should be familiar with Passport 15000 or 20000 hardware and general enterprise or central office procedures and equipment.

You should also be familiar with fundamental data communications and basic electronic concepts and terms. You can acquire product knowledge by reading 241-5701-030 *Passport 7400, 15000, 20000 Overview* and 241-1501-200 *Passport 15000, 20000 Hardware Description*.



WARNING

Risk of radio interference

Passport 15000 is a class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

What's new in this document

The following features were added to this document:

- “16-port OC-3/STM-1 POS and ATM FP with PEC NTHW44” (page 17)
- “An additional version of the lower and upper cooling units” (page 17)
- “Enclosing a NEBS 2000 frame with doors and side panels” (page 18)
- “Voice services processor 3 with optical TDM interface (2pOC3ChSmIrVsp3)” (page 18)
- “Y-protection for dual 16-port OC-3/STM-1 POS and ATM FPs” (page 18)

Other changes made to this document include the following:

- added “Assess air filter maintenance” (page 33) and included it in the task flow “Task flow of planning considerations” (page 30)
- added the weight for a top frame bracket NTRU0185 and corrected the weight of a NEBS 2000 frame NTRU04 to the these tables and updated the total weight tallies:
 - “Base weight of a frame shipped with one Passport 15000 switch (shelf)” (page 60)
 - “Base weight of a frame shipped with two Passport 15000 switches (shelves)” (page 61)
 - “Base weight of a frame shipped with one Passport 20000 switch (shelf)” (page 62)
 - “Base weight of a frame shipped with two Passport 20000 switches (shelves)” (page 63)

- added the weight of a NEBS 2000 frame joining kit NTRU0101 to the table “Weight of optional or additional Passport 15000 or 20000 parts” (page 65)
- changed the heading “Front and rear access” to “Front and rear access to switch hardware” (page 72)
- added the section “Kits of spare parts for a Passport 15000 or 20000” (page 85)
- corrected the calculation of the area of the maintenance aisle space in “Checking the floor” (page 104)
- moved planning criteria for extended cable management brackets into new section “When adding a door to a NEBS 2000 frame” (page 111)
- corrected all occurrences of BIP part numbers NT6C67 to be AP6C67 and all occurrences of NT6C68 to AP6C68 through this document

16-port OC-3/STM-1 POS and ATM FP with PEC NTHW44

The function processor (FP) 16-port OC-3/STM-1 packet over SONET (POS) and asynchronous transfer mode (ATM) with product engineering code (PEC) NTHW44 and software name 16pOC3PosAtm is added to the list of available FPs. These tables are updated:

- “Weight of optional or additional Passport 15000 or 20000 parts” (page 65)
- “Power consumption for hardware parts for a Passport 15000 or 20000” (page 127)

An additional version of the lower and upper cooling units

An additional version of the lower (rear) and upper (front) cooling units is available. The following distinguish one version from the other:

- updated all of the tables in “Equipment size and weight” (page 58)
- added the section “Spare cooling units or cooling unit parts” (page 84)
- updated the table “Power consumption for hardware parts for a Passport 15000 or 20000” (page 127)

Enclosing a NEBS 2000 frame with doors and side panels

A NEBS 2000 frame can be enclosed by adding doors to the front and rear of the frame using the hardware kit NTQS37AA or NTQS37AB and by adding the side panels and hardware from the kit NTPX4050. These changes are made to this document:

- updated “General guidelines for placing the equipment” (page 55) to indicate there is a change in the frame footprint
- added the weights of the doors, extended side panels, top frame bracket, and brandline covers to the table “Weight of optional or additional Passport 15000 or 20000 parts” (page 65)
- updated “Front and rear access to switch hardware” (page 72) to include the space required to open a door that is added to a NEBS 2000 frame
- added the need for an increased footprint due to door hardware in “Using the NEBS floor template” (page 97)
- updated the task flow “Preparing the floor for anchor holes” (page 101) to accommodate the increased footprint needed by door hardware
- added “When adding a door to a NEBS 2000 frame” (page 111) to indicate the measurements of a changed frame footprint when adding one or two doors
- updated the procedure “Marking the footprint and the anchor holes on the floor” (page 112) to add extended size side panels with the regular size

Voice services processor 3 with optical TDM interface (2pOC3ChSmlrVsp3)

The following sections were added or updated for this feature.

- “Weight of optional or additional Passport 15000 or 20000 parts” (page 65)
- “Power consumption for hardware parts for a Passport 15000 or 20000” (page 127)

Y-protection for dual 16-port OC-3/STM-1 POS and ATM FPs

The following sections were added or updated this feature.

- “Determining your cable density” (page 37) to indicate where to position Y-splitter couplers

- “Placing a fiber management unit for cable slack” (page 45) to indicate what to do with Y-splitter couplers of fiber optical cables
- “Using custom-made processor card or system cables” (page 47)

Related documents

See the following documents for related information:

- 241-5701-001 *Passport 7400, 15000, 20000 Documentation Guide*
- 241-5701-002 *Passport 7400, 15000, 20000 Using New Task-based Documentation*
- 241-5701-005 *Passport 7400, 15000, 20000 List of Terms*
- 241-5701-030 *Passport 7400, 15000, 20000 Overview*
- 241-1501-200 *Passport 15000, 20000 Hardware Description*
- 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*
- 167-9021-102 *Advanced Power Systems MFA150 Modular Front Access Power System Description, Operation and Maintenance User Manual*
- 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*

How to get more help

For information on training, problem reporting, and technical support, see the “Nortel Networks support services” section in the *product overview document*.

Chapter 1

Safety information

The safety information in this section applies to all activities of site planning and preparation and to the installation and maintenance of a Passport 15000 or 20000. Where procedures occur throughout the suite of Passport NTPs, the appropriate safety information is repeated.

Follow all warnings and cautions provided with this product, as well as the safety procedures identified by your company. Some procedures must be performed by qualified personnel. Where indicated, contact your Nortel Networks technical support representative.

The safety information for Passport 15000 or 20000 includes:

- “Personal safety” (page 22)
- “Safe equipment handling” (page 23)
- “Avoiding equipment damage from static electricity” (page 24)
- “Storing and transporting circuit cards” (page 28)
- “Compliance with electrical and safety standards” (page 28)

Personal safety

Symbols are used in this document to indicate the need for personal safety. For procedures involving tasks that risk personal injury, a **WARNING** is provided at the procedure or the step in the procedure where task-specific safety information is required. The following are examples of personnel safety warnings for the Passport 15000 or 20000.



WARNING

Risk of injury when handling a frame

Never place a foot or a hand under any part of the frame while it is being tilted or moved. Always move it with three or four people. The weight of a shipped frame with one Passport 15000 or 20000 is approximately 419 kg (926 pounds); with two Passport 15000s the weight is approximately 612 kg (1,344 pounds). For additional protection, wear safety boots with steel toes.



WARNING

Verletzungsgefahr beim Gestelltransport

Stellen Sie niemals einen Fuß unter das Gestell, wenn dieses bewegt oder gekippt wird, und greifen Sie nicht unter das Gestell. Die Einheit muß mit vier Personen von der Transportpalette genommen werden. Ein Gestell wiegt mit einem Passport 15000 oder 20000 ca. 420 kg, mit zwei Passport 15000-Einheiten ca. 610 kg. Tragen Sie zu Ihrem zusätzlichen Schutz Sicherheitsschuhe mit Stahlkappen.



WARNING

Risk of injury by electrocution

When a breaker interface module (BIM) is unseated, regardless of switching breakers on or off, the capacitors inside a BIM need time to discharge. Wait 15 seconds before re-seating the BIM or removing it from the breaker interface panel (BIP).

**WARNUNG****Verletzungsgefahr**

Die Speisestromzuführungen zu jedem BIM sind für bis zu 100 A ausgelegt. Wenn ein BIM vom BIP getrennt wird, benötigen die Kondensatoren im BIM 15 Sekunden zur Entladung. Lassen Sie das BIM während dieser Zeit freigeschaltet und innerhalb des BIP.

**WARNUNG****Risk of injury or damage by electricity**

When switching off power breakers on a breaker interface module (BIM) or in the circuit up to it, or removing a fuse from the circuit up to it, always put tape over the breaker or fuse cavity. The tape indicates it was manually switched off, and not tripped by the system. This prevents accidental activation of the power circuit, especially if power cables are being handled.

**WARNUNG****Schäden oder Verletzungen durch Elektrizität**

Wenn die Leistungtrennschalter an einem Trennschalterkopplungsmodul (BIM) oder im zuführenden Stromkreis geöffnet bzw. Sicherungen aus dem Stromkreis entfernt werden, decken Sie den Trennschalter oder den Sicherungssteckplatz mit Klebeband ab. Das Klebeband signalisiert, daß er manuell ausgeschaltet und nicht vom System ausgelöst wurde. Damit verhindern Sie eine versehentliche Aktivierung der Stromversorgung, besonders beim Hantieren mit Netzkabeln.

Safe equipment handling

Safe equipment handling includes “Personal safety” (page 22), safely moving the NEBS 2000 frame that houses one or two Passport 15000 or 20000 switches, preventing damage by electrostatic discharge (ESD), and following regulatory safety activities for the installation and maintenance of a switch. The symbol used in this document for safe equipment handling is:



CAUTION

Loss of service

For procedures involving tasks that risk damaging equipment, a CAUTION is provided at the procedure or the step in the procedure where task-specific safety information is required.



ACHTUNG

Betriebsstörungen

Mit diesem Hinweis sind Vorgänge oder Arbeitsschritte gekennzeichnet, bei denen die Gefahr von Geräteschäden besteht. Es werden jeweils situationsspezifische Informationen gegeben.

Moving the frame safely

The size and weight of a partially or fully provisioned Passport 15000 or 20000 requires equipment that is needed to move it from the receiving area to the place where it is to be anchored to the floor. For the safe handling of a frame, see 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

Avoiding equipment damage from static electricity

Damage to electronic components can occur from the discharge of static electricity when a hand touches a circuit module. To avoid equipment damage by electrostatic discharge (ESD), wear a wrist strap. Nortel Networks recommends also using conductive carpet flooring with conductive shoes, or heel “grounders”. The symbols used in this document to avoid equipment damage by ESD are:



CAUTION

Risk of equipment damage by ESD

Unpack a circuit card or module only minutes before it is to be inserted in its slot in the Passport 15000 or 20000. The packaging protects the circuitry from electrostatic discharge (ESD).

**ACHTUNG****Geräteschäden durch elektrostatische Entladung**

Nehmen Sie Schaltkarten oder Module erst unmittelbar vor dem Einsetzen in den Steckplatz im Passport 15000 oder 20000 aus der Verpackung. Die Verpackung schützt die Schaltungen vor elektrostatischer Entladung.

**CAUTION****Risk of damage to equipment by ESD**

Although the electronic components of a Passport 15000 or 20000 switch are not touched directly by hand, handling any part of it or its frame can generate electrostatic discharge (ESD) that is transferred to ESD-sensitive hardware inside the switch. Always ground yourself by an approved anti-ESD method before and while handling any tools or hardware on or near the switch hardware. You can plug the provided wrist strap (part number A0378999) into an anti-ESD jack on the lower left mounting ear of either cooling unit (row of fans).

**ACHTUNG****Geräteschäden durch elektrostatische Entladung**

Obgleich die Elektronikbauteile eines Passport 15000 oder 20000 nie direkt mit der Hand berührt werden, kann durch Berühren anderer Bestandteile oder des Gestells elektrostatische Entladung entstehen, die auf interne, elektrostatisch gefährdete Hardware-Komponenten des Passport übertragen wird und zu Störungen führen kann. Vermeiden Sie elektrostatische Entladung, indem Sie sich nach einer anerkannten Methode erden, bevor und während Sie am oder in der Nähe des Passport mit Werkzeug oder Hardware hantieren. Stecken Sie das mitgelieferte Armband (Artikelnummer A0378999) in die dafür vorgesehene Buchse im unteren linken Flansch eines Kühlaggregats (Lüfterreihe).

Installing the switch safely

Installing the switch safely applies mostly to anchoring the frame securely to the floor and connecting the appropriate power and grounding cables.

Before anchoring the frame to the floor, ensure that there is a minimum of 76.2 cm (30 inches) in the front and 61 cm (24 inches) in the rear of the bay. The minimum is required to enable personnel to safely do various installation, maintenance, or upgrade tasks. For example, replacing a fan controller module requires the maintenance technician to bend over and reach into the switch to access an upper or a lower fan controller module. This can be done safely and without damage to equipment by complying to the minimum allowance. The minimum is also enough to do other maintenance tasks, such as replacing an air filter, opening cage doors, or replacing a module.



CAUTION

Risk of service degradation or equipment damage

While drilling into the floor to create anchor holes, vacuum the dust. Use a vacuum with an induction-wound motor to prevent EMI from affecting nearby electronic circuitry. Dust can prevent the proper seating of cards or modules or prematurely increase the arresstance of the cooling air through the fan filters.



ACHTUNG

Leistungsbeeinträchtigung oder Geräteschäden

Entfernen Sie den Bohrstaub, der beim Setzen der Verankerungslöcher anfällt, sofort mit einem Staubsauger. Verwenden Sie einen Staubsauger mit Induktionsmotor, damit in der Nähe befindliche Elektronikbaugruppen keinen elektromagnetischen Störungen ausgesetzt sind. Der Bohrstaub kann dazu führen, daß die Module nicht richtig sitzen und daß sich der Lüfterfilter vorzeitig zusetzt.

**CAUTION****Risk of damage by fire**

In the bottom rear center of the frame, each removable plate (drip tray, part number P0870734) may have two knockout disks. Each knockout disk must remain intact and unbent unless a power conduit from a raised floor will be routed through it. Leaving an opening reduces the fire-proofing of the Passport 15000 or 20000.

**ACHTUNG****Geräteschäden**

Die Ausbrechöffnungen in der Platte, die sich auf der Rückseite jedes Gestells unten in der Mitte befindet, sollten nur dann geöffnet werden, wenn eine Stromleitung von einem Montageboden durchgeführt werden muß. Unnötige Öffnungen vermindern die Feuersicherheit der Schaltereinheit.

**CAUTION****Risk of equipment damage by fire**

To remove a conduit knockout disk from the bottom rear center plate, remove the plate to a bench. Knock out a disk at the bench so that the plate is not bent. A bent plate leaves an opening which reduces the fire proofing effect of the Passport 15000 or 20000.

**ACHTUNG****Geräteschäden**

Wenn Sie aus der unteren mittleren Rückwandplatte eine Durchführungsöffnung ausbrechen wollen, legen Sie die Platte auf einen geeigneten Werkstisch. Achten Sie darauf, daß die Platte beim Ausbrechen der Scheibe nicht verbogen wird. Eine verbogene Platte läßt im montierten Zustand eine Spaltöffnung an den Kanten frei. Dadurch verschlechtert sich die Feuersicherheit der Schalteinheit.

After using the footprint template to mark the floor for the anchor holes, ensure it is installed between the floor and the levellers. The template adds to insulating the switch from electrical current. Also, slip the insulating feet over the anchoring rods. The feet are brown or yellow disks provided in the anchoring kit (either NTRU0325 for zone 2 anchoring or NTRU0327 for zone 4 anchoring).

Storing and transporting circuit cards

Care is required to store or transport circuit modules.

Store each circuit module in its own antistatic material and transportation package to avoid physical or ESD damage or the accumulation of dust on contacts. Be careful not to damage the module while packaging it.

Store packaged circuit modules in areas where the relative humidity is less than 95% and the temperature is less than 70 degrees Celsius (158 Fahrenheit). This significantly reduces the chances of warping the circuit board and corrosion of electrical contacts. The nominal storage humidity is 55% and the nominal storage temperature is 20 degrees Celsius (68 Fahrenheit).

Compliance with electrical and safety standards

Passport 15000 or 20000 switches comply with North American and international regulatory safety requirements for the handling and the installation of equipment. For a complete list of standards, see “Standards and compliance considerations” (page 159).

Chapter 2

Planning considerations


Plan the location and installation of a Passport 15000 or 20000 switch using all the information in this section. It is important that you review all considerations because site requirements vary depending on specific installation options.

- “Task flow of planning considerations” (page 29)

Task flow of planning considerations

This task flow shows the sequence in which to plan for the installation of a Passport 15000 or 20000 switch and its accessories or peripheral hardware. To link to any procedure, go to “Task flow navigation” (page 31).

Figure 1
Task flow of planning considerations



Task flow navigation

The following references in the task flow are listed here alphabetically:

- “Adding a switch to an anchored NEBS 2000 frame” (page 32)
- “Assess air filter maintenance” (page 33)
- “Assess cable management” (page 35)
- “Assess environmental requirements” (page 49)
- “Assess power cable location” (page 54)
- “Assess the location of a Passport 15000 or 20000” (page 55)
- “Assess the location of a system of ac rectifiers” (page 74)
- “Assess the locations of peripheral equipment” (page 76)
- “Assess spare parts storage and selection” (page 83)
- “Assess timing requirements” (page 85)
- “Plan for the use of an equivalent mounting apparatus” (page 87)

Adding a switch to an anchored NEBS 2000 frame

With packages NTQH03 or NTQS03, a Passport 15000 or 20000 can be added to a NEBS 2000 frame that is already anchored. The addition can occur as a re-deployment or as a new installation without affecting the service of a Passport in the lower position of the frame. Use the requirements and considerations of planning the installation of either Passport as indicated throughout this document. For example, some of the unit weights or power consumptions of the plug-in cards and modules are different between a Passport 15000 and 20000. For the differences, see

- “Equipment size and weight” (page 58)
- “Power distribution and consumption” (page 125)

When two Passport 15000 or two Passport 20000 nodes are installed in the same NEBS 2000 frame, they share the same BIP. The power ratings of the BIMs must be matched to the power demands of the shelf assembly. If you wish to add a Passport 20000 to a frame that already has a Passport 15000 mounted in it, or wish to add a Passport 15000 to a frame that already has a Passport 20000 mounted in it, use the table “Combinations of BIMs in a BIP” (page 33) to plan a safe installation involving equipment with different power ratings.

A label on the cover of the cable channel that runs across the front of the shelf assembly identifies the lower shelf node as a Passport 15000 or Passport 20000. On older models of a Passport 15000, the cover is blank. The type of shelf indicates which version of the BIP you have.

Table 1
Combinations of BIMs in a BIP

Shelf type	PEC of a BIP with 2 BIMs	PECs of the BIM pairs that can be installed
Passport 15000	NT6C62	two or four 20-amp NT6C60PA for one or two Passport 15000s or two 20-amp NT6C60PA for the Passport 15000 in the lower half of the NEBS 2000 frame and two 25-amp AP6C67PA for a Passport 20000 in the upper half of the NEBS 2000 frame
Passport 20000	AP6C68	two or four 25-amp AP6C67PA for one or two Passport 20000s or two 25-amp AP6C67PA for the Passport 20000 in the lower half of the NEBS 2000 frame and two 20-amp NT6C60PA for a Passport 15000 in the upper half of the NEBS 2000 frame

Assess air filter maintenance

The air filter for each Passport 15000 or 20000 must be replaced at three-month intervals or more often to ensure that the plug-in processor cards, fabric cards, and modules do not fail or degrade their performance due to the accumulation of dust. In order to validate the equipment warranties, you may have to replace the filter more often than three months from the power-up date of the Passport, and just as periodically thereafter. Upper and lower air filters require the same interval of replacement.

When choosing the anchored position of a Passport 15000 or 20000 in a mounting apparatus, minimize the amount of particulates that the filters trap by ensuring that the switch is not located near room ventilation or in the path of air exhaust from other equipment. See also “Cooling considerations” (page 91).

Vacuuming around the Passport equipment will reduce the amount of particulates drawn into the air filters, which improves their cooling efficiency over time, but will not change the interval of replacing an air filter. For

information about vacuuming and the special equipment, refer to “Equipment vacuuming” in *241-1501-240 Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

The frequency of replacing an air filter and the date of the actual replacement for each Passport must be recorded. In *241-1501-240 Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade* at the procedure to replace an air filter, a one-page form is provided. Nortel Networks intends that a hardcopy of the form be kept near the switches for your recording convenience and to be available upon request.

When a plug-in card or module is returned to Nortel Networks for warranty service, you may be asked to provide a copy of the air filter replacement form to validate the warranty. Equipment that failed due to accumulated particulates will void that equipment’s warranty.

Order a supply of replacement filters for each Passport 15000 or 20000 to prepare for the frequency of replacement. The part numbers for the available packages are listed in *241-1501-200 Passport 15000, 20000 Hardware Description*, the chapter of field replaceable units (FRUs).

Assess cable management


Assess cable management to determine how your site will support the cabling required for a Passport 15000 or Passport 20000 switch.

- “Task flow of cable management assessment” (page 35)

Task flow of cable management assessment

This task flow shows you the sequence of criteria needed for you to appropriately assess cable management requirements. To link to any procedure, go to “Task flow navigation” (page 36).

Figure 2
Task flow of cable management assessment



Task flow navigation

- “Determining your cable density” (page 37)
- “Managing low-density cabling” (page 42)
- “Managing high-density cabling” (page 40)
- “Managing very high-density coax cabling” (page 43)
- “Placing a fiber management unit for cable slack” (page 45)
- “Using custom-made processor card or system cables” (page 47)

Determining your cable density

Passport 15000 and Passport 20000 switches support low-density cable management and, through the use of additional cable management brackets, high-density, and very high-density cable management. You must determine current and future cabling requirements. By calculating the immediate and future cable requirements, you can determine whether the basic cable management brackets will accommodate your cable density, or whether you will need to add the optional additional cable management brackets. The two kinds of high-density cable management brackets are:

- the high-density cable management bracket pairs for fiber, or mini-coax, or both
- the extended cable management brackets for 8W8 mini-coax or standard coax

The brackets and their intended uses are described in 241-1501-200 *Passport 15000, 20000 Hardware Description*.

The couplers that are part of fiber optical Y-splitter cable assemblies (for example, with NTHW44 FPs) must not reside inside any type of cable management bracket that is provided with or for the NEBS 2000 frame. The presence of a coupler inside a bracket will occupy space that should be used for other cables sharing the same routing path.

Use the table “Determining cable density by the number and type of cards” (page 38) to identify which brackets you will need.

The table “Diameters of processor card cables” (page 38) identifies the area of individual and clustered cables.

Table 2
Determining cable density by the number and type of cards

Cable density	Number of FP types
Low	<ul style="list-style-type: none"> • less than five 12-port DS3s or E3s are in one cage (one row of a shelf) • less than nine 12-port DS3s or E3s are in one NEBS 2000 frame • fewer than 15 to 28 FPs of any type occupy one or two Passport 15000 or 20000 switches in one NEBS 2000 frame • less than ten 16-port OC-3/STM-1s using MT-RJ cables in one NEBS 2000 frame • less than eleven 16-port OC-3/STM-1s using LC cables in one NEBS 2000 frame
High	<ul style="list-style-type: none"> • greater than five 12-port DS3s or E3s are in one cage (one row of a shelf) • 15 to 28 FPs of any type occupy one or two Passport 15000 or 20000 switches in one NEBS 2000 frame • greater than ten 16-port OC-3/STM-1s using MT-RJ cables in one NEBS 2000 frame • greater than eleven 16-port OC-3/STM-1s using LC cables in one NEBS 2000 frame
Very high (coax cables only)	<ul style="list-style-type: none"> • greater than nine 12-port DS3s or E3s are in one NEBS 2000 frame • a shelf full of 12-port DS3s or E3s in one NEBS 2000 frame

Table 3
Diameters of processor card cables

Type of cable	Diameter per cable	Cross-sectional area
control cable, with DB9 connector	5.0 or 6.0 mm	___ mm ²
fiber, simplex multimode or single-mode with SC connectors	2.9 mm	9.0 mm ²
(Sheet 1 of 2)		

Table 3 (continued)
Diameters of processor card cables

Type of cable	Diameter per cable	Cross-sectional area
fiber, simplex multimode or single-mode with LC connectors	2.0 mm	4.0 mm ²
fiber, simplex multimode or single-mode with MT-RJ connectors	2.9 mm	9.0 mm ²
fiber, duplex multimode or single-mode with SC connectors	5.8 mm	18.0 mm ²
fiber, duplex multimode or single-mode with LC connectors	4.0 mm	8.0 mm ²
coax, standard size	____ mm	____ mm ²
mini-coax 8w8, single cable	3.0 mm	9.0 mm ²
mini-coax 8w8, cluster of 8 cables	10.5 mm	113.0 mm ²
(Sheet 2 of 2)		

To calculate the area of the cables, multiply the total number of cables by the value of the cross-sectional area for that cable type. Calculate the area for each type of cable on your shelf. If the sum of the areas is less than 1400 mm² than you have a low-density cabling. If the sum is greater than 1400 mm², but not greater than 2800 mm², you have a high-density cabling.

For example, the area of cables for five 16-port OC-3/STM-1 FPs (NTHW21 with MT-RJ connectors) which have a cross-sectional area of 9.0 mm² can be calculated as follows:

$$\langle \text{total number of FPs} \rangle * \langle \text{number of cables} \rangle * \langle \text{cross-sectional area} \rangle = \text{total area of cable bundle}$$

$$5 * 16 * 9.0 \text{ mm}^2 = 720.0 \text{ mm}^2$$

The total area, for this example, is 720.0 mm². Since the total area is less than 1400 mm², this configuration is a low-density cabling situation.

Depending on the number and type of processor cards (CPs and FPs) that are provided with a Passport 15000 or 20000 or to be added later, the basic cable management brackets may need to be doubled or replaced to accommodate a

high-density cabling. A pair of plastic cable management brackets are used to accommodate both coax and fiber high-density. The optional left-side or right-side extended cable management brackets support very high-density coax cabling. The extended brackets are needed when a switch has high-capacity electrical FPs, for example, when greater than nine 12-port DS3s are provisioned in a NEBS 2000 frame or equivalent. High-density optical brackets are needed when a switch has high-capacity optical FPs such as the 16-port OC-3/STM-1 FPs.

Managing high-density cabling

To plan cable management for Passport 15000 and Passport 20000 switches with high-density cabling, do the following:

- review background information on managing telecom cables in 241-1501-200 *Passport 15000, 20000 Hardware Description*
- review the description of high-density cable management brackets in 241-1501-200 *Passport 15000, 20000 Hardware Description*
- review cable and connection specifications for the types of cables you are planning to install. Cable specifications are listed in 241-1501-200 *Passport 15000, 20000 Hardware Description*
- review basic cable handling guidelines listed in the best practices section of 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*
- ensure that the installer is familiar with the task flows and procedures for routing high-density cables listed in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*

Example high-density routing calculation

This example of a high-density routing calculation demonstrates how the capacity of cable management brackets and troughs are determined for a switch populated with 16-port-OC-3 FPs. Two versions of this FP are discussed.

Note: The following section is an example of routing capacity calculations. The calculations for any specific site will vary depending on the type and number of high-capacity FPs used.

The following FPs are used in this example.

NTHW21AB - 16-port card containing:

- MT-RJ Fiber connectors
- 2 fibers per jacket = 16 fiber cables per card
- 8 cards per shelf creating 128 cables per shelf (16 x 8)
- total area of 128 fiber cables = 904.96 mm²

NTHW31AB - 16-port card containing:

- LC fiber connectors
- 1 fiber per jacket with 32 fiber cables per card
- 8 cards per shelf creating 256 fiber cables per shelf (32 x 8)
- total area of 256 fiber cables = 803.84 mm²

The total area in the cable trough under the fiber organizer is 2232.88 mm²

The approximate area available in the molded plastic cable management brackets is

- $35 \times 21 = 735$ mm² in the first bracket compartment
- $26 \times 21 = 546$ mm² in the second compartment
- $18 \times 21 = 378$ mm² in the third compartment

Therefore the approximate area available in a fiber management bracket is 1659 mm². To ensure proper cable management, any area greater than 1400 mm², but less than 2800 mm², is considered high-density.

To determine the capacity required for NTHW21:

- 1 Calculate the number of fibers. In this example uses 16 MT-RJ fibers per card with a fiber diameter of 3 mm. Eight cards are in the lower half of the shelf containing 128 fibers and 6 cards are in the upper half of the shelf containing 96 fibers. Therefore the total number of 224 fibers will need to be installed

- 2 Calculate the capacity of the cable management bracket. In a packed scenario, using a single cable bracket (P0937935), the first compartment holds 87 fibers, the second 64 fibers, and the third 40 fibers for a total of 187 fibers. In an unpacked scenario, the first compartment holds 77 fibers, the second 56, and the third 35 for a total of 168 fibers.

Based on this calculation, a single cable bracket (P0937935) will handle the fibers from only one-half of a shelf (a cage) containing NTHW21 cards.

To determine the capacity required for NTHW31:

- 1 Calculate the number of fibers. In this example uses 32 LC fibers per card. Eight cards are in the lower half of the shelf containing 256 fibers and 6 cards are in the upper half of the shelf containing 192 fibers. Therefore the total number or 448 fibers will need to be installed.
- 2 Calculate the capacity of the cable management bracket. In a single cable bracket (P0937935) the first compartment holds 170 fibers, the second compartment holds 120 fibers, and the third 80 fibers for a total of 370 fibers.

Based on this calculation, a single cable bracket (P0937935) will handle the fibers from only one-half of a shelf containing NTHW31 cards.

Managing low-density cabling

To plan cable management for Passport 15000 and Passport 20000 switches with low-density cabling, do the following:

- review background information on managing telecom cables in *241-1501-200 Passport 15000, 20000 Hardware Description*
- review cable and connection specifications for the types of cables you are planning to install. Cable specifications are listed in *241-1501-200 Passport 15000, 20000 Hardware Description*
- review basic cable handling guidelines listed in the best practices section of *241-1501-240 Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*
- ensure that the installer is familiar with the task flows and procedures for routing cables listed in *241-1501-240 Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*

Managing very high-density coax cabling

To plan cable management for Passport 15000 and Passport 20000 switches with very high-density coax cabling, do the following:

- review the explanation of the use of extended cable management brackets and study the cable routing example provided at the end of this section

Note: Using extended cable management brackets expands the footprint of a Passport 15000 or a Passport 20000 switch. Review the material in “Assess the location of a Passport 15000 or 20000” (page 55) to determine the allowance that must be made to accommodate these brackets.

- review background information on managing telecom cables in 241-1501-200 *Passport 15000, 20000 Hardware Description*
- review the description of the extended cable management brackets in 241-1501-200 *Passport 15000, 20000 Hardware Description*
- review cable and connection specifications for the types of cables you are planning to install. Cable specifications are listed in 241-1501-200 *Passport 15000, 20000 Hardware Description*
- review basic cable handling guidelines listed in the best practices section of 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*
- ensure that the installer is familiar with the task flows and procedures for routing high-density cables listed in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*

Using cable management brackets

For high-density cabling that involves coax or 8W8 mini-coax cables, the basic cable management brackets can be replaced by the optional left-side or right-side extended cable management brackets for coax or a pair of molded plastic brackets for fiber.

The kit number for a left-side extended bracket (facing the front of the frame) is NTRU0368 and the right-side is NTRU0369. All the hardware to install one bracket is included in each kit.

High-density brackets are two molded plastic brackets each with part number P0937935.

You must choose the number of optional extended brackets you will need because the brackets cannot be installed before the frame is shipped. The number of needed brackets is determined by:

- the volumes of either kind of cable, for example, a switch full of 12-port DS3s is 348 mini-coax cables and two switches is 700 FP cables
- the direction you plan to route the cables, up over the frame or down under the floor, or both
- the starting point as a lower switch, an upper switch, or both

Up to four extended cable management brackets fit on each side of the NEBS 2000 frame. The bracket installation procedure identifies where the brackets are fastened to the frame.

After choosing the number of brackets for each side of the frame, ensure that the footprint of the frame is marked on the floor to accommodate the extended brackets, especially if the frame is installed adjacent another frame. See “When anchoring NEBS 2000 frames side-by-side” (page 116) and “Marking the footprint and the anchor holes on the floor” (page 112).


For cable management on a Passport 15000 or 20000 switch, all coax cables are typically routed to the right front side of the NEBS 2000 frame (facing the front of the switch) and all fiber and CP cables are typically routed to the left. Depending on the number of DS3 or E3 FPs, cable management can be made easier to install, maintain, add to, or upgrade when the optional extended cable management brackets are used.

To develop a cable routing plan, for specific FP types, such as 16-port OC-3 FPs, review the guidelines for routing high-density cables in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

Placing a fiber management unit for cable slack

Fiber cable slack can be managed near the Passport 15000 or 20000 switch by installing one or more optional dual-drawer fiber management units in the same or an adjacent NEBS 2000 frame as the switch. The product engineering code (PEC) of the fiber unit is NTHW50. See the figure “A dual-drawer fiber management unit” (page 45).

Figure 3
A dual-drawer fiber management unit



Each fiber shelf includes two latched drawers that accommodate up to 20 fiber cables. Up to six fiber units can fit into either the front or the rear of a NEBS 2000 frame that has a switch in its lower half. The fiber units can be mounted at both the front and the rear of the frame. When installing them at the rear, the cable path from the FP faceplates may not be practical.

The couplers that are part of fiber optical Y-splitter cable assemblies (for example, for NTHW44 FPs) must not reside inside the NTHW50 when managing cable slack from the FPs. The presence of a coupler inside a unit increases the risk of losing traffic because the space to add or remove cables will be more confined and congested.

All fiber units must have separate mounting holes except when shared with a cable management bracket.

A switch fully provisioned with only 4-port OC-3s would require three fiber management units, that is:

14 FPs x 8 connections per FP = 112 cables

112 divided by 40 = 2.8, which means three 2-drawer fiber units

Based on the number of fiber ports your configuration will initially have or might expand to, determine how many fiber units you will need. Then consider where to locate the fiber units relative to the location of the switch. Wherever you plan to locate the fiber management unit, ensure that it does not constrict the access of the fiber cables into it, or unavoidably exceed the bend radius limitations.

Note 1: Once at least one fiber management unit is installed in the upper half of a NEBS 2000 frame, adding a second switch to that frame would require relocating the fiber unit. Relocation means removing the fiber optical connections from service at both ends of the cable path, and disconnecting one end to remove the cables from the fiber unit. Consider installing the fiber management unit in a 21-inch (53.34-cm) mounting apparatus that is anchored near the switch.

Note 2: Nortel Networks recommends that a fiber management unit not be installed in a 23-inch (58.42-cm) EIA rack that already houses a Passport 15000 or 20000 switch because of weight limitations.

Consider leaving trays empty in sequence to accommodate card slots that will have filler cards in them. When a processor card is added to the slot, the tray would be available for the fiber optical cable, if that is the type of card that is installed. Also, the preferred method of replacing a fiber cable is to route and connect a parallel cable to another tray, then cut the connectors off the cable being replaced and leave it installed. Removing a fiber cable from a cluster can disrupt traffic passing through cables sharing the same path.

Using custom-made processor card or system cables

Since all fiber signaling cables for function processor (FP) cards are your responsibility to have them measured, cut, and assembled for each installation and because managing cable slack requires the NTHW50 fiber cable management unit, the length of the fiber cables varies according to the location of fiber cards within the shelf and the distance of the shelf from the next equipment in the port connection paths.

For the electrical FPs (for example, with DS3, E3, or E1 interfaces), Nortel Networks also offers prefabricated cable assemblies for the traffic (signaling) ports, and the control ports for sparing panels.

Prefabricated cable assemblies are also provided for the control processors (CPs). To use an equivalent cable with a different length, you can custom make your own.

Prefabricated cables are available for the alarm/BITS module that interfaces with the site's timing (clocking) source.

Prefabricated cable assemblies are not offered by Nortel Networks for fiber optical FPs.

The position of the coupler on each fiber optical Y-splitter cable is critical for having effective cable management on a Passport 15000 or 20000. Plan the length of each installed cable so that its coupler:

- will not reside across the front of the shelf
- will not reside in a drawer of the fiber management unit (NTHW50)
- resides on the side of the NEBS 2000 frame or equivalent mounting apparatus, or beyond, but not on any of the cable management brackets

Prefabricated cables are not provided for the external alarm connections.

If you are planning to custom make cables for any of the following,

- the fiber optical FP cards
- the electrical FP cards and their termination panels
- the CPs
- BITS timing
- external alarms

the specifications of each cable assembly is identified in 241-1501-200 *Passport 15000, 20000 Hardware Description* for each hardware unit.

Note: Some cable assemblies for the Passport 15000 or 20000 identify only the prefabricated version and do not provide specifications for custom-making the cable. In these cases, it is not recommended to make your cable (for example, the proprietary mini-coax cables with 8W8 connectors).

Assess environmental requirements

This section contains information on the physical environment required to operate the Passport 15000 or 20000. These topics include:

- “Operational environment” (page 49)
- “Power dissipation” (page 51)
- “Bulk heat dissipation” (page 52)
- “Prerequisites for your earthquake zone and application” (page 53)

Operational environment

The Passport 15000 or 20000 switch hardware should be installed in a climate controlled environment.

The switch hardware complies with the Telcordia NEBS GR-63-CORE, and ETS 300-019-1-3, class 3.1E for operating temperature.

The ranges for temperature, humidity, and other environmental values are listed in the following tables:

- “Operational environment specifications for a Passport 15000 or 20000” (page 49)
- “Operational environment specifications for a Passport 15000-VSS” (page 50)
- “Operational environment specifications for a Passport 15000 with a Shasta 5000” (page 51)

Table 4
Operational environment specifications for a Passport 15000 or 20000

Parameter	Range
Normal operating temperature	5 to 40 degrees Celsius (41 to 104 degrees Fahrenheit)
Normal operating humidity	10% to 90% relative humidity (non-condensing)
(Sheet 1 of 2)	

Table 4 (continued)
Operational environment specifications for a Passport 15000 or 20000

Parameter	Range
Short term operating temperature	-5 to 50 degrees Celsius (23 to 122 degrees Fahrenheit)
Short term operating humidity	5% to 90% relative humidity at 25 degrees Celsius (77 degrees Fahrenheit)
Rate of temperature change	60 degrees Celsius (140 degrees Fahrenheit) or less per hour
Storage temperature	-40 to 70 degrees Celsius (-40 to 158 degrees Fahrenheit)
Earthquake	up to zone 4
Altitude	60 m (197 ft) below sea level to 4,000 m 13,123.36 ft) above sea level
Vibration	0.1 G (1 m/s ²) over the range 5 - 200 Hz
(Sheet 2 of 2)	

Table 5
Operational environment specifications for a Passport 15000-VSS

Parameter	Range
Normal operating temperature	10 to 40 degrees Celsius (50 to 104 degrees Fahrenheit)
Storage temperature	-40 to 70 degrees Celsius (-40 to 158 degrees Fahrenheit)
Normal operating humidity	10% to 90% relative humidity (non-condensing)
Storage humidity	10% to 80% relative humidity non- condensing (5.2 kPa pressure maximum)
Rate of temperature change	60 degrees Celsius (140 degrees Fahrenheit) or less per hour
Altitude	60 m (197 ft) below sea level to 4,000 m 13,123.36 ft) above sea level

Table 6
Operational environment specifications for a Passport 15000 with a Shasta 5000

Parameter	Range
Normal operating temperature	0 to 40 degrees Celsius (32 to 104 degrees Fahrenheit)
Normal operating humidity	10% to 90% relative humidity (non-condensing)
Short term operating temperature	-5 to 50 degrees Celsius (23 to 122 degrees Fahrenheit)
Rate of temperature change	60 degrees Celsius (140 degrees Fahrenheit) or less per hour
Altitude	60 m (197 ft) below sea level to 4,000 m 13,123.36 ft) above sea level
Storage temperature	-40 to 70 degrees Celsius (-40 to 158 degrees Fahrenheit)

For information about how temperature affects the performance of hardware equipment before and during maintenance activities, refer to checking ambient room temperature in the common procedures of general maintenance in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

Power dissipation

Power dissipation is the amount of heat (in watts) generated by electronic and mechanical equipment. It is important to ensure that your ventilation system is able to accommodate the power dissipation from all of the equipment in a single location.

The thermal design of the Passport 15000 or 20000 provides for 3000 W power dissipation per shelf. For the purposes of this calculation, a shelf is defined as a double card cage of 9 times ~53-mm wide modules. Since a NEBS 2000 frame can accommodate two shelves in addition to the fabric

cards, BIP, and cooling units, the total power dissipation for a fully provisioned frame (two shelves) is up to 6000 W. The dissipation for one shelf is calculated as

16 slots at 150 W each + 2 fabric cards at 75 W each + 2 cooling units + BIP = 2700 W for a frame housing one shelf (one Passport 15000 or 20000)

The exact power dissipation of an individual Passport 15000 or 20000 shelf will vary, depending on the number of function processors installed in the shelf. To calculate a Passport 15000's total power dissipation, add the total watts for each individual part (values for each part are shown in the table "Power budget for a Passport 15000 or 20000 shelf assembly (fully provisioned)" (page 52). To determine the power dissipation for a Passport 15000 frame, add the totals for each shelf.

Table 7
Power budget for a Passport 15000 or 20000 shelf assembly (fully provisioned)

Unit	Per unit Watts	Quantity	Total Watts
Fabric slot of a Passport 15000	75	2	150
Fabric slot of a Passport 20000	150	2	300
Expansion slots 0E and 1E (currently unused)	150	2	300
FP or CP slots	150	16	2400
Fan unit	30	3	90
Note: These are maximum design values. Actual card dissipation will be somewhat less depending on implementation.			

Bulk heat dissipation

The heat dissipation of a single Passport 15000 or 20000 shelf is 2580 W/m², and with two shelves is 5160 W/m². These are maximum ratings. Typical ratings are less.

Prerequisites for your earthquake zone and application

Before proceeding, check your site survey and requirements to determine the type of building construction and safety considerations. Due to the small footprint of the proportionately tall NEBS 2000 frame, anchors will be required for both earthquake and non-earthquake applications. Refer to 241-1501-200 *Passport 15000, 20000 Hardware Description* for specific information about the differences between earthquake and non-earthquake installations.

For information about anchoring kits for earthquake zones 2 and 4, for either a raised floor or a concrete floor, contact your Nortel Networks sales representative.

Assess power cable location

This section provides the following information about determining the location of input power cables feeding the Passport 15000 or 20000:

- “Ceiling requirements” (page 54)
- “Flooring requirements” (page 54)

Other floor criteria to consider when choosing an overhead or underfloor route for the power cables is described in “Preparing the floor for anchor holes” (page 101).

Ceiling requirements

Consider the following before installing a NEBS 2000 frame.

- The room should be clear of potential obstructions such as beams, columns, heating and air conditioning ducts, water pipes, lights and video monitors.
- There should be no sprinklers in the room; however, other appropriate fire protection should be available such as a fire extinguisher.
- The minimum ceiling clearance must be 2.5 m (8.25 feet).

Flooring requirements

The flooring can be one of the following types:

- raised subflooring, ideally with a clearance of 45.5 cm (18 inches), and a subfloor cable management system
- non-raised floor such as concrete, which typically means installing conduit according to your local electrical codes

Assess the location of a Passport 15000 or 20000

To assess the location of one or two Passport 15000 or 20000 switches in a NEBS 2000 frame, consider whether the system will always be a stand-alone network node, or whether hardware might be added later. If the frame will contain two switches, consider installing another frame to house the sparing panels or fanout panels to be used in conjunction with the function processors (FP).

This section includes:

- “General guidelines for placing the equipment” (page 55)
- “Equipment size and weight” (page 58)
- “Front and rear access to switch hardware” (page 72)

The marking of actual footprint measurements, including allowance for add-on options, is described in “Site preparation” (page 95).

General guidelines for placing the equipment


Observe these general guidelines when deciding where to place a Passport 15000 or 20000, that is, in the NEBS 2000 frame.

- The area must be stable and free of excess movement and jarring.
- Locate the Passport 15000 or 20000 where its cooling unit fans will not intake exhaust air from other equipment, or blow exhaust air onto other equipment. A switch in the lower frame position pulls air from the base of the frame and pushes it to the rear middle of the frame, while in the upper frame position pulls air from the middle front of the frame and pushes it to the upper frame, mostly the rear.
- Ensure all power cables, cords, and traffic (signaling) cables can be safely routed and fastened. Refer to “Assess cable management” (page 35).
- If the optional extended cable management brackets were ordered, the position of the frame will need to accommodate the added width on one or both sides of the frame. Coordinate this with “Assess cable management” (page 35).

- If the optional side panel kit NTPX4050 was ordered, the footprint of the frame will be slightly wider as described in “Front and rear access to switch hardware” (page 72) and included in the procedure “Marking the footprint and the anchor holes on the floor” (page 112).
- If the optional door kit NTQS37AA or NTQS37AB was ordered, you must accommodate that the footprint of the frame will be deeper and that you will need clearance for the door to swing open as described in “Front and rear access to switch hardware” (page 72) and included in the procedure “Marking the footprint and the anchor holes on the floor” (page 112).
- Consider whether a frame can be positioned next to the Passport 15000 or 20000 at initial installation or afterwards for adding sparing or fanout panels, or fiber management units (NTHW50) to support proper cable and fiber routing, and connection. Coordinate this with “Assess the locations of peripheral equipment” (page 76).
- Ensure the area in front of and behind the mounting apparatus has sufficient air flow to assist cooling the Passport 15000 or 20000.
- Ensure the area is free of excess heat, dust, smoke, and electrostatic discharge (ESD).
- Since a NEBS 2000 frame or an MFA150 framework with batteries has a small footprint relative to its mass and weight, plan to use anchors to secure the frame to the floor for either earthquake or non-earthquake applications.

Also consider the location of the Passport 15000 or 20000 relative to the location of the hardware that connects to it, namely the equipment identified in all other sections of this chapter.

Figure 4
Airflow directions of upper and lower cooling units in an NTRU04



Equipment size and weight

Before installing the NEBS 2000 frame with one or two Passport 15000 or 20000 switches, ensure that the room can accommodate the size, weight, and environmental (thermal and humidity) requirements of the equipment.

Dimensions without packaging material

Determine whether the dimensions of the frame can fit through the site up to the footprint where the frame is to be anchored. A Network Building Equipment System (NEBS) frame is 60 cm (23.62 inches) wide by 60 cm (23.62 inches) deep by 212.5 cm (83.66 inches) tall.

For the frame footprint, the width is increased by an additional 75 mm (2.95 in.) on each side when the optional extended brackets for cable management (part number P0902826) are installed. It is also recommended that you allow 1 cm between the outermost reach of the extended brackets so that cables can be passed between the brackets and whatever equipment is beside them. These additional dimensions are addressed in “Marking the footprint and the anchor holes on the floor” (page 112).

Weights with one or two switches

This section provides information to help you calculate the weight of a populated Passport 15000 or 20000 frame. Knowing the weight enables you to determine the following:

- which tool you need to safely move the frame
- whether the floor, especially a raised floor, can safely support the weight of all the installed equipment

The weight of an anchored NEBS 2000 frame containing one or two provisioned switches varies according to

- the type and number of all plug-in cards and modules
- all of the standard and optional add-on parts
- the type and lengths of cables that are supported by the frame within the NEBS footprint

Calculate the installed weight of your switch hardware by doing the following.

- 1 Use one of the following tables to determine the pre-installed base weight.
 - “Base weight of a frame shipped with one Passport 15000 switch (shelf)” (page 60)
 - “Base weight of a frame shipped with two Passport 15000 switches (shelves)” (page 61)
 - “Base weight of a frame shipped with one Passport 20000 switch (shelf)” (page 62)
 - “Base weight of a frame shipped with two Passport 20000 switches (shelves)” (page 63)
 - “Weights of a frame with a Passport 15000-VSS” (page 68)
 - “Weights of a frame with a Passport 15000 and a Shasta 5000” (page 68)
 - “Weight of Passport 15000 shelf-based parts that are installed in a 23-inch EIA rack” (page 69)
 - “Weight of Passport 20000 shelf-based parts that are installed in a 23-inch EIA rack” (page 70)
 - “Optional and to-be-determined weights for a Passport 15000 or 20000 in a 23-inch EIA rack” (page 71)

- 2 Use the table “Weight of optional or additional Passport 15000 or 20000 parts” (page 65) to add to the base weight all the hardware parts that are to be installed after anchoring.

Note: The plug-in cards that are listed in this table (CPs, FPs, and blanks) are already included as a average total card weight in the tables “Base weight of a frame shipped with one Passport 20000 switch (shelf)” (page 62) and “Base weight of a frame shipped with two Passport 20000 switches (shelves)” (page 63). A Passport 20000 is shipped with all plug-in cards partially installed.

Considerations about the weight of the system are described in “Checking the floor” (page 104).

Table 8
Base weight of a frame shipped with one Passport 15000 switch (shelf)

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
frame, NEBS 2000, 600 mm x 600 mm (also known as a PTE 2000)	NTRU04	1	181.4 (400)
breaker interface panel (BIP) with 2 BIMs	NT6C62	1	11.7 (25.8)
cabling strain relief bar (back of BIP)	P0911981	1	0.9 (2.0)
shelf (lower) assembly with:	NTHR50 or NTHW99	1	99.0 (218)
alarm/BITS module	NTHR12, 13, or 14	1	
MAC address module	NTHR11	1	
PIMs	NTHR15	4	
cables:			
BIP alarm cable assembly (lower shelf)	NTHR56	1	0.3 (0.65)
Cooling unit alarm cable (upper or lower shelf)	NTHR57	1	0.3 (0.66)
power distribution cable (for lower shelf)	NTHR54	1	1.9 (4.2)
power distribution cable (upper or lower cooling unit)	NTHR66	1	0.2 (0.4)
top frame cover kit front or rear	NTRU0185	1 kit	2.3 (5.0)
cable cover kit (2 covers) front or rear	NTRU0120	1 kit	5.3 (11.6)
cooling unit (lower)	NTHR51AA or NTHR51AB	1	9.1 (20)
cable management brackets, metal	P0879577	2	0.91 (2.0)
cable management brackets, moulded plastic	P0937935	28	0.98 (2.16)
anchor kit for frame (2 anchors per kit)	NTRU0327	3 kits	16.5 (36.4)
TOTAL WEIGHT	n/a	n/a	331.8 (728.9)

Table 9
Base weight of a frame shipped with two Passport 15000 switches (shelves)

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
frame, NEBS 2000, 600 mm x 600 mm (also known as a PTE 2000)	NTRU04	1	181.4 (400)
breaker interface panel (BIP) with 4 BIMs	NT6C61	1	15.7 (34.6)
cabling strain relief bar (back of BIP)	P0911981	1	0.9 (2.0)
shelf assemblies (upper and lower) with:	NTPN70	2	231.8 (510)
alarm/BITS module	NTHR12, 13, or 14	2	
MAC address module	NTHR11	2	
PIMs	NTHR15	8	
Cables:			
cooling unit alarm cable (upper or lower shelf)	NTHR57	2	0.3 (0.66)
BIP alarm cable assembly (lower shelf)	NTHR56	1	0.3 (0.65)
BIP alarm cable assembly (upper shelf)	NTHR55	1	0.23 (0.5)
power distribution cable (for lower shelf)	NTHR54	1	1.9 (4.2)
power distribution cable (for upper shelf)	NTHR53	1	1.1 (2.4)
power distribution cable (upper and lower cooling unit)	NTHR66	2	0.4 (0.8)
cooling unit (lower)	NTHR51AA or NTHR51AB	1	9.1 (20.0)
cooling unit (upper)	NTHR52AA or NTHR52AB	1	8.63 (19.0)
top frame cover kit front or rear	NTRU0185	1 kit	2.3 (5.0)
cable cover kit (2 covers)	NTRU0120	1 kit	5.3 (11.6)
cable management brackets, metal	P0879577	2	0.91 (2.0)
cable management brackets, moulded plastic	P0937935	28	0.98 (2.16)
anchor kit for frame (2 anchors per kit)	NTRU0327	3 kits	16.5 (36.4)
TOTAL WEIGHT	n/a	n/a	478.1 (1052.0)

Table 10
Base weight of a frame shipped with one Passport 20000 switch (shelf)

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
frame, NEBS 2000, 600 mm x 600 mm (also known as a PTE 2000)	NTRU04	1	181.4 (400)
breaker interface panel (BIP) with 2 BIMs	AP6C68	1	11.7 (25.8)
cabling strain relief bar (back of BIP)	P0911981	1	0.9 (2.0)
shelf (lower) assembly with:	NTPN70	1	33.6 (74.0)
alarm/BITS module	NTPN12 or 13	1	
MAC address module	NTPN11	1	
PIMs	NTPN15	4	
fabrics	NTPN02	2	10.9 (24.0)
control processor (CP) cards	NTHW06	2	10.0 (22.0)
see the weights of your selection of FP cards in the table "Weight of optional or additional Passport 15000 or 20000 parts" (page 65) for card-specific weights	various	1 to 14	x.x (y.y)
system cables:			
cooling unit alarm cable (upper or lower shelf)	NTHR57	1	0.3 (0.66)
BIP alarm cable assembly (lower shelf)	NTHR56	1	0.3 (0.65)
power distribution cable (for lower shelf)	NTHR54	1	1.9 (4.2)
power distribution cable (upper or lower cooling unit)	NTHR66	1	0.2 (0.4)
cooling unit (lower)	NTHR51AA or NTHR51AB	1	9.1 (20.0)
top frame cover kit front or rear	NTRU0185	1 kit	2.3 (5.0)
cable cover kit (2 covers)	NTRU0120	1 kit	5.3 (11.6)
cable management brackets, metal	P0879577	2	0.91 (2.0)
cable management brackets, moulded plastic	P0937935	28	0.98 (2.16)
anchor kit for frame (2 anchors per kit)	NTRU0327	3 kits	16.5 (36.4)
TOTAL WEIGHT	n/a	n/a	286.6 (630.9)

Table 11
Base weight of a frame shipped with two Passport 20000 switches (shelves)

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
frame, NEBS 2000, 600 mm x 600 mm (also known as a PTE 2000)	NTRU04	1	181.4 (400)
breaker interface panel (with 4 BIMs)	AP6C67	1	16.0 (35.4)
cabling strain relief bar (back of BIP)	P0911981	1	0.9 (2.0)
shelf assemblies (upper and lower) with:	NTPN70	2	67.2 (148.0)
Alarm/BITS module	NTPN12 or 13	2	
MAC address module	NTPN11	8	
PIMs	NTPN15		
fabrics	NTPN02	4	21.8 (48.0)
control processor (CP) cards	NTHW06	4	20.0 (44.0)
see the weights of your selection of FP cards in the table "Weight of optional or additional Passport 15000 or 20000 parts" (page 65) for card-specific weights	various	1 to 28	x.x (y.y)
cables:			
cooling unit alarm cable (upper or lower shelf)	NTHR57	2	0.3 (0.66)
BIP alarm cable assembly (lower shelf)	NTHR56	1	0.3 (0.65)
BIP alarm cable assembly (upper shelf)	NTHR55	1	0.23 (0.5)
power distribution cable (for lower shelf)	NTHR54	1	1.9 (4.2)
power distribution cable (for upper shelf)	NTHR53	1	1.1 (2.4)
power distribution cable (both cooling units)	NTHR66	2	0.4 (0.8)
cooling unit (lower)	NTHR51AA or NTHR51AB	1	9.1 (20.0)
cooling unit (upper)	NTHR52AA or NTHR52AB	1	8.63 (19.0)
top frame cover kit front or rear	NTRU0185	1 kit	2.3 (5.0)
cable cover kit (2 covers)	NTRU0120	1 kit	5.3 (11.6)
cable management brackets, metal	P0879577	2	0.91 (2.0)
(Sheet 1 of 2)			

Table 11 (continued)**Base weight of a frame shipped with two Passport 20000 switches (shelves)**

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
cable management brackets, moulded plastic	P0937935	28	0.98 (2.16)
anchor kit for frame (2 anchors per kit)	NTRU0327	3 kits	16.5 (36.4)
TOTAL WEIGHT	n/a	n/a	781.6 (356.8)
(Sheet 2 of 2)			

Table 12
Weight of optional or additional Passport 15000 or 20000 parts

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
adapter brackets for installing 19-inch wide EIA equipment into a NEBS 2000 frame	NTHW14	2	— (—)
cable management extension bracket (left or right) -- replace a P0879577 or P0937935	NTRU0368 NTRU0369	1	1.4 (3.0)
cable cover kit (front or rear kit used with cable management extension brackets)	NTRU0366	1	7.3 (16)
cables:			
power input cable (1/0 AWG)	customer-supplied	0.3 m (1 ft)	0.15 (0.32)*
mini-coax FP cable (upper shelf)		0.3 m (1 ft)	0.09 (0.19)*
fiber optic FP cable		0.3 m (1 ft)	0.025(0.06)*
FP control port cable (upper shelf)		1	0.1 (0.2)
FP control port cable (lower shelf)		1	0.16 (0.35)
CP Ethernet cable assembly kit	NT0479	1	0.43 (0.95)
E1 balanced to unbalanced BITS	NTPN81	1	0.3 (0.66)
conversion kit for an NTPN13			
Note: * multiply this weight with the number of meters (feet) of cable that fall within the perimeter of the Passport 15000 or 20000, is supported by the NEBS 2000 frame, and the quantity of cables.			
conduit junction box, overhead	NTHR78	1	1.4 (3.0)
door-mounting hardware: cosmetic extension filler door door catches and hinges extension brackets, lower left and right kickplate extension top brandline cover, plain or illuminated top extension bracket	NTQS37AA or NTQS37AB	1	25.4 (56.0)
ETSI power-and-ground assembly kit	A0834149	1	3.1 (6.85)
fiber management unit, dual-drawer	NTHW50	1	8.25 (18.2)
frame (cabinet) joining kit	NTRU0101	1	0.5 (1.0)
multiport aggregate device	NT0421 or NT0486	1	2.0 (4.4)
(Sheet 1 of 3)			

Table 12 (continued)
Weight of optional or additional Passport 15000 or 20000 parts

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
polyvalent power-and-ground assembly kit	A0834143	1	2.1 (4.65)
side panel, extended	NTPX4050	1	18.1 (40.0)
side panel, regular	NTRU0128	1	12.27 (27.0)
temperature sensor bracket assembly for an NTHR52AA	NTHR68AA	1	0.459 (1.01)
temperature sensor bracket assembly for an NTHR52AB	NTHR68AB	1	0.459 (1.01)
processor cards:			
2pGpDsk	NTHW10	1	4.90 (10.8)
4pGe	NTHW49	1	5.6 (12.5) *
CP2	any	1	5.5 (12.0) !
CP3	NTHW06CA	1	4.99 (11.0)
2pDS3cTDM	NTHW91	1	4.5 (10.7)
4pDS3ChAtm	NTHR31	1	5.22 (11.5)
4pDS3ChAtm	NTHR91	1	5.22 (11.5)
12pDS3Atm	NTHR23	1	5.45 (12.0)
32pE1TDM	NTHW92	1	4.9 (10.8)
E3	any	1	5.5 (12.0) !
4pOC3MmAtm	NTHR17	1	5.63 (12.4)
4pOC3SmlrAtm	NTHR21	1	5.58 (12.3)
4pOC3TDM	NTHW70	1	6.1 (13.4)
16pOC3SmlrAtm	NTHW21	1	5.90 (13.0)
16pOC3SmlrAtm	NTHW31	1	5.5 (12.0) !
16pOC3PosAtm	NTHW44	1	5.9 (13.0) *
1pOC12SmLrAtm	NTHR29	1	5.45 (12.0)
4pOC12SmlrAtm	NTHW11	1	5.63 (12.4)
1pOC48ChSmlrAtm	NTHW01	1	5.49 (12.1)
STM-1	any	1	5.5 (12.0) !
STM-4	any	1	5.5 (12.0) !
VpnXc	any	1	5.5 (12.0) !
Vsp2 (VSP2)	NTHW87	1	5.3 (11.6)
2pGeMmSrVsp3 (VSP3)	NTHW84	1	6.1 (13.4)
2pOC3ChSmlrVsp3 (VSP3-o)	NTHW77	1	6.94 (15.3)
Blank processor card (aka filler module)	NTHR64	1	2.22 (4.9)
(Sheet 2 of 3)			

Table 12 (continued)
Weight of optional or additional Passport 15000 or 20000 parts

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
Note: Weights with ! are estimated. Weights with * include all SFPs (NTPP0x).			
fabrics, Passport 15000	NTHR16	2	13.6 (30.0)
fanout panel, DS3 or E3, 12-port	NTHW52	1	1.0 (2.2)
sparing panel assembly for DS3 or E3, 3-port	NTFP99AA	1	___(___)
sparing panel assembly for DS3, 4-port	NTHR79	1	___(___)
sparing panel assembly for DS3 or E3, including:	NTQS31	1	11.0 (24.3)
sparing panel module	NTHR37	1	
sparing panel relay module	NTHR39	12	
sparing panel control module	NTHR42	1	
frame spacer kit	NTRU0365	1	2.5 (5.5)
spaced frame junction kit	NTRU0370	1	1.1 (2.5)
top cover (panel) kit	NTRU0185	1	2.3 (5.0)
top cover (panel) kit, brandlining	NTHW51	1	2.3 (5.0)
shelf filler panels			
front of frame, 1000 mm (3.3 ft)	NTHR76	1	6.8 (15)
rear of frame, 800 mm (2.6 ft)	NTHR77	1	6.8 (15)
side panel kit (includes 2 panels)	NTRU0128	1 kit	12.9 (28.4)
BIM fillers for the BIP	P0887704	2	0.2 (0.44)
(Sheet 3 of 3)			

Table 13
Weights of a frame with a Passport 15000-VSS

Number of shelves	Status of shelf	Weight	Hardware included with the weight
two	shipped in a frame	395 kg (562 lbs)	a NEBS 2000 frame, a BIP with 2 BIMs, one Passport 15000 shelf (2 cages) and all rear shelf plug-in modules and no cards or fabrics, one Passport 7400 shelf with cooling unit and filter
two	installed completely	588 kg (982 lbs)	the same hardware as shipped in a frame plus 3 Passport 7400 power supplies, and CP and FP modules, and the CP, FP, and fabric cards for the Passport 15000

Table 14
Weights of a frame with a Passport 15000 and a Shasta 5000

Number of shelves	Status of shelf	Weight	Hardware included with the weight
two	shipped in a frame	383 kg (535 lbs)	a NEBS 2000 frame, a BIP with 2 BIMs, one Passport 15000 shelf (2 cages) with rear plug-in modules and no front cards or fabrics, one Shasta 5000 shelf
two	installed completely	569 kg (940 lbs)	the same as shipped in a frame plus all the Shasta 5000 line cards and the CP, FP and fabric cards for the Passport 15000

Table 15
Weight of Passport 15000 shelf-based parts that are installed in a 23-inch EIA rack

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
adapter brackets (front) for installing switch hardware into a 23-inch EIA rack	P0918821 P0918822	2	10.2 (22.4)
adapter brackets (rear) for installing switch hardware into a 23-inch EIA rack	P0918823 P0918824	8	1.6 (3.52)
breaker interface panel (BIP) with 2 BIMs	NT6C62	1	11.7 (25.8)
cabling strain relief bar (back of BIP)	P0911981	1	0.9 (2.0)
shelf (lower) assembly with:	NTHR50 or NTHW99	1	99.0 (218)
Alarm/BITS module	NTHR12, 13, or 14	1	
MAC address module	NTHR11	1	
PIMs	NTHR15	4	
fabrics	NTHR16	2	13.6 (30.0)
cables			
BIP alarm cable assembly (lower shelf)	NTHR56	1	0.3 (0.65)
Cooling unit alarm cable (upper or lower shelf)	NTHR57	1	0.3 (0.66)
Power distribution cable (upper or lower cooling unit)	NTHR66	1	0.2 (0.4)
cooling unit (upper)	NTHR52AA or NTHR52AB	1	8.63 (19.0)
cable management brackets, metal	P0879577	2	0.91 (2.0)
cable management brackets, moulded plastic	P0937935	28	0.98 (2.16)
TOTAL WEIGHT	n/a	n/a	148.32 (326.59)

Table 16
Weight of Passport 20000 shelf-based parts that are installed in a 23-inch EIA rack

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
adapter brackets (front) for installing switch hardware into a 23-inch EIA rack	P0918821 P0918822	2	10.2 (22.4)
adapter brackets (rear) for installing switch hardware into a 23-inch EIA rack	P0918823 P0918824	8	1.6 (3.52)
breaker interface panel (BIP) with 2 BIMs	AP6C68	1	11.7 (25.8)
cabling strain relief bar (back of BIP)	P0911981	1	0.9 (2.0)
shelf (lower) assembly with:	NTPN70	1	33.6 (74.0)
Alarm/BITS module	NTPN12 or 13	1	
MAC address module	NTPN11	1	
PIMs	NTPN15	4	
fabrics	NTPN02	2	10.9 (24.0)
cables			
BIP alarm cable assembly (lower shelf)	NTHR56	1	0.3 (0.65)
Cooling unit alarm cable (upper or lower shelf)	NTHR57	1	0.3 (0.66)
Power distribution cable (upper or lower cooling unit)	NTHR66	1	0.2 (0.4)
cooling unit (upper)	NTHR52AA or NTHR52AB	1	8.63 (19.0)
cable management brackets, metal	P0879577	2	0.91 (2.0)
cable management brackets, moulded plastic	P0937935	28	0.98 (2.16)
TOTAL WEIGHT	n/a	n/a	80.22 (176.59)

Table 17
Optional and to-be-determined weights for a Passport 15000 or 20000 in a 23-inch EIA rack

Name of the hardware part	PEC or part number	Quantity	Weight kg (lbs)
23-inch wide EIA rack or equivalent	see manufacturer's	1	x.x (y.y)
polyvalent power-and-ground assembly kit	A0834143	1	2.1 (4.65)
temperature sensor bracket assembly for an NTHR52AA	NTHR68AA	1	0.459 (1.01)
temperature sensor bracket assembly for an NTHR52AB	NTHR68AB	1	0.459 (1.01)
see the weights of your selection of CP and FP cards in the table "Weight of optional or additional Passport 15000 or 20000 parts" (page 65) for card-specific weights	various	1 to 14	x.x (y.y)
Cables			
power input cable (1/0 AWG)	customer-supplied	0.3 m (1 ft)	0.15
mini-coax FP cable (upper shelf)		0.3 m (1 ft)	(0.32)*
fiber optic FP cable		0.3 m (1 ft)	0.09
FP control port cable (upper shelf)		1	(0.19)*
FP control port cable (lower shelf)		1	0.025
CP Ethernet cable assembly kit	NT0479	1	(0.06)*
E1 balanced to unbalanced BITS conversion kit for an NTPN13	NTPN81	1	0.1 (0.2) 0.16 (0.35) 0.43 (0.95) 0.3 (0.66)
Note: * multiply this weight with the number of meters (feet) of cable that fall within the perimeter of the Passport 15000 or 20000, is supported by the NEBS 2000 frame, and the quantity of cables.			
ETSI power-and-ground assembly kit	A0834149	1	3.1 (6.85)
Anchor kit for rack	see manufacturer's	2 or 4	x.x (y.y)

Front and rear access to switch hardware


It is important to be able to have comfortable access to the Passport 15000 or 20000 switch hardware to perform maintenance. The sizes of the plug-in cards and modules require minimum distances for you to be able to safely remove and insert them for a maintenance or an upgrade task. Both front access and rear access must be planned using these guidelines:

- the maintenance aisle, in front of the mounting apparatus, requires a clearance of 76.2 cm (30 in.)
- the wiring aisle, at the rear of the mounting apparatus, requires a clearance of 61 cm (24 in.)
- when adding a door to the front or rear of a NEBS 2000 frame, you need clearance to swing the door open as shown in the figure “Clearance to swing a door open on a NEBS 2000 frame” (page 73)

Note: If clearance is not available, for example, the frame is already installed, an unlocked door can easily be removed to enable access to switch hardware inside the frame.

For more information about general equipment requirements, see the Telcordia NEBS, General Equipment Requirements, GR-63-CORE.

Figure 5
Clearance to swing a door open on a NEBS 2000 frame



Assess the location of a system of ac rectifiers

A Passport 15000 or 20000 switch can be powered from a system of ac rectifiers, such as an Astec MFA150 power system. Because the ac rectifiers supply dc power directly to the breaker interface panel (BIP) of the switch, consider the following:

- where the rectifiers tap into the ac power input source of the site
- whether the MFA150 framework is to be installed in the same room as the switch

Note: While a switch is mounted in a NEBS 2000 frame, an MFA150 power system is mounted in a framework. The frame and framework are structurally different but provide the same functionality.

- how far the dc power output cables must be run from the rectifiers to the switch so that 40 to 100 A redundant service can be supplied
- whether the power input cables to the BIP are to run from an overhead trough, through conduit imbedded in a solid floor, or under a raised floor (described in “Assess power cable location” (page 54))
- whether cables for external alarms are to run to the BIP so that a rectifier failure or tripped breaker can be indicated at the BIP
- whether the distance between the BIP and its MFA150 system of rectifiers is less than 10 m (32.8 ft) to accommodate the path of the external alarm cable assembly P0940531; this external alarm cable enables a rectifier failure or tripped breaker to be indicated at the BIP and reported to the Preside Multiservice Data Manager software
- if anchoring the framework beside a NEBS 2000 frame:
 - whether there is enough room for both footprints; a framework is 64.5 cm (25.4 inches) wide by 50.8 cm (20-inches) deep, but the dimensions are subject to change without notice
 - whether the NEBS 2000 frame might receive the optional cable extension brackets or side panels after initial installation
 - whether the power input and output cables on the sides of the MFA150 framework would interfere with signals passing through coax cables on the side of the NEBS 2000 frame (for example, DS3

or E3 mini-coax cables routed along the right side or standard coax connecting a fanout or sparing panel)

- whether the floor can support the installed weight of the framework setup, especially when involving a raised floor
- whether there is any other site-specific consideration for installing an MFA150 framework setup that could also affect the installation of the switch

An MFA150 system can be anchored beside a Passport 15000 or 20000 without interfering with its telecommunications performance.



CAUTION

Risk of service interruption

An MFA150 power system of ac rectifiers is rated as class A equipment, therefore it requires an appropriately controlled environment for your site setup.

For powering one Passport 15000 or 20000 shelf, the Astec identifier AP5C900FF has two 60-A mid-trip circuit breakers and three Helios rectifiers 25/48 with power factor correction (PFC). For powering two Passport 15000 or 20000 shelves, the Astec identifier AP5C900FG has four 60-A mid-trip circuit breakers and five Helios rectifiers 25/48 with power factor correction (PFC). Both kits exclude the recommended No. 6 AWG (13.3mm²) 2-wire armored cable for ac power (R0061445). These hardware configurations are subject to change, therefore consult with your sales representatives of Nortel Networks and Astec to determine the most appropriate setup for your Passport switch and installation site.

For the details of these considerations and the installation of an MFA150, see the Astec document 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.

Throughout the Passport 15000 and 20000 documents, MFA150 information has been integrated where necessary. The intent is to coordinate the overall installation of an MFA150 framework with a Passport that is installed in a NEBS 2000 frame.



CAUTION

Risk of service interruption or delay

An MFA150 power system of ac rectifiers is manufactured by a third party, which means hardware specifications can change without notice. Nortel Networks attempts to integrate the changes that impact the rectifiers, but is not responsible when changes are communicated after this document is published.

Assess the locations of peripheral equipment

The peripheral equipment of a Passport 15000 or 20000 includes anything that connects to it and is not integrally part of the switch hardware. Since peripheral equipment is optional, assessing each location depends on which of the following you intend to deploy:

- “Choosing the user interface equipment” (page 76)
- “Choosing the network management computer for a Passport 15000 or 20000” (page 77)
- “Deciding where to place local user interface equipment” (page 78)
- “Deciding where to place a sparing or a fanout panel” (page 78)
- “Deciding where to place interworking equipment” (page 80)
- “Deciding which external BIP alarms to connect” (page 82)
- “Using a connection to a gigabit Ethernet port on NTHW84” (page 83)
- “Placing a fiber management unit for cable slack” (page 45)

Choosing the user interface equipment

The user interface equipment is typically a terminal (computer with a monitor) that is connected to the Passport 15000 or 20000 switch. The user interface equipment enables a software operator to:

- start initial software loading
- configure the software setup of the switch
- monitor the status and performance operation of the switch

- change the status of software components and hardware parts to prepare the switch system for maintenance or upgrades

Only one user interface terminal connects to a Passport 15000 or 20000 switch. The connection is by an RS232 cable with a V.24 DCE connector on the faceplate of the control processor (CP) in the switch and a 9-pin D-sub connector at the VT100 terminal. This connection is typically not left in place after the hardware and software installations are complete. Details of installing and connecting an operator terminal are described in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

Note: The user interface terminal is not the equipment used for Preside Multiservice Data Manager which communicates with the Passport 15000 or 20000 as a node in the network. For information about Preside Multiservice Data Manager connectivity, see “Choosing the network management computer for a Passport 15000 or 20000” (page 77).

Choose the user interface equipment before deciding where it is to be placed. The type of user interface equipment that will operate with the switch is a VT100 terminal or device that emulates a VT100 terminal. The specifications of the terminal are the standard VT100 specifications.

Once the VT100 has been chosen, do “Deciding where to place local user interface equipment” (page 78).

Choosing the network management computer for a Passport 15000 or 20000

The network management equipment is typically a terminal (computer with a monitor) that is connected to the Passport 15000 or 20000 switch. The network management equipment runs the Preside Multiservice Data Manager software or equivalent software. The Preside Multiservice Data Manager host enables a software network operator to monitor and control a Passport 15000 or 20000 as a node in a network of switches. Choose network management equipment that is provisioned with a hard disk that is sufficiently sized to accommodate software loads, accounting records, and other mass storage requirements used by the processor. The sizes of each node software load or

Preside Multiservice Data Manager load are different. The installation of a Preside Multiservice Data Manager terminal is described in 241-6001-100 *Preside MDM Installer Guide*.

Note: The Preside Multiservice Data Manager terminal is not the equipment used for the local user interface which is necessary to initially start up and configure a Passport 15000 or 20000. For information about the user interface, see “Choosing the user interface equipment” (page 76).

Deciding where to place local user interface equipment

Before deciding where to place local user interface equipment, ensure the type of terminal is chosen so that size, weight, and other limitations can be considered. See “Choosing the user interface equipment” (page 76). Decide where to place the terminal relative to the where the Passport 15000 or 20000 is to be positioned. The terminal must be co-located at the same site as the Passport 15000 or 20000. Include the following criteria:

- a terminal (computer and monitor) and whatever requirements the manufacturer specifies (for example, a 15 A 3-prong ac outlet for the power cords of the computer and the monitor)
- a shelf, rack, or desk large enough and strong enough to house the terminal
- an area for the shelf, rack, or desk to reside in while at a distance of several meters away from the Passport 15000 or 20000

The installation of the operator terminal is in described in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*, the chapter on connecting an operator terminal.

Deciding where to place a sparing or a fanout panel

A sparing panel or a fanout panel should be mounted as close to the Passport 15000 or 20000 switch as possible to minimize the length of cable connecting them together. One NTQS31 sparing panel can be mounted in a NEBS 2000 frame with one shelf, or up to 4 panels in a NEBS 2000 frame with no shelf. With other types of sparing panels, for example, the 4-port DS3 NTHR79 or the 2-port DS3 NTFP99, one to three panels can also occupy a frame that has a shelf in it. Each NTHR79 or NTFP99 panel is 2Us high.

The fanout or sparing panels can also be installed in a mounting apparatus other than the NEBS 2000 frame (NTRU04). Since most of the sparing panels that are used with a Passport 15000 or 20000 are 19 inches wide, they can be mounted on a 19-inch wide apparatus, or on the 21-inch wide NTRU04 using the EIA-to-NEBS adapter brackets in the kit NTHW21. Panel dimensions are identified in 241-1501-200 *Passport 15000, 20000 Hardware Description*, the chapter on termination panels.

The sparing or fanout panels connecting to a Passport 15000-VSS must be located in a different mounting apparatus. There is no room in the frame to accommodate the sparing or fanout panels.

The sparing or fanout panel connecting to a Passport 15000 interworking with a Shasta 5000 in the same frame must be located in different mounting apparatus. There is no room in the frame to accommodate the sparing or fanout panels.

Cabling considerations for a termination panel

Nortel Networks makes prefabricated cable assemblies of various lengths available for the DS3 function processor (FP) cards. Typical cable lengths are 2.5 m (8 ft), 5 m (16 ft), or 15 m (49 ft). An FP an with 8W8 connector on the faceplate requires a proprietary cable assembly that cannot be custom made. The prefabricated cable assemblies that are offered for each FP and the specifications to custom make your own lengths are described in 241-1501-200 *Passport 15000, 20000 Hardware Description*, the chapter on processor cards.

A frame with two fully provisioned shelves can have up to 700 mini-coax cables or 284 fiber optical cables, or a combination of both connected to the front of the Passport 15000 or 20000 shelf. Since cable slack for all coax signaling cables cannot occur at the shelf, the location of the electrical function processor (FP) cards relative to the location of the sparing or fanout termination panel directly affects how long each cable will be.

Consider where the sparing or fanout panel will be located relative to:

- how many and how far the cables must be routed from the FP in a slot to the termination panel

- how many and how far the cables must be routed from the far-end of the FP connection to the termination panel
- where and how the cable slack is to be managed along the connection path
- whether the density of cables will obstruct any of the airflows that keep the entire system operating at an optimum temperature

Ensure that you address all of the cable planning criteria in “Assess cable management” (page 35).

Deciding where to place interworking equipment

When the Passport 15000 or 20000 will be interworking with equipment, such as an EdgeLink 100, determine from the manufacturer of the equipment

- what the dimensions and weight are
- what the maximum length that the interface cables can be
- what the power requirements are
- which external alarms on the equipment, if any, or on the Passport 15000 or 20000 switch can be connected; for the switch, see “Deciding which external BIP alarms to connect” (page 82)

Decide where to put the interworking equipment within reach of the switch, and within reach of the power source. Decide the same criteria when the interworking equipment connects to Preside Multiservice Data Manager instead of the switch.

When the interworking equipment is an EdgeLink, refer to the installation considerations in “Interworking with an EdgeLink 100” (page 80).

When the interworking equipment is a Shasta 5000, refer to the installation considerations in “Interworking with a Shasta 5000” (page 82).

Interworking with an EdgeLink 100

An EdgeLink 100 is an electrical multiplexer (mux) for DS1 and DS3 (T1 and T3) interfaces. It multiplexes DS1 channels into a single DS3 B3ZS data channel, and de-multiplexes the DS3 B3ZS signal into its DS1 parts. It can

transmit and receive DS1 signals over an electrical DS3 interface. It also has an Ethernet port, which could be used to link to Preside Multiservice Data Manager.

Since the hardware of an EdgeLink is manufactured by Telco Systems, it is subject to change without notice. Confirm the installation criteria in Telco Systems documentation, starting with *EdgeLink 100 Digital Multiplexer General Description*, section 825-102-001.

An EdgeLink 100 is powered by -48 V dc, but it does not need to share the same power-and-ground sources as the Passport 15000 or 20000.

The mounting of an EdgeLink 100 in a NEBS 2000 frame, grounding it, and connecting power to it is described in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*, the chapter on installing interface equipment.

External alarm connections between the EdgeLink and the Passport 15000 or 20000 are not supported.

The line impedance of the interface cables is 75 ohms unbalanced for DS3 and 100 ohms nominal balanced for DS1.

The lengths of the prefabricated interface cables are in the table “Cable lengths between an EdgeLink 100 and a Passport 15000 or 20000” (page 81). For other lengths, contact your local Nortel Networks sales representative.

Table 18
Cable lengths between an EdgeLink 100 and a Passport 15000 or 20000

Type	Part numbers	Maximum length
DS1	Telco Systems' AWX436G or AWX438G	131 m (432 ft) up to an FP
DS3	custom-made coax cable	137 m (450 ft) up to an FP
Ethernet	Telco Systems' AWX454G10	3 m (10 ft) up to an Ethernet hub linked to Preside Multiservice Data Manager

The installation of the EdgeLink 100 interface cables is described in *241-1501-240 Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*, the chapter on installing system cables.

Interworking with a Shasta 5000

A Shasta 5000 is an enterprise switch that can be mounted in a NEBS 2000 frame with a Passport 15000 to enable interworking, for example, with IP over VPN. The installation requires the hardware provided in kit NTHW85.

Since the hardware of a Shasta 5000 is subject to change without notice, confirm the installation criteria in its documentation.

A Shasta 5000 is powered by -48 V dc, but it does not need to share the same power source as the Passport 15000. The grounding to the site ground window is shared through the NEBS 2000 frame.

Shared external alarm connections between the Shasta 5000 and the Passport 15000 are not supported.

The interface cable between the Shasta 5000 and the Passport 15000 is a multi-mode fiber optic cable with flat SC connectors.

The installation of the ground cable and the interface cable are described in *241-1501-240 Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

Deciding which external BIP alarms to connect

The breaker interface panel (BIP) can be connected to external alarms such as an end-of-aisle lamp, a LED, or an audible alarm. Since the alarm terminals are customer premises equipment (CPE), you must decide which alarms are to be connected to the Passport 15000 or 20000. For the complete list of available BIP external alarm connections and the types of alarms they provide, refer to *241-1501-200 Passport 15000, 20000 Hardware Description*.

The choices of alarms from an Astec MFA150 power system of ac rectifiers that can be connected to the Passport 15000 or 20000 are described in the Astec document 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.

The recommended pin-to-pin connections of each alarm cable between the MFA150 and the BIP are described in 241-1501-200 *Passport 15000, 20000 Hardware Description*.

Using a connection to a gigabit Ethernet port on NTHW84

When using the voice services processor 3 (VSP3) card with PEC NTHW84, you can either use the virtual ports of the card or use the two gigabit Ethernet ports on its faceplate. There is no cable connection to enable using the virtual ports. Using the gigabit ports requires two cable connections from an Ethernet source with 1000Base-SX transmission capability. A 1000Base-SX has a short transmission wavelength of 770860 nm.

The Ethernet source must be an Internet Protocol (IP) local area network (LAN), preferably through a router that is capable of bridging and has VRRP (or an equivalent protocol).

The maximum distance between the router (or equivalent Ethernet source) and the VSP3 faceplate depends on the diameter of the multimode fiber cable core that you will use. With 50-micron cores, the maximum distance is 550 m (1,804.55 ft.). With 62.5-micron cores, the distance is 275 m (902.28 ft.).

Card functionality and fiber cable specifications are identified in the cable assembly section of the card description in 241-1501-200 *Passport 15000, 20000 Hardware Description*.

Assess spare parts storage and selection

Assess which spare parts of various equipment you plan to have available for replacements. Having a spare maximizes your ability to maintain a Passport 15000 or 20000. To have a spare available for the quickest use, you must provide a means of storage for the items.

Spare processor cards

When you have spare processor cards that have already been checked as operational and are compatible or equivalent spare cards to the versions of cards you have, replacing a failed card is quicker.

Spare processor cards should be stored in the same room as the Passport 15000 or 20000 switches so that the influence of imbalanced humidity is minimized. Otherwise you must wait an hour to acclimatize a card before inserting it into a slot.

Spare cooling units or cooling unit parts

When you have a spare cooling unit available as a replacement, you can:

- very safely and very quickly replace the cooling unit faster than you can replace some of its components (for example, a temperature sensor inside a lower cooling unit)
- minimize the impact of a failed component on overall cooling and reduce the amount of time the remaining fans operate at the higher rpm speed
- change the failed component on the removed cooling unit without jeopardizing safety or the time-sensitive removal of a failed component on a live cooling unit

Since there are two versions available for the lower (rear) cooling units, and two for the upper, you must ensure that your spare parts match the cooling unit they fit. The parts of the lower (rear) cooling unit NTHR51AA are not interchangeable with the parts of NTHR51AB. The parts of the upper (front) cooling unit NTHR52AA are not interchangeable with the parts of NTHR52AB. The parts of the temperature sensor bracket assembly NTHR68AA and not interchangeable with NTHR68AB, except a sensor from an AA can be used on an AB.

You can replace an entire cooling unit with either version. The performance of the versions is the same.

You can replace a temperature sensor bracket assembly with either version. The performance of the versions is the same.

For spare air filters, see “Assess air filter maintenance” (page 33).

Kits of spare parts for a Passport 15000 or 20000

Hardware kits are available to provide sets of spare parts for a Passport 15000 or 20000. For a Passport 15000, the kits are:

- NTQS29AA
- NTQS29AB

For a Passport 20000, the kits are:

- NTQH29AA
- NTQH29AB
- NTQH29AC
- NTQH29AD

The parts of each kit are listed in the chapter on field replaceable units (FRUs) in 241-1501-200 *Passport 15000, 20000 Hardware Description*.

Assess timing requirements

Timing and synchronization are necessary to ensure that any network element that derives timing from the Passport 15000 or 20000 ports is part of the synchronization hierarchy. This is especially important for any circuit emulation applications and SONET-based networks that derive their timing information from a high quality network clock.

A Passport 15000 or 20000 can receive a clock signal from:

- a non-traffic carrying link to the building (BITS)
- a traffic-carrying signal originating from another node that supports line timing
- the free-running internal oscillator (stratum 3) of a CP card

Note: Use only one type of timing mode, that is, BITS or line timing, not a combination. Mixing timing modes can interfere with sustaining timing while a module that is directly associated with timing undergoes a maintenance activity.

If the timing source of your site is BITS, you must provide and install whatever timing cables are needed to connect the site source to the alarm/BITS module itself on the Passport 15000 or 20000, or to a cable assembly that is connected to the alarm/BITS module.

For information on installing or replacing the timing cables, refer to 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*.

Plan for the use of an equivalent mounting apparatus

The Passport 15000 or 20000 shelf and the NEBS 2000 frame comply to applicable sections of the Network Equipment Building System (NEBS) standard. When the Passport 15000 or 20000 shelf is installed in a mounting apparatus other than the NEBS 2000 frame, additional frame level testing may be required to ensure compliance.

NEBS compliance of the shelf and frame combination is your responsibility. Nortel Networks may not offer the Passport 15000 or 20000 shelf in the frame or cabinet you have selected.

When installing a Passport 15000 or 20000 into a mounting apparatus other than the NEBS 2000 frame, the hardware is provided in a shelf kit.

The shelf kit, designed to fit a Passport 15000 or 20000 into a 23-inch EIA rack, complies with Seismic Zone 2 requirements when installed in the bottom of the frame. The preferred installation is into a rack with no doors, however, installation is possible in a cabinet with solid or perforated doors.

See 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade* for installation information.

In preparation for using an equivalent mounting apparatus, consider the following.

- “Dimensions and weight rating for the alternate rack” (page 88)
- “Rack and cabinet specifications” (page 88)
- “Electromagnetic compatibilities for an alternative mounting apparatus” (page 91)
- “Cooling considerations” (page 91)
- “Preparing your site’s source of power” (page 93)
- “Grounding the switch hardware” (page 93)
- “Assess the location of a Passport 15000 or 20000” (page 55)

Dimensions and weight rating for the alternate rack

Ensure that:

- the width and height of a Passport 15000 or 20000 fit your rack.
- your rack is rated for the weight of your hardware configuration
- your floor is rated for the combined weight of the Passport 15000 or 20000, the rack, and any other equipment you plan to mount on the rack

Passport 15000 or 20000 hardware has a width of 21 inches (53.34 cm) and a mounted height of 43.63 inches (110.8 cm). Switch hardware package NTQS04 or NTQH04 provides adapter brackets to accommodate a 23-inch (58.4-cm) wide EIA rack.

The weight of an installed Passport 15000 or 20000 switch varies according to the number and type of plug-in cards, add-on hardware, or tie-wrapped cables that are installed into the shelf or onto the rack. Excluding the rack, a fully provisioned switch weighs up to 627 lbs (285 kg) after the installation is complete. To calculate the weight of your configuration, see “Equipment size and weight” (page 58).

Floor strength and anchors for the frame, in a seismic application, must be in accordance with the frame manufacturer’s recommendations for the seismic zone of the installation. For additional information, see Telcordia GR-63-CORE, Issue 2, April 2002, section 4.4.2 for Earthquake Environment Criteria and section 4.4.3 for Framework and Anchor Criteria.

Rack and cabinet specifications

The shelf kit for the Passport 15000 and 20000 is comprised of a BIP, shelf, and upper cooling unit. The shelf is installed above the cooling unit and below the BIP. All parts must be installed in the bottom of the rack or cabinet. See the figure, “A shelf assembly in a rack, isometric front view” (page 90).

The shelf kit requires a total of 1100 mm (43 in.) of vertical space and 575 mm (23 in.) of space front-to-back in the rack.


To mount the Passport 15000 or 20000 shelf into a rack without using the adapter brackets provided in the kit, the rack must meet the following criteria:

- The mounting holes must be at 25 mm (1.0 in.) vertical increments starting 12.5 mm (0.5 in.) from the bottom.
- The horizontal spacing between mounting holes must be 515 mm (20.3 in.).
- A horizontal width of 535 mm (21.0 in.) across mounting flanges.

The mounting adapter brackets have hole spacing that is compliant to the 23-inch EIA standard.

A shelf installed in a cabinet with solid or perforated doors and side panels may generate acoustic noise greater than 60 dBA. For information about Passport 15000 and 20000 acoustic noise compliance see, “Acoustic noise compliance” (page 163).

Figure 6
A shelf assembly in a rack, isometric front view



Electromagnetic compatibilities for an alternative mounting apparatus

Passport 15000 and 20000 in a NEBS 2000 frame meet EMC standards as described in “Electromagnetic compatibilities” (page 162). When a Passport 15000 or 20000 is placed in a customer rack or cabinet, the equipment must have the same type of EMC compliance as the Passport shelf to maintain Class compliance.

Regardless of the EMC compliance level of either the shelf or mounting apparatus, the EMC compliance level of the combination is equal to the lowest compliance level of the parts. For example, when using a Class A compliant Passport 15000 and a Class B mounting apparatus, the shelf and mounting apparatus combination will have Class A compliance.

Cooling considerations

The cooling unit fans of shelf-based switch hardware packages NTQH04 and NTQS04 pull air from the lower front of the hardware and push it out from under the BIP to both the front and back of the rack.

A shelf kit installed in a rack, with no doors, allows for unrestricted air intake and exhaust. Consider locating your mounting apparatus where the front of the switch hardware will not intake exhaust air from other equipment, and where the upper rear of the hardware does not blow onto other equipment. See the table, “Passport 15000 and 20000 shelf air temperature rise” (page 92) for additional information about temperature generated by Passport equipment.

A shelf kit installed in a cabinet, with solid or perforated doors, must meet the following requirements to ensure that over heating will not effect or degrade the performance the cooling unit.

- The Passport 15000 or 20000 shelf kit requires no less than 10 cm free of obstructions in front of the cooling unit inlet.
- The cabinet doors should have no less than 25 cm² of open area in front of the cooling unit inlet.
- The exhaust air from the shelf must be removed from the cabinet to prevent the re-circulation of hot exhaust air from returning to the cooling unit inlet. To remove the exhaust air, cabinet fans, installed at the top of the cabinet, must be able to exchange the required airflow for the

Passport and all other equipment in the cabinet or perforations in the rear door of the cabinet, exhaust grill, and exhaust air ducting should be used to remove the exhaust air. The exhaust air duct and grille area should be located directly behind the BIP in order to direct the exhaust air from the rear of the shelf out of the cabinet. The exhaust grille area in the cabinet door and the exhaust duct cross sectional area should be at least 25 cm². The exhaust air duct must be installed such that air is prevented from leaking back into the cabinet.

If you plan to install additional equipment in the rack or cabinet above the Passport 15000 or 20000, do not restrict the inlet or exhaust area of the cooling unit with equipment cables. There must be sufficient air flow to ensure that the cooling unit is not taking in air heated by the additional equipment.

Table 19
Passport 15000 and 20000 shelf air temperature rise

Altitude	Shelf configuration	Room temperature degrees C			Shelf air temperature rise degrees C		
		long-term (normal)	short-term (high speed)	short-term (fan fail)	long-term (normal)	short-term (high speed)	short-term (fan fail)
Sea Level	1 card cage (75 W FPs)	£48	>48	£48	5	3	4
	1 card cage (150 W FPs) or 2 card cages (75 W FPs)	£4	>44	£44	9	6	8
	2 card cages (150 W FPs)	£35	>35	£35	18	12	16

(Sheet 1 of 2)

Table 19 (continued)
Passport 15000 and 20000 shelf air temperature rise

Altitude	Shelf configuration	Room temperature degrees C			Shelf air temperature rise degrees C		
		long-term (normal)	short-term (high speed)	short-term (fan fail)	long-term (normal)	short-term (high speed)	short-term (fan fail)
4000 m	1 card cage (75 W FPs)	£45	>45	£45	8	5	7
	1 card cage (150 W FPs) or 2 card cages (75 W FPs)	£38	>38	£38	15	10	14
	2 card cages (150 W FPs)	£24	>24	£24	30	20	27
(Sheet 2 of 2)							

Preparing your site's source of power

Ensure that the electricians who install the power input cabling for the Passport 15000 or 20000 are qualified to handle your method of power source.

Passport 15000 or 20000 switch hardware is dc-powered directly from a protected dc source (for example, by fuses or breakers) or indirectly from a system of ac rectifiers. The power demand is from 50 to 100 A for each feed. The amount of required power varies according to the number and kind of plug-in cards. To calculate your power requirements and install the appropriate power input cabling to where the switch will be located, see "Power distribution and consumption" (page 125).

Grounding the switch hardware

A Passport 15000 or 20000 switch and all other equipment installed in a rack must be grounded to comply with NEBS requirements. The frame must be grounded by using the silvery grounding tape, provided in the kit, mounted against clean, unpainted metal on the rack. The adapter brackets for mounting have the silvery grounding tape bonded to them at the factory.

If the rack cannot be grounded using the silvery grounding tape, the following criteria must be met:

- The BIP grounding stud connection must be utilized for bonding the BIP to the rack or cabinet.
- The Passport shelf grounding stud connection must be utilized for bonding the shelf to the rack or cabinet.
- Frame must be solidly bonded to the your site's ground

Chapter 3

Site preparation


Prepare the site for the anchoring a NEBS 2000 frame that houses one or two Passport 15000 or 20000 switches.

- “Task flow of site preparation” (page 95)

Task flow of site preparation

This task flow shows you the sequence of procedures you perform to prepare a site for anchoring a NEBS 2000 frame. To link to any procedure, go to “Task flow navigation” (page 95).

Figure 7
Task flow of site preparation



Task flow navigation

- “Before you begin” (page 96)
- “Using the NEBS floor template” (page 97)
- “Preparing the floor for anchor holes” (page 101)

Before you begin

This section provides information you need to consider before performing any of the procedures required for site preparation. The following topics are included:

- “Safety precautions” (page 96)
- “Tools and equipment required” (page 96)

Safety precautions

While you are preparing the floor, you must observe the general safety precautions against personal injury and equipment damage outlined in your local office standards. The procedures in this document contain specific caution and warning information that you must observe while performing each procedure.

For a description of the cautions and warnings which will appear in the procedures described in this document, see “Personal safety” (page 22).

Before following any of the procedures in this section, you should also see “Safe equipment handling” (page 23) for a description of the tools and personnel required to move Passport 15000 or 20000 switches in a frame into position.

Tools and equipment required

You must have the following tools and equipment to prepare the floor:

- a line marker (for example, chalk, wax pencil, or ink marker)
- raised floor marker
- 2-lb. ball peen hammer
- vacuum cleaner
- safety goggles
- ear plugs
- steel square, 12-in. by 24-in. minimum
- straight edge, 4-ft minimum
- 50-ft. (15 m) tape

- hammer drill (for example, a Hilti TE-52)
- 18-mm mason or floor-tile drill bit

Using the NEBS floor template


The floor template is the footprint of a NEBS 2000 frame. As the footprint, it enables the exact floor marking of the position of the frame or joined frames and the position of the anchor holes. Using a template maximizes efficient use of floor space. As the isolator pad, it insulates the frame from the floor. The NEBS floor template for a Passport 15000 or 20000 has part number A0682225.

The instructions for marking the footprint in the task flow “Preparing the floor for anchor holes” (page 101) also include accommodating space for:

- safe handling of switch hardware, as described in “Front and rear access to switch hardware” (page 72)
- the optional extended cable management brackets including a gap for cables to be passed beside the bracket, as described in “When adding a door to a NEBS 2000 frame” (page 111)
- routing signal cables through a raised floor beside a NEBS 2000 frame
- the upper and lower frame-to-frame joining brackets for two adjacent frames
- door hardware on either the front or the rear of a NEBS 2000 frame, as described in “When adding a door to a NEBS 2000 frame” (page 111)
- a 40-mm (1.57-in.) thick side panel on one or both sides of a frame

See the figure “NEBS 2000 footprint measurements” (page 98).

Figure 8
NEBS 2000 footprint measurements



Notes

1. The minimum safety distance for front and rear maintenance activities is 0.9 m (3 feet).
2. The minimum distance for at least one optional cable management extension bracket is 7.5 cm (3 inches).
3. Each quadrant has the same measurements, all corners are 90 degrees, each half is symmetrical, and inside measurements start from the ⊕.

PPT 2819 023 AA

Raised floor openings for processor cables

If you are planning to route the signaling cables from the function processors (FPs), control processors (CPs), or both under a raised floor, then you must allow space beside the footprint of the mounting apparatus to accommodate an opening in the raised floor tile. A floor opening should not be widened after cables are installed through it because of the risk of damaging a cable and affecting a system that is in service.

Determine the required area of the floor opening by factoring these criteria into your calculation.

- Use the table “Diameters of processor card cables” (page 38) to add up the diameters of the quantities of each type of processor cable that will be initially installed on the Passport 15000 or 20000.
- Add up the diameters of the quantities of each type of processor cable for cards that will possibly be added to empty slots after the initial installation.
- Accommodate passing the largest connector through each floor opening up to the last few cables without stressing any connectors on the way through.
- Allow space for replacement cards that have more connectors.
- You will likely need more than one floor opening. Allow space for each cable bundle to be loose enough to prevent pinching or crimping any cable going through a floor opening, or exceeding the bend radius of any cable as it enters or exits the opening.

It is recommended that you use the 7.5 cm (3 in.) area allowed in the footprint for using the extended cable management brackets. (See the area in the figure “NEBS 2000 footprint measurements” (page 98)). Depending on your floor tile structure and rating, you might be able to safely cut an opening up to 56 cm by 7 cm (22 in. by 2.75 in.) on either or both sides of the NEBS 2000 frame. When planning the position of an opening beside the footprint, ensure that:

- there is no support structure under the raised floor tile, or any other obstruction
- the capacity of the floor with one or two openings in it can still safely hold the weight of your Passport 15000 or 20000 after it is fully installed

- any DS3 or E1 signalling cables do not share a parallel path with the power cables

To calculate the weight of your Passport 15000 or 20000 switch hardware, see “Equipment size and weight” (page 58). To calculate your diminished raised floor capacity, estimate the size of the hole and deduct its area from the area rating of the floor. Once you have calculated these values, determine whether the floor can still safely support your hardware.

If all of the criteria can be met, include floor markings beside the footprint for the processor cable openings.

Preparing the floor for anchor holes


Preparing the floor for the anchoring holes is typically a one-time permanent task. This preparation is common to all types of anchoring.

- “Task flow of preparing the floor” (page 101)

Task flow of preparing the floor

This task flow shows you the sequence of procedures you perform to prepare the floor for anchor holes. To link to any procedure, go to “Task flow navigation” (page 95).

Figure 9
Task flow of preparing the floor for anchor holes



PP_TASK_1104

Task flow navigation

The following references are listed alphabetically:

- “Checking the floor” (page 104)
- “Common procedure used for drilling any floor” (page 105)
- “When adding a door to a NEBS 2000 frame” (page 111)
- “When adding a door to a NEBS 2000 frame” (page 111)
- “Marking the footprint and the anchor holes on the floor” (page 112)
- “When anchoring NEBS 2000 frames side-by-side” (page 116)
- “When anchoring ac rectifiers near a Passport” (page 118)

Checking the floor

Before marking a floor with the position of the frame, ensure the proposed position for anchoring the frame is appropriate. In a solid floor or underneath a raised floor, verify there are no obstacles that can cause unsafe installation of anchoring rods. For example, know where pipes, cables, or conduit pass near the proposed anchor hole positions. For raised floors with removable tiles, raise a tile at the proposed positions and verify that the underneath surface is clear of obstructions. For solid floors (for example, cement or marble inlay), review the building plans and site modification records to determine where anything lies imbedded in the floor. For raised floors without visual access, review the building plans and site modification records to determine where anything lies under the floor.

For any type of floor, verify it can support a maximum weight of 726 kg (1,600 pounds) at the position of the NEBS 2000 frame. This weight includes a completely installed frame with two Passport 15000 or 20000 switches, full of modules, and all power and signal cabling that fits inside the NEBS 2000 footprint. This maximum is a worst-case weight calculated by adding all of the heaviest pieces of equipment that can possibly fit within the NEBS 2000 footprint.

Note: The worst-case weight is not likely to be reached by an average configuration of hardware. For detailed information on calculating the actual weight of your configuration, see “Equipment size and weight” (page 58).

When considering the rating of your raised floor relative to the surface area to be occupied by the frame, include

$$38.1 + 30.48 \text{ cm} = 68.58 \text{ cm (or } 15 + 12 \text{ in.} = 27 \text{ in.)}$$

of aisle area in front and behind the frame. This aisle area is half the required minimum space in front of and behind a Passport 15000 or 20000 in a NEBS 2000 frame. With the frame and the aisle space, the total surface area of the floor would be

$$(38.1 + 60 + 30.48 \text{ cm}) \text{ times } 60 \text{ cm} = 7,714.8 \text{ sq cm} = 0.77148 \text{ square m}$$

or

$$(15 + 21.25 + 12 \text{ in.}) \text{ times } 21.25 \text{ in.} = 1025.3 \text{ sq in.} = 7.12 \text{ square ft}$$

Common procedure used for drilling any floor

Use this common procedure when you need to drill holes to anchor Passport switches.

Prerequisites

**WARNING****Risk of eye or ear injury**

Wear safety goggles and ear protection while drilling.

**WARNUNG****Verletzungsgefahr**

Tragen Sie beim Bohren eine Schutzbrille und einen Gehörschutz.

- “Preparing the floor for anchor holes” (page 101)

Procedure steps

- 1 Match the drill bit size to the diameter of the shank of the isolation bushing (part number P0715199) included in the anchor kit. As with drilling any cement, drill the hole first with a bit that is thinner than the final target. The hole must not be oversized or undersized, otherwise the anchor will not secure properly.
- 2 For drilling concrete, use the length of the parts of the anchor below the largest washer to measure the depth of the hole. For most Nortel Networks anchors, this is approximately 10 cm (4 in.). Refer to the figure “Anchor in a concrete floor” (page 110). If the drill has no depth gauge, mark the bit with electrical tape.

For drilling a raised floor, set the depth to pass the thickness of the upper floor.



WARNING

Risk of equipment damage by water

Do not penetrate the concrete into the vapor barrier when drilling holes. Ground water may seep into the anchor hole.



WARNING

Geräteschäden durch Wasser

Beschädigen Sie beim Bohren nicht die Dampfsperre unter dem Estrich. Es könnte Grundwasser durch die Verankerungslöcher dringen.

- 3 For drilling concrete, set the hammer drill to hammer. For a non-concrete or marble raised floor with or without removable tiles, set the drill to not hammer.
- 4 Start drilling the top surface of the floor. Apply moderate pressure to drill each hole until the depth gauge is even with the floor.

Consider drilling all 8 holes marked on the floor, even those not intended to be used. Once a frame is fastened to the floor, the only way to drill holes later is to remove the anchors and the frame off the footprint. With the frame anchored and holes already drilled, additional anchors can be installed later.



CAUTION

Risk of service degradation or equipment damage

While drilling into the floor to create anchor holes, vacuum the dust. Use a vacuum with an induction-wound motor to prevent EMI from affecting nearby electronic circuitry. Dust can prevent the proper seating of cards or modules or prematurely increase the arresstance of the cooling air through the fan filters.

- 5 While drilling the floor, vacuum the drill bit debris. Use a foot or a helper to hold the nozzle in position.
- 6 To drill the anchor hole into the surface under a raised floor, place a post level against the shaft of the bit to determine a vertical angle relative to gravity. The drill bit for a raised floor is typically approximately 46 cm

(18 in.) long. Allow for adding the height of the post level. See the figure "Drilling a raised floor without removable tiles" (page 109).

- 7 For a cement floor or a raised floor without removable panels, remove the debris from the bottom of the drilled holes by taping a tube to the vacuum nozzle. The tube must be long enough and narrow enough to reach the bottoms of the holes.

For a raised floor with removable panels, lift a nearby panel to vacuum the drill bit debris from the lower surface.

**CAUTION****Risk of improper equipment grounding**

When an anchor hole exposes conductive construction materials (for example, rebar) in a cement floor and the anchor contacts it, there is a possibility that the isolator bushing around the anchor can fail from earthquake vibrations. The contact with the rebar risks having the building ground interfere with the site ground that the frame is grounded to. Never use anchor hole that exposes conductive material in the hole.

- 8 Look inside each hole to verify that no conductive construction material (rebar) has been exposed by the hole.

When a hole exposes such material, drill a hole at the other end of the oval opening. If the second hole hits more conductive construction material, use another oval hole.

- 9 Cover the holes with tape to keep them clean until the anchors are actually installed.

Procedure job aid

Figure 10
Anchoring to a raised floor with removable tiles




Figure 11
Drilling a raised floor without removable tiles





Figure 12
Anchor in a concrete floor



When adding extended cable management brackets to a NEBS 2000 frame

The optional extended brackets enable handling the cables of one or two fully provisioned Passport 15000 or 20000 switches in the frame. Installing the NTRU0370 junction kits provides brackets and hardware to join two adjacent and equally enlarged NEBS 2000 frames.

The frame spacer kits in NTRU0365 are used to enlarge the standard 600 by 600 mm footprint of a NEBS 2000 frame. They add 150 mm width to the footprint, 75 mm on each side. Installing the NTRU0365 kits means that the spacer brackets from these kits must be installed on each side of the frame. Installing the spacer brackets enables adding the optional extended cable management brackets (NTRU0368 and NTRU0369).

The need for the extended cable management brackets is described in “Managing very high-density coax cabling” (page 43).

When adding a door to a NEBS 2000 frame

The door hardware from kits NTQS37AA and NTQS37AB is added to the base of a NEBS 2000 frame. When adding a door and its mounting hardware to a frame, the footprint where the frame is to be anchored or has been anchored increases into the aisle by 6.6 cm (2 5/8 in.) on that face of the frame. Adding a door to both the front and rear of the frame increases the footprint the same on each half for a total of 13.2 cm (5 1/4 in.). The larger footprint must accommodate:

- space to add the extension hardware and space to install it by hand tools
- space to fully open the door at either the front or rear of frame so that plug-in cards or modules can be safely removed and installed, as indicated in “Front and rear access to switch hardware” (page 72)

Marking the footprint and the anchor holes on the floor

Mark the footprint and anchor holes in preparation for drilling.

Prerequisites



WARNING

Risk of injury by restricted access

Before marking the floor with the footprint of the NEBS 2000 frame, ensure there is a minimum safety clearance of 0.9 m (3 feet) in front of or behind a Passport 15000 or 20000. The minimum is required to enable personnel to safely do various installation, maintenance, or upgrade tasks on the Passport 15000.



WARNUNG

Verletzungsgefahr

Planen Sie einen Sicherheitsabstand von mindestens 0,9 m ein, wenn Sie den Umriß des Gestells auf dem Boden aufzeichnen. Dieser Abstand ist erforderlich, damit vor und hinter dem Passport 15000 oder 20000 Installations-, Wartungs- und Aufrüstungsarbeiten gefahrlos möglich sind.

- “Checking the floor” (page 104)
- “When anchoring NEBS 2000 frames side-by-side” (page 116)
- For information on marking the footprint of an Astec MFA150 framework (for the installation of ac rectifiers), refer to the Astec document 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.
- Marking the footprint of an NTRU04 frame (also known as the PTE 2000 frame) has no margin of error for adjusting an anchor hole after it is drilled, or moving a frame to add or replace a component. Each oval opening in the base of the frame accommodates having a hole to drilled in the floor (or through a raised tile) at either end of the oval. This

provides two positions for the drill hole to miss imbedded reinforcing rods (rebar). The outside end of the ovals is the primary anchoring hole position, while the inside end is the secondary choice.

Procedure steps

- 1 Place the footprint template (part number P0890503) on the floor where the frame is to be anchored or mark a footprint according to the clearances shown in the figure “NEBS 2000 footprint measurements” (page 98).
- 2 Verify there are no obstacles where the frame anchors are to be installed. For a raised floor with removable panels, remove the panel to view the surface underneath. For a raised floor without removable panels, stick a solid-core wire (a “fish tape”) through the holes and pivot it against the lower surface. Move obstacles aside if possible. Otherwise, see “Checking the floor” (page 104).
- 3 Measure the minimum clearances of 72 cm (30 in.) of open space from the edges of the front and 61 cm (24 in.) from the rear of the frame, and 7.5 cm (3 in.) on both sides of the template. The side clearance is the minimum required when the optional extended cable brackets are present or to be added onto the side of the frame (NTHR0368 for the left side facing the front of the frame or NTHR0369 for the right side).

If an adjacent frame is installed closer than this minimum, then the brackets cannot be added later as an upgrade or an increase in cable management due to increased module provisioning. The spacer brackets in kit number NTRU0365 ensure the required minimum space between the fastened frames. When positioning a second Nortel Networks frame to join this one, use the same clearance on the second one.

- 4 If the frame is to have doors added to the front or rear of the frame (or both), the footprint must be enlarged according to the specifications in “When adding a door to a NEBS 2000 frame” (page 111).
- 5 If the frame is to have the optional extended cable management brackets added (NTR0368 on the left side facing the front, or NTRU0369 on the right side), add another 7.5 cm (3 in.) to each side that is to have the brackets.
- 6 If the frame is to have an optional exterior side panel added, either regular or extended size, mark another 4.0 cm (1.6 in.) per panel to the side of the floor clearance.

A side panel cannot be put between joined frames, especially if the extended cable management brackets are going to be used on the adjacent sides of the frame. The brackets in spacer kit NTRU0365 allows

a regular size side panel to cover the extended cable management brackets.

7 Mark the clearance on the floor as a dashed line.

8 Adjust the position of the template until all clearances are met.

For a raised floor with removable tiles, ensure the anchor hole markings are at least 5 cm (2 in.) from the edge of a tile. This avoids drilling the support of the tile that is under the floor.

9 Indelibly mark onto the floor the perimeter of the footprint template and all oval openings that are to have an anchor. The perimeter is used later to accurately position the frame. For zone 4 compliance, a minimum of 4 anchors must be used. The NEBS 2000 frame is best anchored at the 4 outer corners with the hardware indicated in the table “Frame anchoring kits” (page 115). The position of each anchor should have been verified as clear of obstruction in or under the floor in “Checking the floor” (page 104).

10 From the table “Frame anchoring kits” (page 115), identify the anchor that is appropriate to the type of floor or grade of installation.

11 Mark all 8 oval anchor openings on the floor. Although the frame provides 8 oval anchor openings, it is not necessary to use all unless the site has been zoned for seismic tolerance. Zone 2 anchoring requires a minimum of 4 anchors, while zone 3 requires 6 anchors (3 per half), and zone 4 requires all 8. All ovals are marked in case the drilling reaches an obstruction imbedded in the floor (for example, construction rods or rebar).

12 At the outside end (relative to the perimeter of the footprint) of each oval opening, mark a center point as close to the end as the thickness of the anchor. Anchor diameters are indicated in the table “Frame anchoring kits” (page 115).

The other end of the oval opening is to be drilled only if the hole in the outside end has reached an obstruction.

13 Keep the footprint template (insulator pad) with the frame because it is to be used again when the frame is anchored to the floor.

14 Follow “Common procedure used for drilling any floor” (page 105).

Procedure job aid

Table 20
Frame anchoring kits

Kit code	Description	CPC number	Description	Qty
NTRU0327	M12 concrete and raised floor anchor kit	A0686271 P0873854	Hilti HSLG M12 expansion anchor kit, steel sleeve, 30 mm long	4
(A0682227)	anchors	P0601087	M12 1.75 x 762 mm (30") threaded rod	4
	800 mm depth in concrete	P0133117	flat washer 0.563" ID, 1.375" OD, 0.109" T	4
	up to zone 4	P0691892	Belleville washer.52" ID, 1.31" OD, 14" T	4
		P0715199	isolation bushing 2.5/0.9" OD, 0.5" ID, 0.4/0.08" T	4
		P0600400	M12 1.75 nut	18
		P0691895	plate washer.531" ID, 2.375" OD, 0.375" T	18
NTRU0325	3/8" in concrete and raised floor anchor kit	P0649113	expansion shield, 3/8", 16 x 1.5"	4
(A0681285)	4 anchors	P0691006	3/8", 16 x 30" threaded rod	4
	300 and 600 mm depth in concrete	P0284166	flat washer 0.451" ID, 0.875" OD, 0.071" T	4
		P0691891	Belleville washer 0.431" ID, 1.063" OD, 0.125" T	4
	up to zone 2	P0715199	isolation bushing 2.5/.9" OD, 0.5" ID, 0.4/0.08" T	4
		P0401452	3/8" 16 nut	12
		P0735806	plate washer 0.406" ID, 2.25" OD, 0.188" T	12
	Legend:	ID	inside diameter	
		OD	outside diameter	
		T	thickness	

When anchoring NEBS 2000 frames side-by-side

When anchoring NEBS 2000 frames side-by-side to minimize use of floor space or to accommodate a fanout (NTHW52) or sparing panel (NTQS31), the adjacent frames can be fastened together. For example, when a frame contains two Passport 15000 or 20000 switches, an adjacent frame minimizes the distance of cabling to a fanout or sparing panel. When the frame contains one switch, the panel can be installed in the empty portion. (The installation of a sparing panel is described in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade.*)

Before anchoring side-by-side Nortel Networks frames, determine the type of joining bracket that will be used. The type of bracket determines how far apart the frame footprint for anchoring is marked on the floor.

Adjacent NEBS 2000 frames can be fastened with the upper and lower frame-to-frame joining brackets in kit number A0677590 (that comes with the frame) or optional kit numbers NTHR0370 and NTRU0365. The optional kits are required when the extended cable management brackets will be installed on the side of a frame and between the pair of frames. Using either sets of kit:

- maximizes efficient use of floor space
- minimizes the lengths of fiber or coax cable run between a Passport 15000 or 20000 and its sparing panel (which must be in its own frame)
- maintains the minimum distance required to string FP cable clusters between cable brackets when fastening them to the brackets
- increases the stability of the frames for safety

Using optional kits NTHR0370 and NTRU0365 together

- accommodates the space to install optional extended cable management brackets in kits NTRU0368 and NTRU0369
- accommodates a 19-mm (0.75-inch) clearance for inserting cables between the arms of opposing extended cable management brackets mounted on adjacent frames

Anchoring a second frame beside and joining a first frame uses:

- 1 an identical footprint to the one shown in the figure “NEBS 2000 footprint measurements” (page 98) or at least measurements from it (for example, the footprint space between the frames is fixed, but the measurements at either end of the pair may be less if the optional extended cable management brackets will never be added)
- 2 the pair of frames must be adjustable to the same height together
- 3 the frames must be fastened together by the frame-to-frame brackets and levelled together before the pair are anchored to the floor

The floor must be pre-marked to accommodate adjacent frames to be fastened together. Refer to “Marking the footprint and the anchor holes on the floor” (page 112).

When anchoring ac rectifiers near a Passport

When a Passport 15000 and 20000 is to be powered by a system of ac rectifiers, such as an Astec MFA150 power system, you must consider how close the rack, frame, or framework is to be anchored near the NEBS 2000 frame. The basic considerations are identified in “Assess the location of a system of ac rectifiers” (page 74).

For the details of preparing the floor and drilling anchor holes for an MFA150 framework, see the Astec document 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.

Chapter 4

Power and grounding preparation

This section describes the various aspects of power distribution and grounding that are important to consider when you plan to install one of the following Passport products:

- Passport 15000
- Passport 15000-VSS
- Passport 20000

This section also includes shared power and grounding of peripheral equipment that interworks with a Passport.

The topics discussed in this section are:

- “Power architecture” (page 120)
- “Power requirements” (page 121)
- “Power distribution and consumption” (page 125)
- “Preparation for installing power and ground cables” (page 131)
- “Power cable specifications” (page 143)
- “Power and ground cabling overview” (page 153)
- “Grounding the frame and communication links” (page 157)

Power architecture

Power is supplied to the Passport 15000 or 20000 by redundant A and B feeds to the breaker interface panel (BIP). The source of power must be dc that is provided either directly from the site power plant or from a system of ac rectifiers, such as an Astec MFA150 power system.

The BIP provides the following functions.

- It is a termination point for large power distribution cables from the customer dc power source (site plant or rectifiers).
- It provides a means to power down individual incoming dc feeds to allow safe servicing at an individual shelf.
- It provides low-frequency stability filtering for each input feed. This ensures that critical damping is achieved and that step load changes will not result in oscillations on the dc power bus.
- It provides stabilized output power feed connections to the shelf assembly and cooling units. For example, when set up with the redundant A and B feeds, either feed can provide power through the BIP to the whole shelf in a load-sharing mode of operation.
- It provides internal and external alarm collection and propagation.

For each power feed to a shelf, a redundant pair of power interface modules (PIMs) further filters and interfaces the -48/-60 V dc power to the backplane. Each control processor (CP) or function processor (FP) also provides additional high frequency filtering.

In general, the power and ground cabling requirements and guidelines between a Passport 15000 or 20000 and an MFA150 configuration is the same as for a dc site power plant unless otherwise specified. For information about power and ground requirements between an MFA150 and a Passport 15000 or 20000, see

- “Power requirements” (page 121)
- “Preparation for installing power and ground cables” (page 131)
- “Power and ground cabling overview” (page 153)
- “Grounding the frame and communication links” (page 157)

To install an MFA150 rectifier setup, see the Astec document 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.

For information about how the Astec MFA150 operates with a Passport 15000 or 20000, see 241-1501-200 *Passport 15000, 20000 Hardware Description*.

Passport 15000-VSS power architecture

Power from the site distribution panels is supplied to the Passport 15000-Variable Speed Switch by two different methods:

- Power for the Passport 15000 node is supplied at the breaker interface panel as described in “Power architecture” (page 120).
- Power for the Passport 7480 node is supplied directly from a disconnect device to the Passport 7480 as described in the 16-slot Passport switch section of 241-7401-200 *Passport 7400 Hardware Description*.

Power requirements

To meet the maximum power demands on a fully provisioned Passport 15000 or 20000 switch, Nortel Networks recommends input power to be fed by up to 1/0 AWG (53.49 mm²) cables with a guarantee of 40 or 50 up to 100 A per feed. (The 40 A is two times the largest BIP breaker for a Passport 15000, while the 50 A is two times the largest BIP breaker for a Passport 20000.) The cables must meet or exceed the criteria identified in “Power cable specifications” (page 143).

For a Passport 15000, shelf power is supplied through four feeds at a nominal voltage of -48/-60 V dc at 20 A. Each shelf is rated at 3000 W. The maximum current rating per feed is up to 85 to 100 A, while the minimum is 40 A. When planning to use less than 100-A feeds, see “Power cable specifications for a partially provisioned shelf” (page 146).

For a Passport 20000, shelf power is supplied through four feeds at a nominal voltage of -48/-60 V dc at 20 A. Each shelf is rated at 3000 W. The maximum current rating per feed is up to 85 to 100 A, while the minimum is 40 A. When planning to use less than 100-A feeds, see “Power cable specifications for a partially provisioned shelf” (page 146).

For information about power division and calculating power consumption, see “Power distribution and consumption” (page 125).

See the appropriate section for additional power requirements:

- “Redundant power feeds” (page 122)
- “Power input through tapping a main” (page 122)
- “Power input from a system of ac rectifiers” (page 123)

Redundant power feeds

It is desirable to power a Passport 15000 or 20000 switch from two independent sources in such a way that it eliminates a single point of failure. For example, if the A side fails, the B side continues the load to the same breaker interface module (BIM). Also, each power feed to a Passport 15000 or 20000 must be protected by a fuse or breaker between the battery and the BIP.

This process involves complete separation of the feeders, including the BR (battery returns) to avoid potential influence that a failing side could impose on the redundant side.

Passport 15000 or 20000 supports completely separate battery feeds and battery returns down to the control processors (CPs), function processors (FPs), and cooling units. Under normal conditions, the load is shared evenly between the two feeds if they are within 0.3 V of each other. Each feed must therefore be engineered to operate a fully provisioned shelf if one feed fails.

Power input through tapping a main

When tapping the 1/0 AWG (53.49 mm²) power cable from a larger cable to the breaker interface panel (BIP) of the Passport 15000 or 20000, the total consumption of power from the larger cable must always be capable of providing the power requirement at the rear of the BIP.

For information about cable sizes and ratings, see “Power cable specifications” (page 143).


Power input from a system of ac rectifiers

When powering the BIP from a system of ac rectifiers, such as an Astec MFA150 power system without batteries, the nominal dc power output must be 50 A. To power two Passport 15000 or 20000 switches, Nortel Networks recommends using an MFA150 configuration of five 25-A rectifiers connected in parallel. To power one switch, use an MFA150 configuration of three 25-A rectifiers connected in parallel. Four or two rectifiers provide up to 50 A per shelf and one backs up any of the others for an n+1 sparing. For an example, see the figure “MFA150 power system of five rectifiers for two Passport 15000 or 20000 shelves” (page 124).

After calculating the total power consumption of the configuration of your switch, you may identify that the ac rectifier system you plan on using cannot provide enough power, or does not allow for any additional cards or modules. Calculating the power usage is described “Power distribution and consumption” (page 125).

For the power cables between the MFA150 rectifiers and the BIP, you must use cables with an appropriate gauge and rating for 50-A service to the BIP. See “Power cable specifications when using ac rectifiers” (page 152).

Figure 13
MFA150 power system of five rectifiers for two Passport 15000 or 20000 shelves



PPT 2997 001 AB

Passport 15000-VSS power requirements

The power supply for the Passport 15000-Variable Speed Switch (VSS) is dc. Since a VSS is a combination of a Passport 15000 and a Passport 7480, the power requirements for each is different.

- For the Passport 15000, see “Power requirements” (page 121).
- For the Passport 7480, see the section on power requirements in 241-7401-200 *Passport 7400 Hardware Description*.

Power distribution and consumption

The Passport 15000 or 20000 switch is powered from four field-replaceable power interface modules (PIMs) located on the back of the shelf. Each PIM terminates two redundant power feeds from the BIP (either an A feed or B feed from a single breaker interface module). The filter consists of a passive low pass LC network that provides EMI filtering to prevent shelf generated noise from being radiated. Each filter also provides termination for the HSCX buses and clock signals.

For a Passport 15000 the redundant power feeds are 20 A.

For a Passport 20000 the redundant power feeds are 25 A.

Total power consumption depends on the type and quantity of installed parts. The total power consumption dictates the minimum gauge of power cable and the power plant that you can safely use for the Passport 15000 or 20000 (if you choose not to use the recommended 1/0 AWG cable).



CAUTION

Equipment damage

If you install additional power-consuming hardware parts in your configuration, you must recalculate the power consumption (and current required) and install the appropriate cabling and fuses or breakers, if necessary.

To determine the minimum gauge of cable you can use, calculate the input current that your system configuration requires by doing the following:

- 1 Determine the power consumption in watts for each Passport 15000 or 20000 by totalling the maximum power consumption of the individual parts. Use the table “Power consumption for hardware parts for a Passport 15000 or 20000” (page 127), which is sorted by part number. The information in the table (sorted by PEC) enables you to calculate the total typical and maximum power consumption. Always use the maximum value in your calculations.

Note: Most sparing panels show 0.0 W consumed because they get their power from at least one FP that connects to it. The power consumption values for the electrical FPs take into account how much a sparing panel will draw (about 0.8 W average except for NTQS31).

- 2 Divide each shelf’s total maximum consumption in watts either by the worst case voltage (36.5 V or -46.0 V with a system of ac rectifiers), or by the low drop-out voltage (for example, 43.5 V) at the BIP input if your system uses a low voltage disconnect device. (For example, this calculation gives you the current in amps (single feed maximum) that each shelf requires. See “Sample calculation of maximum input current” (page 130) for an example.
- 3 Choose a gauge of power cable that is rated for the current in amps that each shelf requires, and rated according to the distance between the power source and the BIP to ensure the voltage drop is less than 1.75 V.

Note: To prevent nuisance tripping of the breakers, they need to be rated at least 25 to 30% above the calculated amperage for your system, to a maximum of the 100 A breaker rating.

Table 21
Power consumption for hardware parts for a Passport 15000 or 20000

Hardware part	Typical power (W)	Maximum power (W)
NT6C61 or NT6C62 BIP (per shelf, 2 feeds, with 20 A breakers)	12.84	20.82
NT6C67AA or NT6C68AA BIP (per shelf, 2 feeds, with 25 A breakers)	12.84	20.82
NTHP99 3-port DS3 sparing panel power is supplied by the FPs	0.0	0.0
NTHR05 OC-3 multimode CQC	52.2	65.25
NTHR06 control processor (CP2E)	25.0	50.0
NTHR12, NTHR13, or NTHR14 alarm/BITS module	diode ORed across all feeds and consumes about 1.0 W.	
NTHR11 MAC address module power is supplied by the control processor (CP)	0.0	0.0
NTHR15 power interface module (PIM) power is supplied by the control processor (CP)	0.0	0.0
NTHR16 fabric	50.0	60.0
NTHR17 4-port OC-3 multimode	73.0	100.0
NTHR21 4-port OC-3 single-mode intermediate reach	75.0	100.0
NTHR23 12-port DS3	71.0	100.0
NTHR25 12-port E3	71.0	100.0
NTHR29 1-port OC-12 single-mode long reach	87.0	111.25
NTHR31 4-port DS3 ATM IMA	115.0	138.0
NTHR35 control processor (CP2E)	25.0	50.0
NTHR37 sparing panel power is supplied by the FPs	0.0	0.0
Note: See NTQS31 because NTHR37 is part of it.		
(Sheet 1 of 4)		

Table 21 (continued)
Power consumption for hardware parts for a Passport 15000 or 20000

Hardware part	Typical power (W)	Maximum power (W)
NTHR45 CQC E3	41.76	52.2
NTHR47 CQC OC-3 single-mode	54.81	68.51
NTHR51AA or AB, or NTHR52AA or AB cooling unit	79.2	187.2
NTHR64 blank processor card (also known as a filler module) power is not used by this card	0.0	0.0
NTHR79 4-port DS3 sparing panel power is supplied by the FPs	0.0	0.0
NTHR83 1-port STM-1 channelized single-mode intermediate reach FR	84.0	105.0
NTHR86 1-port STM-1 channelized single-mode intermediate reach ATM/IMA	100.0	125.0
NTHR88 4-port DS3 channelized FR	77.2	115.0
NTHR89 4-port DS3 channelized FR	65.0	90.0
NTHR91 4-port DS3 channelized AAL1 CES	115.0	138.0
NTHW01 1-port OC-48/STM-16 single-mode intermediate reach ATM with APS	68.1	99.25
NTHW05 4-port OC-3 multimode	73.0	100.0
NTHW06 control processor (CP3)	36.7	55.0
NTHW08 control processor (CP3)	36.7	55.0
NTHW10 2-port general processor with disk	36.7	55.0
NTHW11 4-port OC-12/STM-4 single-mode intermediate reach ATM	136.0	150.0
NTHW15 4-port OC-3 single-mode intermediate reach	75.0	100.0
NTHW18 6-module packet server service processor	__TBD__	__TBD__
(Sheet 2 of 4)		

Table 21 (continued)
Power consumption for hardware parts for a Passport 15000 or 20000

Hardware part	Typical power (W)	Maximum power (W)
NTHW21 16-port OC-3/STM-1 ATM single-mode intermediate reach	130.0	150.0
NTHW30 VPN extender card	36.7	55.0
NTHW31 16-port OC-3/STM-1 single-mode intermediate reach ATM	130.0	150.0
NTHW39 1-port OC-48/STM-16 single-mode short reach POS	90.0	120.0
NTHW44 16-port OC-3/STM-1 POS and ATM	140.0	150.0
NTHW49 4-port Gigabit Ethernet	120.0	150.0
NTHW52 12-port DS3 or E3 fanout panel power is not used with this patch panel	0.0	0.0
NTHW70 4-port OC-3/STM-1Ch single-mode intermediate reach TDM/CES	120.0	150.0
NTHW77 voice services processor 3 with optical TDM interface (VSP3-o)	115.0	140.0
NTHW84 voice services processor 3 (VSP3)	90.0	130.0
NTHW86 4-port OC-12 single-mode intermediate reach ATM	120.0	150.0
NTHW87 Voice services processor 2 (VSP2)	90.0	110.0
NTHW91 2-port DS3C TDM	40.0	50.0
NTHW92 32-port E1 TDM	40.0	50.0
NTPN02 fabric	77.0	85.0
NTPN11 MAC address module power is supplied by the control processor (CP)	0.0	0.0
NTPN12 or NTPN13 alarm/BITS module	diode ORed across all feeds and consumes about 1.0 W.	
(Sheet 3 of 4)		

Table 21 (continued)
Power consumption for hardware parts for a Passport 15000 or 20000

Hardware part	Typical power (W)	Maximum power (W)
NTPN15 power interface module (PIM) power is supplied by the control processor (CP)	0.0	0.0
NTQS31 sparing panel power is supplied by the FPs <i>Note:</i> Although the sparing panel draws its power from at least one DS3 or E3 FP, add 10 W of power consumption when using one.	10.0	10.0
NTPP0x small form pluggable (SFP) module <i>Note:</i> Each SFP is powered from its FP, so do not add the SFP consumption to your totals.	0.7	1.0
(Sheet 4 of 4)		

Sample calculation of maximum input current

This section provides a sample calculation to show you how to calculate the maximum input current (single feed max) in amps. The following example is for a very limited system configuration, with one Passport 15000 node.

Note: This calculation is an example only. The maximum input current for your configuration depends on the type and number of hardware parts that you install. Always use the maximum power values.

part	Quantity	Maximum power (W)
control processor	2	100.0
fabric card	2	120.0
BIP	1	20.82
cooling unit	1	187.2
MAC address module	1	0.0
alarm/BITS module	1	0.0
TOTAL POWER CONSUMPTION		428.02 W
(Sheet 1 of 2)		

part	Quantity	Maximum power (W)
TOTAL MAX CURRENT INPUT (at WCV) =		
		428.02 W / 34.7 V = 12.3 A (single feed maximum)
Note: 34.7 V is the worst case voltage (WCV), from 36.6 V at the BIP and an internal drop of 1.9 V. If you use a low-voltage disconnect device (LVD), see the last row of this table.		
TOTAL MAX CURRENT INPUT (at LDO voltage) =		
		428.02 W / 43.5 V = 9.8 A
Note: If you use a low-voltage disconnect device (LVD), then the WCV is the trip value of the LVD measured at the the BIP power input, that is, the low drop-out (LDO) voltage. In this example, the LDO voltage is 43.5 V.		
(Sheet 2 of 2)		

Passport 15000-VSS power distribution

Power distribution for the Passport 15000 Variable Speed Switch (VSS) is different for each node.

- For the Passport 15000, see “Power distribution and consumption” (page 125).
- For the Passport 7480, see the section on power in 241-7401-200 *Passport 7400 Hardware Description*.

Preparation for installing power and ground cables

The Passport 15000 or 20000 is powered from a dc power source by 2 or 4 feeds to the breaker interface panel (BIP). The dc power source can be from either an all-dc power plant or a system of ac rectifiers, such as an Astec MFA150 power system. A feed is two power cables, a negative (battery) and a positive (battery return). The BIP handles the input power to the

Passport 15000 or 20000 through the feeds A1 and B1 for the lower shelf and A2 and B2 for the upper shelf, and redundantly distributes the power to hardware parts.

The operating company must provide and install the input power cables that feed the system of ac rectifiers. If using an MFA150 power system of rectifiers, the ac power input cable to the MFA150 must be ordered separately. For the size of power input between the MFA150 and the BIP, see “Power distribution and consumption” (page 125) to calculate the power demand of the Passport 15000 or 20000.



WARNING

Risk of injury and equipment damage by electricity

For installing input power cables, ensure the installer is a qualified electrician. Local electrical codes take precedence over Nortel Networks’ unless the local code advocates a lesser grade of installation.



WARNUNG

Gefahr von Geräteschäden und Verletzungen

Lassen Sie die Stromversorgungskabel nur von einem qualifizierten Elektriker verlegen. Die an Ihrem Standort gültigen gesetzlichen Normen haben Vorrang vor den Richtlinien, die Nortel Networks aufgestellt hat, sofern diese Richtlinien nicht strenger sind als die gesetzlichen Normen.

The overall installation of power and ground cables from the power plant to the BIP includes:

- installing the A and B power feed cables from the customer premises equipment (CPE), the central office (CO), or a system of ac rectifiers to the BIP
- when using an Astec MFA150 power system of rectifiers, installing the ac power input cable
- connecting the A and B power feed cables

- grounding the Passport 15000 or 20000 to the CPE or the CO ground window to the NEBS 2000 frame
- if present, grounding the MFA150 power system to the same ground window as the Passport 15000 or 20000
- adding a pair of breaker interface modules (BIMs) to the BIP
- adding the power distribution cables from the BIP to a second shelf and to its cooling unit (already pre-wired in NTQS10)

**CAUTION****Risk of damage to equipment by reversed polarity**

Use the plus (+) and minus (-) symbols on the rear of the breaker interface panel (BIP) to ensure that the polarity of each A and B battery (-48/-60 V dc) and battery return for the input power feeds is correct. When powering up the BIP, reversed polarity will damage circuits inside it.

Before installing the power and ground cables for a Passport 15000 or 20000, observe the following information:

- “Allowing for voltage drop over distance” (page 133)
- “About restricted and non-restricted sites” (page 135)
- “Labeling the power feeds in CPE or a CO” (page 136)
- “Grounding the frame in CPE or a CO” (page 138)
- “Grounding when not using a NEBS 2000 frame” (page 141)
- “Grounding when using ac rectifiers as a power source” (page 141)
- “Prerequisites to installing dc power input cables” (page 141)

Allowing for voltage drop over distance

As the distance from the power source to the cable connections to the BIP increases, the voltage drops on the feeds. The gauge of wire must be increased according to the distance to the connection so that exceeding the allowable voltage drop is prevented.

In a takeover mode for power redundancy, a larger voltage drop occurs between the dc power source and the BIP. For example, when the A feed takes over the B feed, a drop larger than 1.75 V occurs and the amount of drop depends on the gauge and distance of power cable. This is normal. During the drop, Passport 15000 or 20000 operation and service are maintained. If during the takeover mode the battery becomes low (a double fault scenario), the system turns itself off for protection. When the power source level returns to nominal, the system turns itself back on. For the effects of turning the switch off, refer to 241-5701-600 *Passport 7400, 15000, 20000 Configuration Guide*.

To determine the size of power cable at CPE, a CO, or an ac rectifier to the BIP, or from a C-tap to the BIP according to the distance the cable must be run, use the table “Power feed sizes” (page 135) as a guide. The specifications in the table meet the following criteria:

- the distance is one way from the power source to the BIP
- a 1.75 V loop drop from the power source to the BIP for a single feed is already included in the specifications, assuming a 50% load diversity between the A and B feed pairs (that is, sharing 26.5 A each so that with one power source down, the other has 85 A)
- the insulation rating on the feeder cable is assumed to be a minimum 90-degrees Celsius and the maximum ambient room temperature is assumed to be 50 degrees Celsius (122 Fahrenheit)
- the use of No. 1/0 AWG (53.49 mm²) to the BIP is based on 8 conductors in the cable bundle for two fully provisioned Passport 15000 or 20000 switches in a frame

Note: When using a dc site source for power, rate the size of the over-current feed protector for dc with disconnects that are approved according to the country where the Passport is installed (for example, UL, CSA, or VDE). The approved disconnect must never exceed 85 to 100 A or be lower than 40 A. (The 40 A is derived from two times the largest BIP breaker.) When using an Astec MFA150 power system of ac rectifiers to provide dc power, the over-current feed protection is provided by mid-trip breakers.

With a Passport 20000, the breakers to the shelves on the breaker interface panel (BIP) increase from 20 A to 25 A. Apply the same criteria for voltage drop, cable size, and cable specification as a regular Passport 15000 with the 20 A breakers.

Table 22
Power feed sizes

Cable size	maximum distance for 1 V dc voltage drop	maximum distance for 1.75 V dc voltage drop
1 (42.41 mm ²)	48.5 ft (15.9 m)	84.8 ft (27.8 m)
1/0 (53.49 mm ²)	61.3 ft (20.1 m)	107.2 ft (35.2 m)
2/0 (67.43 mm ²) see Note	77.0 ft (25.3 m)	134.9 ft (44.2 m)
4/0 (107.2 mm ²) see Note	97.3 ft (31.9 m)	170.4 ft (51.9 m)
Note: The power cables being terminated at the BIP input studs must be up to No. 1/0 AWG. Using larger cables up to the BIP requires C-tapping by an appropriate size less than or equal to 1/0 AWG at the BIP.		

About restricted and non-restricted sites

A Passport 15000 or 20000 that is installed in a non-restricted access environment (as with CPE, typically) requires the use of conduit for power cables. The conduit that is passed into the bottom of the frame must be metal, for example, electrical metallic tubing (EMT). To accommodate conduit while maintaining protection from fire, the base of the NEBS 2000 frame has two 2-inch conduit knockout disks. When using conduit for the installation, Nortel Networks recommends using 2-inch metal conduit for power cables going to the BIP. For overhead conduit, stop the installation at the conduit box above the frame. (The PEC for the conduit box is NTHR78.) According to the CE Code Handbook and the National Electric Code, 2-inch EMT conduit can house up to four No. 1/0 AWG cables. For under-floor conduit, stop the conduit at the plate in the bottom of the frame. The installations involving conduit are described in 241-1501-240 *Passport 15000, 20000 Hardware Installation, Maintenance and Upgrade*, the chapter on installing power and ground cables.

A Passport 15000 or 20000 that is installed in a restricted access environment (as with a central office, typically) does not require the use of conduit for power cables and must comply with the operating company's requirements. However, the fastening caution for conduit also applies to cable without conduit.



CAUTION

Risk of equipment damage by fire

In the bottom rear center of the frame, each removable plate (drip tray, part number P0870734) may have two knockout disks. Each knockout disk must remain intact and unbent unless a power conduit from a raised floor will be routed through it. Leaving an opening reduces the fire-proofing of the Passport 15000 or 20000.

Labeling the power feeds in CPE or a CO

It is recommended that you identify dc input power cables with permanent labels or color codes or both according to the tables:

- “Cable identification, Germany” (page 137)
- “Cable identification, Japan” (page 138)
- “Cable identification, North America” (page 137)
- “Cable identification, United Kingdom” (page 138)

With the polyvalent power-and-ground assembly (A0834143), each terminal block for a power cable is provided with a label indicating it is a battery return or battery.

With the European Telecommunications Standards Institutes (ETSI) power-and-ground assembly (A0834149), each terminal block for a power or ground cable is provided with a label indicating it is a battery return, frame ground, or battery.

Table 23
Cable identification, North America

Conductor potential	Function	Conductor label	Color code, if used
-48/-60 V	dc power	L-	blue
0 V, the grounded side of the dc power supply	dc power return battery return, BR conductor	L+	red
grounded (or bonded to ground)	framework ground, framework bonding conductor	FB	green, 50% and yellow, 50%

According to the standard IEC-950, the framework ground or the framework bonding conductors are also known as protective earth. The green and yellow ratio of color for the ground relative to a power cable is nominally 50/50 but must be no less than 30% and no more than 70% for either color.

Table 24
Cable identification, Germany

Signal name	Function	Color code
-48/-60 V	dc power	black (or blue) with tape marked L-
BR	battery return	black (or red) with tape marked L+
FG	frame ground	green and yellow (or black)
LR	logical return	black
-48/-60 V	dc power	black (or blue) with tape marked L-
BR	battery return	black (or red) with tape marked L+

Table 25
Cable identification, United Kingdom

Signal name	Function	Color code
-48 V	dc power	blue
BR	battery return	red (or black if referenced to 0 V)
FG	frame ground	green and yellow
LR	logical return	black

Table 26
Cable identification, Japan

Signal name	Function	Color code
-48 V	dc power	blue
BR	battery return	red
FG	frame ground	black
LR	logical return	black

Grounding the frame in CPE or a CO

With customer premises equipment (CPE) or in a central office (CO), the Passport 15000 or 20000 is grounded to the NEBS 2000 frame (NTRU04) and the frame is grounded to the ground window of the site.



WARNING

Risk of injury or equipment damage by electricity

The frame ground is the protective ground and must have a reliable permanent connection to earth. Do not ground a frame to another frame, especially by “jumping” a wire from frame to frame.


**WARNUNG****Verletzungsgefahr**

Die Erdung des Gestells ist eine Schutzterdung und muß zuverlässig und dauerhaft mit der Netzerde verbunden sein. Bilden Sie keinesfalls eine Kaskadenerdung, das heißt, erden Sie nicht ein Gestell am anderen.

The methods of grounding to the ground window vary. However, in all methods at the point where a C-tap is to ground a cable between the NTRU04 frame and the ground window cable, ensure the cable runs from the frame to the tap in the same direction as the flow of ground. That is, the end of the cable at the tap points in the direction of ground flow. The minimum cables size to ground the frame is 6 AWG (13.3 mm²). The “S” curve of the cable at rest is not to exceed a 90-degree bend. Ensure the cable labeling remains at both ends of the cable. See the figure “Grounding an NTRU04 frame to a ground window” (page 140).

With the polyvalent (A0834143) and ETSI (A0834143) power-and-ground assembly, the mounting bracket covers the normal grounding points on the rear of the NTRU04 frame. The alternative grounding point to the frame from the site ground window is at the top front of the NEBS 2000 frame on the silvery grounding strip.

Figure 14
Grounding an NTRU04 frame to a ground window



Grounding when not using a NEBS 2000 frame

Normally, the bonding of the metalwork of the hardware parts to the frame (with or without the conductive tape on the uprights) by the self-tapping bolts (provided), grounds the hardware to the frame. Ground your Passport 15000 or 20000 by this method provided the frame is appropriately grounded to the site's ground window. The frame ground to the site's grounding window is identified by the universal ground icon across the top of the NEBS 2000 frame (NTRU04).

When installing the BIP in a frame other than an NTRU04 (that is, lacking conductive tape or is entirely painted), a secondary grounding point is provided in the BIP chassis. There are 2 studs at the rear lower right of the chassis. Ground the BIP chassis to the frame reliably by firmly attaching a ground of minimum size 6 AWG cable E/W (13.3 mm²) between the studs and a common grounding point. Use two straight 2-hole lugs, one to the chassis and the other to the frame ground bonding point. The stud nuts on the chassis are number 10-32 unc and are included with washers on the studs. There is no metric equivalent to the stud nuts. Use star washers between the lug and the frame. Do not overtighten the nuts.

Grounding when using ac rectifiers as a power source

When installing a system of ac rectifiers such as an Astec MFA150 power system to provide dc power to the Passport 15000 or 20000, ground the frame and the framework to the same ground window. Also, ground both by similar methods, for example, as described in "Grounding the frame in CPE or a CO" (page 138).

For more information on grounding an MFA150, see 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.

Prerequisites to installing dc power input cables

Installing dc power cables for the BIP means routing the cables from the power source to the BIP or the frame's floor footprint without connecting either end. Dressing the cables onto the NEBS 2000 frame and connecting to the BIP or power-and-ground cable assembly is handled in the appropriate sequence by an installation task flow. Because of the lead time recommended to schedule a qualified electrician, the task flows accommodate installing the cables before the switch hardware arrives.

Each input stud at the rear of the BIP is provided with a narrow-tongued 2-hole 90-degree offset 2/0 AWG lug (part number A0757391) underneath a clamped insulating boot. The boot prevents direct access to the power connections and potential shorting between adjacent connections. The power input cables must have been installed directly to the studs on the BIP or to a power-and-ground assembly that relays the feeds to the BIP.



CAUTION

Risk of equipment damage by reversed polarity

Use the plus (+) and minus (-) symbols on the rear of the breaker interface panel (BIP) to ensure that the polarity of each A and B battery (-48/-60 V dc) and battery return for the input power feeds is correct. When powering up the BIP, reversed polarity will damage circuits inside it.

When connecting power input cables to the rear of the BIP, you will be connecting to the breaker interface modules (BIMs) on the other side of the BIP backplane. Determine each appropriate connection from the information in the table “Feed codes of the BIP BIMs, rear view” (page 142).

When connecting power output cables from a system of ac rectifiers to the BIP, ensure that the dc power cable connections at the system support the redundant A and B feeds with correct polarity from the BIP. Determine the correct connection pattern and labelling for the system of ac rectifiers from the table “Feed codes of the BIP BIMs, rear view” (page 142).

Table 27
Feed codes of the BIP BIMs, rear view

Position of BIM	At rear of BIM	Label	Output to
left BIM	right pair of studs	A1+	lower shelf
	left pair of studs	A1-	
middle left BIM	right pair of studs	B1+	lower shelf
	left pair of studs	B1-	
(Sheet 1 of 2)			

Table 27 (continued)
Feed codes of the BIP BIMs, rear view

Position of BIM	At rear of BIM	Label	Output to
middle right BIM	right pair of studs	A2+	upper shelf
	left pair of studs	A2-	
right BIM	right pair of studs	B2+	upper shelf
	left pair of studs	B2-	
(Sheet 2 of 2)			

Power cable specifications

Power cable specifications vary according to:

- the amount of power required to safely operate a fully or partially provisioned Passport 15000 or 20000 switch
- the power cable limitations of the source of dc power from the site's batteries or from a system of ac rectifiers
- the distance between legs and endpoints of the power source
- the electrical codes of the country of installation

With a Passport 20000, the breakers to the shelves on the breaker interface panel (BIP) increase from 20 A to 25 A. Apply the same criteria for voltage drop, cable size, and cable specification as a regular Passport 15000 with the 20 A breakers.

Refer to the cabling section that applies to your installation of power cables:

- “Power cable specifications for a fully provisioned shelf” (page 144)
- “Power cable specifications for a partially provisioned shelf” (page 146)
- “Power cable specifications with a polyvalent assembly” (page 147)
- “Power cable specifications with an ETSI assembly” (page 149)
- “Power cable specifications when using ac rectifiers” (page 152)

Power cable specifications for a fully provisioned shelf

The cable specifications for the input power cables terminating at the breaker interface panel (BIP) must be fed by 1/0 AWG (53.49 mm²) cables for each fully provisioned Passport 15000 or 20000 switch. The operating company must provide the power cables up to the BIP. The cable size between the BIP and the power plant or the BIP and a branch cable must be very flexible 1/0 AWG cable (such as welding cable). Use cable or an equivalent with these recommended wire specifications from the National Wire and Cable Standard:

- 1/0 AWG gauge of Super Flex cable has 2646/34 strands and strand size with a conductor diameter of 0.437 inches or 96.77 mm²
- 1/0 AWG gauge of Welding cable has 1045/30 strands and strand size with a conductor diameter of 0.431 inches or 94.17 mm²

Use the indicated gauge and especially the flexibility of the power cables for safe, easier, and appropriate installation. Manufacturers of 1/0 AWG (53.49 mm²) cable typically have a different number of strands in the cable, which affects how easily the cable can be bent (flexed) and whether a lug for 1/0 AWG can be easily crimped onto the end of the cable. Because the inside diameter of a 1/0 AWG lug barrel is 0.39 inches (1 cm) and for a 2/0 AWG (67.43 mm²) lug is 0.45 inches (1.1 cm), 2/0 AWG 90-degree offset narrow-tongued 2-hole lugs (part number A0757391) are typically included with the BIP. Also, when the insulation is stripped from the cable, the strands tend to splay slightly and the 1/0 AWG lug is awkward to fit onto the end.

At the rear of the BIP, each input power connection has two studs to ensure a safe installation of the power cables. The top stud of each pair carries the power. The bottom stud prevents rotation of the lug from the weight of the power cable. With secure fastening of a 90-degree (right-angled) 2-hole lug, arcing and rotation are prevented.

At the rear of the BIP, each A and B feed connection is identified as positive (+) for the battery return or negative (-) for the battery (-48 V/-60 V dc). Each connection is also provided with an insulating boot covering a 90-degree offset narrow-tongued 2-hole lug for the 1/0 AWG flexible cable. The provided lug is size 2/0 AWG to accommodate differences in the thickness of 1/0 AWG cable by different manufacturers.

Note: The polyvalent or ETSI power-and-ground assembly accommodates power non-Super Flex input cables from No. 6 AWG (13.3 mm²) up to 2 AWG (33.62 mm²). Provided your local electrical codes accept the equipment, using the assembly to accommodate power input cabling at the BIP can be a much simpler installation method at your site. See “Power cable specifications with a polyvalent assembly” (page 147) or “Power cable specifications with an ETSI assembly” (page 149).

If, according to the National Electrical Code (NEC), 100 A protectors are being used between the site power source and the BIP, and the room’s ambient temperature can reach 50 degrees Celsius (122 degrees Fahrenheit), a cluster of 8 power conductors running over 2 feet with a cable insulation rating of 90 degrees Celsius (194 degrees Fahrenheit) is required for a 97.58 A current. These specifications are met by using 1/0 AWG cable.

All power cables must meet the requirements of the country of installation. For example, use cable with a rating such as CSA or UL VW-1. For the ratings, see the table “North American ratings for cable” (page 145).

Table 28
North American ratings for cable

Canada	US	Description
FT-4	UL 1581	general installation
FT-4	UL 1666	riser
FT-6	UL 910	plenum

Additional information about cables used in a setup with an ac rectifier is included in “Power cable specifications when using ac rectifiers” (page 152).

**CAUTION****Risk of damage to equipment by reversed polarity**

Use the plus (+) and minus (-) symbols on the rear of the breaker interface panel (BIP) to ensure that the polarity of each A and B battery (-48/-60 V dc) and battery return for the input power feeds is correct. When powering up the BIP, reversed polarity will damage circuits inside it.

Power cable specifications for a partially provisioned shelf

A partially provisioned shelf means some card or module slots are empty, that is, covered by a filler (blank). The cable specifications for the input power cables terminating at the breaker interface panel (BIP) can be less than the recommended 1/0 AWG (53.49 mm²) cables for a partially provisioned Passport 15000 or 20000 switch.

The operating company must provide the power cables up to the BIP. The cable size between the BIP and the power plant or the BIP and a branch cable must be determined from the power consumption of your shelf. To calculate your minimum power consumption, and accommodate the addition of powered parts after the initial installation, see “Power distribution and consumption” (page 125).

At the rear of the BIP, each input power connection has two studs to ensure a safe installation of the power cables. The top stud of each pair carries the power. The bottom stud prevents rotation of the lug from the weight of the power cable. With secure fastening of a 90-degree (right-angled) 2-hole lug, arcing and rotation are prevented.

At the rear of the BIP, each A and B feed connection is identified as positive (+) for the battery return or negative (-) for the battery (-48 V/-60 V dc). Each connection is also provided with an insulating boot covering a 90-degree offset narrow-tongued 2-hole lug intended for the 1/0 AWG flexible cable. When using a gauge of less than 1/0 AWG cable, you must replace the provided lugs with ones that have an appropriately sized lug barrel with the same 2-hole size and spacing on a 90-degree offset narrow-tongued lug. The original insulation boots are used for any cable size less than 1/0 AWG.

Note: The polyvalent or ETSI power-and-ground assembly accommodates non-Super Flex power input cables from No. 6 AWG (13.3 mm²) up to 2 AWG (33.62 mm²). Provided your local electrical codes accept the equipment, using the assembly to accommodate power input cabling at the BIP can be a much simpler installation method at your site. See “Power cable specifications with a polyvalent assembly” (page 147) or “Power cable specifications with an ETSI assembly” (page 149).

If, according to the National Electrical Code (NEC), less than 100 A protectors are being used between the site power source and the BIP, and the room’s ambient temperature can reach 50 degrees Celsius (122 degrees Fahrenheit), a cluster of 8 power conductors running over 2 feet with a cable insulation rating of 90 degrees Celsius (194 degrees Fahrenheit) is required. These specifications must be met by whatever cable you plan to install.

All power cables must meet the requirements of the country of installation. For example, use cable with a rating such as CSA or UL VW-1. For the ratings, see the table “North American ratings for cable” (page 145).

Additional information about cables used in a setup with an ac rectifier is included in “Power cable specifications when using ac rectifiers” (page 152).

**CAUTION****Risk of damage to equipment by reversed polarity**

Use the plus (+) and minus (-) symbols on the rear of the breaker interface panel (BIP) to ensure that the polarity of each A and B battery (-48/-60 V dc) and battery return for the input power feeds is correct. When powering up the BIP, reversed polarity will damage circuits inside it.

Power cable specifications with a polyvalent assembly

When the power-and-ground setup of a Passport 15000 or 20000 uses the optional polyvalent assembly, the assembly is installed between the power source cables and the breaker interface panel (BIP). See the figure “Polyvalent power-and-ground assembly A0834143” (page 149).

The polyvalent hardware must be installed on the NEBS 2000 frame on site as an optional kit (part number A0834143). All of the criteria in “Power architecture” (page 120) still apply.


The power cables in the polyvalent hardware kit that connect the bottom of the terminal blocks to the BIP studs are provided. The difference with polyvalent power cables is that the power cable for this leg is size 2/0 AWG (67.43 mm²) Super Flex excelene (manufactured by Essex). The cable is rated R +105C 600V and is cut to measure at 21 cm (8.3 inches). The narrow-tongued 2-hole 90-degree offset 2 AWG lugs used to fasten the power cables to the BIP are included.

When connecting the power input cables to the terminal blocks, bared cable is fastened directly to each block, therefore no special lugs are required.

Note: The polyvalent power-and-ground assembly can accommodate power input cables from No. 6 AWG (13.3 mm²) up to 2 AWG (33.62 mm²), including non-Super Flex.

The NEBS 2000 frame is normally grounded to the site window through the the silvery grounding strip at the top of the frame. The polyvalent assembly bracket covers the strip. When using the polyvalent assembly, the grounding point between the frame and the site ground window must be on the silvery strip at the top front of the frame.

Figure 15
Polyvalent power-and-ground assembly A0834143



Power cable specifications with an ETSI assembly

When the power-and-ground setup of a Passport 15000 or 20000 uses the hardware that complies with the European Telecommunications Standards Institutes (ETSI), the hardware assembly is installed between the power source cables and the breaker interface panel (BIP). See the figure “ETSI power-and-ground assembly A0834149” (page 151).

The ETSI hardware must be installed on the NEBS 2000 frame on site as an optional kit (part number A0834149). All of the criteria in “Power architecture” (page 120) still apply.


The power cables in the ETSI hardware kit that connect the bottom of the terminal blocks to the BIP studs are provided. The difference with ETSI power cables is that the power cable for this leg is size 1/0 AWG (53.49 mm²) Super Flex excelene (manufactured by Essex). The cable is rated R +105C 600 V and is cut to measure at 21 cm (8.3 inches). The narrow-tongued 2-hole 90-degree offset 2 AWG lugs used to fasten the power cables to the BIP are included.

When connecting the power input cables to the terminal blocks, bared cable is fastened directly to each block, therefore no special lugs are required.

Before installing the ETSI power-and-ground assembly, the grounding point between the frame and the site ground window must be on the silvery strip at the top front of the frame. The ground cables in the ETSI hardware kit that connect each middle terminal block to the grounding strip across the top rear of the NEBS 2000 frame are also provided. Typically, the grounding cable is 6 AWG (13.3 mm²) with a matched straight 2-hole lug.

Note: The ETSI power and ground assembly can accommodate power input cables from No. 6 AWG (13.3 mm²) up to 2 AWG (33.62 mm²), including non-Super Flex.

Figure 16
ETSI power-and-ground assembly A0834149



Power cable specifications when using ac rectifiers

When the power and ground setup of a Passport 15000 or 20000 uses a system of ac rectifiers as a power source, such as an Astec MFA150 power system, the size of the dc cables between the rectifier and the rear of the breaker interface panel (BIP) may be different from a rectifier or a dc power source. For example, the MFA150 without batteries provides up to 50 A, while a dc site plant with batteries can provide up to 100 A. Refer to “Power architecture” (page 120).

When the system of ac rectifiers is the MFA150, cable kit AP5C90FJ contains electrical hardware to connect the MFA150 to the BIP to power one or two Passport 15000 or 20000 switches. The kit includes:

- 100 m (328 ft) of No. 2 AWG (33.62 mm²) cable, to be cut equally for the input cables
- for the MFA150, five 1-hole 2 AWG lugs and six 2-hole 5/8-inch lugs
- for the BIP, ten 2-hole 90-degree offset narrow-tongued lugs, which includes two spares

Although the insulation boots that cover the power input studs on the BIP are 1/0 AWG (53.49 mm²), the connection procedure for cables to the rear studs address thinner cables passing through the boots.

When the ac rectifier setup is installed with an optional power-and-ground assembly, either the polyvalent kit (part number A0834143) or the European Telecommunications Standards Institutes (ETSI) kit (part number A0834149), the size of the dc cables between the rectifier and the terminal blocks of the power-and-ground assembly are calculated according to the distance between endpoints. The kit also provides the power input cables between the terminal blocks and the BIP. When connecting the power input cables to the terminal blocks, bared cable is fastened directly to each block. For more cable information, refer to “Power cable specifications” (page 143).

With a system of ac rectifiers, the guidelines for voltage drop are the same as for both the ac and dc methods of cabling except for the Note on overprotection. Refer to “Allowing for voltage drop over distance” (page 133).

**CAUTION****Risk of service interruption**

An MFA150 power system of ac rectifiers is rated as class A equipment, therefore it requires an appropriately controlled environment for your site setup.

For more information on installing power cables for the MFA150 power system, see the Astec document 167-9021-133 *Advanced Power Systems MFA150 Modular Front Access Power System Detailed Installation Guidelines and Procedures Manual*.

Power and ground cabling overview

The NEBS 2000 frame in which one or two Passport 15000 or 20000 switches are mounted has the versatility to use either top or bottom cable routing for the power feeds and the top frame ground (labeled with the standard icon). A -48/-60 V dc power source is required. It must be reliably connected to ground and must be electrically isolated from the ac source. Before you proceed, review the following information and procedures:

- “Grounding topologies” (page 153)
- “General grounding rules for IBN and CBN topologies” (page 156)

Grounding topologies

There are three grounding topologies to choose from depending on your location and requirements:

- Isolated bonding network (IBN), which is used in North America and is isolated from the floor (see the figure “IBN grounding” (page 154))
- Common bonding network (CBN), which is used in North America (see the figure “CBN grounding” (page 155))
- Mesh-BN, which is the standard for the European Telecommunications Standards Institutes (ETSI). The requirements for this grounding topology are similar to CBN, except that each battery return (BR) must be bonded to the frame ground (FG).

Figure 17
IBN grounding





Figure 18
CBN grounding



PPT 2820 029 AA

General grounding rules for IBN and CBN topologies

The recommended configuration for IBN bonding topologies is that the power feed only IBN equipment. The following rules apply:

- There must be only one single point ground (SPG) for all equipment fed from the power plant.
- All communication equipment must be within one floor of the system SPG.
- Insulate the battery return (BR) bar of the power plant from the power plant framework.
- The BR must be connected to the SPG by a battery return reference conductor.
- The framework of the power plant must be bonded to the FGB of the floor where the power plant is located.
- Grounding conductors must not carry current under normal operating conditions.

If both IBN and CBN equipment must receive power from a common power plant, then the configuration must be restricted to applications such as small CB entities co-located with an IBN switch. In this case, the following rules apply:

- The SPG for all IBN equipment fed from the power plant must be a non-current carrying section of the insulated battery return bar of the power plant.
- All IBN equipment must be within one floor of the power plant.
- The battery return bar of the power plant must be insulated from the framework and bonded to the FGB.
- The framework of the power plant must be bonded to the FGB.

For an European Telecommunications Standards Institutes (ETSI) topology using mesh-BN, the optional hardware kit is A0834149, which can be ordered with the Passport 15000 or 20000 or added later. These rules apply:

- the frame ground (FG) of each cabinet is bonded to the local CBN
- the logical return (LR) is bonded to the FG at each cabinet

- the battery return (BR) is bonded to the local CBN by multiple connections, typically at each power distribution cabinet (for example, a PDC)

Grounding the frame and communication links

This section describes the grounding requirements for a NEBS 2000 frame and communication links. The topics described in the section are:

- “Grounding a Passport” (page 157)
- “Grounding the communication links” (page 157)

Grounding a Passport

Each frame is grounded with a minimum No. 6 AWG cable (13.3 mm²) and a 2-hole lug. The 2-hole lug is installed in a position on the top of the frame, usually at the front where the universal grounding icon is located. The No. 6 AWG cables are C-tapped into a No. 0 AWG FG collector cable.

With the power-and-ground setup for either the polyvalent (A0834143) or the ETSI (A0843149), the frame ground cable must be fastened at the top front of the frame.

With a NEBS 2000 frame, the frame ground is bonded to the metalwork of the BIP through conductive tape on the frame’s uprights and the frame mounting brackets and bolts.

Grounding the communication links

In a system with an isolated bonding network (IBN) grounding topology, care must be taken that communication cables going into and out of the system do not violate the topology. To prevent this, the links must be isolated.

There are two main concerns associated with signal links between IBN systems and other equipment:

- operational concerns, when signals are referenced to different ground potentials (possible signal errors or damages to circuitry, or both)
- safety concerns, when metallic connection allows contact between different ground potentials (possible hazard)

Potential differences can occur when signals and shields, or both, are connected to different ground references. This requires specific installation measures to offset any possible hazards or violation. There are three main types of communication cables used in the Passport 15000 or 20000 system: fiber optic cables, shielded twisted-pair, and coaxial cables.

Chapter 5

Standards and compliance considerations

Each Passport 15000 or 20000 complies with North American and international regulatory safety requirements for the handling and the installation of equipment. The prerequisite standards is ITU-T K.27 (Bonding Configurations and Earthing Inside a Telecommunication Building).

Note: Some warnings and cautions in the Passport 15000 or 20000 documentation suite appear in German. This complies with requirements for VDE (Verband Deutscher Elektrotechniker).

The standards and compliances that apply to each type of FP are included with the description of each FP type in 241-5701-615 *Passport 7400, 15000, 20000 FP Configuration Reference*.

The other standards are listed in:

- “Product safety/regulatory” (page 160)
- “Grounding standards” (page 161)
- “Powering standards” (page 161)
- “Electromagnetic compatibilities” (page 162)
- “Acoustic noise compliance” (page 163)
- “Interconnect compliance” (page 163)
- “Quality compliance” (page 163)
- “Material and manufacturing” (page 163)
- “Other standards” (page 163)

Product safety/regulatory

Passport 15000 or 20000 meets the following safety/regulatory requirements:

- Telcordia GR-1089-CORE, GR-63-CORE
- FDA 21 CFR Parts 1000 and 1040 for laser products
- IEC 825
- Nortel Networks corporate safety standards 9001

In North America, UL and CSA specifications apply to an input of -48 V dc, wherein the battery return (BR) and the logical return (LR) are properly grounded. The frame ground (FG) and LR are grounded at the shelf and at the ground window.

The BR and the FG/LR are tied together at the ground window.

Passport 15000 or 20000 was tested to or verified by CSA for North America (Canada and USA) to CSA C22.2 no. 950/UL 1950, 1995.

Passport 15000 or 20000 was tested to or verified using CB reports for international markets according to:

- EN 60950
- IEC 60950 (formerly IEC 950) 1991, 2nd ed., A1:1992, A2:1993, A3:1995, and A4:1997
- CENELEC European Norm EN60950 1992 2nd ed., A1:1993, A2:1993, A3:1995, and A4:1997
- CENELEC EN60825
- AS/NZS 3260

Passport 15000 or 20000 was tested to or verified by VDE to:

- EN 60950
- VDE 0805

Grounding standards

The references for grounding standards are:

- CSA 22.4, (Canadian Electrical Code)
- ETSI EE-2002 (Earthing and Bonding of Telecommunication equipment in Telecommunication Centers)
- ETSI PRETS 300 253 (Earthing and Bonding of Telecommunication equipment in Telecommunication Centers)
- GR 1089 CORE for grounding and bonding
- NFPA70 (US National Electrical Code)
- REA Telecom Engineering and Construction Manual, section 810
- TPH 2253, Telecom Australia (High Ohmic Power and Earthing Guidelines)
- TP01115(U), (Telecom Australia)
- TR-NWT-000295, Telcordia Technical reference, isolated Ground planes: Definition and Application to Telephone Central Offices, July 1992

Powering standards

The references for powering standards are:

- ANSI T1.315-1994, (North American Telcos), Voltage Levels for DC Powered Equipment Used in the Telecommunications Environment, May 1994
- BTR2511, issue 3, British Telecom Requirements for Telecommunication Power Requirements
- DS8171, Issue 2, 60 Hz and -48 V dc Power for DC Powered Telecommunication Equipment, Bell Canada
- ETS 300 132, Draft, Power Supply Interface at the input to Telecommunications Equipment (ETSI)
- FTZ 19, Issue 1, German Telecom Power Requirements (Deutsches Bundesposte Telekom, Germany)

- TELEBRAS 240-500-700, General Specifications for DC Powered Telecommunication Equipment, Brazil
- TP00344B, Spec 1550, Issue 1, Telecom Australia / Power Interface Standards

Electromagnetic compatibilities

The references for electromagnetic compatibilities are as follows.

Electrical fast transient

EN 300-386-2

Electrostatic discharge (ESD)

GR-1089-CORE

EN 300-386-2

Electromagnetic emissions

FCC Part 15B class A

EN 55022 (CISPR 22 class B)

ETSI 300-386-2

GR-1089-CORE

IECS 003



WARNING

Risk of radio interference

Passport 15000 is a class A product. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.



WARNUNG

Radioempfangstörungsgefahr

Passport 15000 ist ein Klasse A Produkt. In Privathaushalten kann es Störungen beim Radioempfang verursachen. In einem solchen Fall muss der Eigentümer eventuell entsprechende Maßnahmen für die Behebung der Empfangsstörung ergreifen.

Electromagnetic immunity (EMI)

EN 55022

EN 300-386-2

GR-1089-CORE

Acoustic noise compliance

Passport 15000 or 20000 meets:

- OSHA 1910.9

Interconnect compliance

Passport 15000 or 20000 meets:

- these ITU standards for interconnect compliance:
 - G.707
 - G.825
 - G.957
- CTR 24 for the E3 metallic interfaces
- ACA TS026, as required
- BAKOM 786 prTA, as required

Quality compliance

Passport 15000 or 20000 meets Nortel Networks corporate quality standards.

Material and manufacturing

Passport 15000 or 20000 meets the material and manufacturing standards of GR-00078.

Other standards

Much of Passport 15000 or 20000 is manufactured with plated metals to ensure no rusting or degradation of ground contact. All non-plated metallic surfaces are painted.


Astec MFA150 standards and compliances

When using an MFA150 power system of rectifiers to provide dc power for the Passport 15000, refer to the standards and compliances listed in Astec's document 167-9021-102 *Advanced Power Systems MFA150 Modular Front Access Power System Description, Operation and Maintenance User Manual*.

Appendix Grounding topologies

Grounding topologies for telecommunications equipment are usually one of three types of bonding networks (BN): mesh, mesh-isolated, and star-IBN isolated. The different types of grounding networks from the International Telecommunications Union standard ITU TS K.27 are shown by the figures “Mesh-BN bonding network” (page 166), “Mesh-IBN isolated bonding network” (page 167), and “Star-IBN isolated bonding network” (page 168).


Figure 19
Mesh-BN bonding network



A bonding network in which all associated switch (SW) frames, racks, and cabinets, and usually, the dc power return conductor, are bonded together as well as at multiple points to the common bonding network (CBN). Consequently, the Mesh-BN augments the CBN.

PPT 2819 055 AA


Figure 20
Mesh-IBN isolated bonding network



A type of IBN in which the components of the IBN (for example, equipment frames) are interconnected to form a mesh-like structure. This may, for example, be achieved by multiple interconnections between cabinet rows, or by connecting all equipment frames to a metallic grid (a bonding mat) extending beneath the equipment. The bonding mat is, of course, insulated from the adjacent CBN. If necessary the bonding could include vertical extensions, resulting in an approximation to a Faraday cage. The spacing of the grid is chosen according to the frequency range of the electromagnetic environment.

PPT 2819 056 AA

Figure 21
Star-IBN isolated bonding network



Passport 15000, 20000 Site Requirements and Preparation Guide

Release 5.2

Copyright © 2004 Nortel Networks.
All Rights Reserved.

NORTEL NETWORKS, the globemark design, the NORTEL NETWORKS corporate logo, and Passport are trademarks of Nortel Networks.

ADC is a registered trademark of ADC Telecommunications, Inc.
AMP, MATE-N-LOK, and Z-PACK are trademarks of AMP of Canada, Ltd.

Astec, Helios, MFA150, and Advanced Power Systems are trademarks of Astec Advanced Power Systems.

EdgeLink is a trademark of Telco Systems.

VT100 is a trademark of Digital Equipment Corporation.

Publication: 241-1501-205

Document status: Standard

Document version: 5.2S2

Document date: February 2004

Printed in Canada

