

>THIS IS **THE WAY**

>THIS IS **NORTEL**

Nortel Multiservice Switch 7400/15000/20000

Operations: Multiprotocol Label Switching

NN10600-445

Document status: Standard
Document issue: 7.1S1
Document date: October 2005
Product release: PCR7.1 and up
Job function: Operations
Type: NTP
Language type: U.S. English

Copyright © 2005 Nortel.
All Rights Reserved.

NORTEL, the globemark design, and the NORTEL corporate logo are trademarks of Nortel.



Contents

What's new	5
MPLS configuration	6
RSVP-TE software installation	8
LER configuration in an RSVP-TE network	10
Configuring the Router and Primary loopback	12
Configuring the Router for RSVP-TE	14
Configuring the RSVP-TE interface on GigE media	15
Modifying the RSVP-TE timers	17
Configuring the RSVP-TE bandwidth allocator	20
LSP configuration on the source LER	22
Configuring the Mpls component	24
Configuring RSVP-TE LSP tunnels	25
Customizing an RSVP-TE LSP	26
Configuring the explicit route	28
Configuring a reachable address for the LSP	30
Configuring a standby RSVP-TE LSP and its subcomponents	31
Monitoring and troubleshooting RSVP-TE	33
Monitoring RSVP-TE network connectivity	35
Monitoring LSP setup	37
Monitoring LSP datapath	39
Displaying information on LSPs	41
Locking and unlocking an LSP	43
Locking and unlocking an RsvpTelf	44
Supporting information for monitoring and troubleshooting RSVP-TE	46
Identifying LSP failures at the source	46
RSVP-TE LSP path tracing	49
RSVP-TE Signaling Statistics	50
Transport Statistics	59
MPLS overview	61
MPLS technology	61



Implementation of MPLS in a Multiservice Switch networks	62
Benefits of MPLS	63
MPLS operation	63
At the edge of the network	64
In the network core	65
In explicit routes	65
Label switched paths (LSPs)	66
Creation of LSPs	66
LSP recovery	70
Considerations for signaled LSPs	70
Resource reservation protocol for LSP tunnels	70
MPLS on Multiservice Switch nodes	72
MPLS using GigE media	72
Traffic engineering with MPLS	72
MPLS QoS	73

Procedure conventions

75

Operational mode	75
Provisioning mode	76
Activating configuration changes	76



What's new

There were no new features added to this document.

Other changes made to this document include the following:

Attention: To ensure that you are using the most current version of an NTP, check the current NTP list in NN10600-000 *Nortel Multiservice Switch 7400/15000/20000 What's New*.

- Updated [LER configuration in an RSVP-TE network \(page 10\)](#) to provide details on configuring DiffServ for the RSVP-TE signaling messages.




MPLS configuration

Configure multiprotocol label switching (MPLS) to set up a label-swapping networking technology that forwards packet traffic over multiple underlying layer-2 media (layer-2 media as defined by the Open Systems Interconnection (OSI) reference model).

MPLS configuration tasks

This task flow shows the sequence of procedures you perform to configure MPLS. To link to any task, go to [MPLS configuration task navigation \(page 7\)](#).

MPLS configuration tasks



MSS 3453 001 AA



MPLS configuration task navigation

- [RSVP-TE software installation \(page 8\)](#)
- [LER configuration in an RSVP-TE network \(page 10\)](#)
- [LSP configuration on the source LER \(page 22\)](#)
- [Monitoring and troubleshooting RSVP-TE \(page 33\)](#)



RSVP-TE software installation

Install resource reservation protocol for traffic engineered LSP tunnels (RSVP-TE) to enable explicit routing in MPLS core networks. Before you can configure the RSVP-TE network, you must install the RSVP-TE software on GigE trunk card.

Prerequisites

- For more information about installing and configuring software, see NN10600-270 *Nortel Multiservice Switch 7400/15000/20000 Software Installation*.
- GigE Trunk cards must be provisioned and validated to the RSVP-TE feature specification.

Procedure steps

Step	Action
1	Add a logical processor type for RSVP-TE. add Sw Lpt /<lpt_name>
2	Set the LPT feature list to include <i>mplsRsvpTe</i> , <i>ip</i> , and <i>atmMpe</i> . set Sw Lpt /<lpt_name> featureList mplsRsvpTe ip atmMpe
3	Set a logical processor to the FP. set Lp /<n> logicalProcessorType Sw Lpt /<lpt_name>
4	Activate the configuration changes.

--End--




Variable definitions

Variable	Value
<lpt_name>	is the name of the lpt and is a mnemonic (for example, mpls_lp).
<n>	is the LP number for the FP.

Procedure job aid

RSVP-TE LER software installation component hierarchy






LER configuration in an RSVP-TE network

Configure the label edge router (LER) in an RSVP-TE network.

LER configuration in an RSVP-TE network procedures

This task flow shows you the sequence of procedures you perform to configure the LER in an RSVP-TE network. To link to any procedure, go to [LER configuration in an RSVP-TE network procedure navigation \(page 11\)](#).

LER configuration in an RSVP-TE network procedures



MSS 3453 004 AB



LER configuration in an RSVP-TE network procedure navigation

- [Configuring the Router and Primary loopback \(page 12\)](#)
- [Configuring the Router for RSVP-TE \(page 14\)](#)
- [Configuring the RSVP-TE interface on GigE media \(page 15\)](#)
- [Modifying the RSVP-TE timers \(page 17\)](#)
- [Configuring the RSVP-TE bandwidth allocator \(page 20\)](#)
- Optionally, configure Differentiated Services for the RSVP-TE signaling messages exchanged with neighbors. For information on configuring DiffServ domain on the *Router* component, see NN10600-809 *Nortel Multiservice Switch 7400/15000/20000 Layer 3 Traffic Management Configuration*.



Configuring the Router and Primary loopback

Configure the Router's mandatory instance of loopback media with the mode set to primary loopback. The address of this component is called the *primaryloopback* address.

Prerequisites

- The Router must be provisioned and configured for OSPF. For information about provisioning Router and OSPF, see NN10600-801 *Nortel Multiservice Switch 7400/15000/20000 IP Configuration Management*.

Procedure steps

Step	Action
1	Add the interface with the loopback address. <code>add -s router/<router_name> interface/<ip_address> loopback</code>
2	Set the netmask. This variable must be 32-bit. <code>set router/<router_name> interface/<ip_address> netmask 255.255.255.255</code>
3	Set the mode to primaryLoopback. <code>set router/<router_name> interface/<ip_address> loopback mode primaryLoopback</code>
4	Add the OSPF broadcast capability to the loopback interface. <code>add router/<router_name> interface/<ipaddress> ospfif</code>

--End--




Variable definitions

Variable	Value
<ip_address>	is a 32-bit address assigned to the interface from which the routing information is derived.
<mask>	is the network mask to be used with the IP address and must be 32-bit.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).

Procedure job aid

Router and primary loopback component hierarchy





Configuring the Router for RSVP-TE

Configure the router for RSVP-TE processing.

Procedure steps


Step	Action
1	Add RSVP-TE under the <i>Router</i> component. <code>add Router/<router_name> RsvpTe</code>
--End--	

Variable definitions

Variable	Value
<router_name>	is name of router and is a mnemonic (for example, RTR1).

Procedure job aid

Router for RSVP-TE component hierarchy





Configuring the RSVP-TE interface on GigE media

Configure the RSVP-TE interface (RsvpTelF) on GigE media.

Prerequisites

- Logical Processor (Lp) must be configured and Ethernet must be configured on the Lp. For more information, refer to NN10600-550 *Nortel Multiservice Switch 7400/15000/20000 Common Configuration Procedures*.

Procedure steps

Step	Action
1	Add the interface and set the netmask. add Router/<router_name> Interface/<ip_address> netmask <netmask>
2	Add the <i>EnetApplication</i> component. add Router/<router_name> Interface/<ip_address> Enet
3	Add an Ethernet port. add Lp/<lp_id> Eth
4	Add the <i>LanApplication</i> component. add La/<la_name> The <i>Framer</i> subcomponent is automatically added.
5	Link the LanApplication to the GigE port. set La/<la_name> Framer interfaceName Lp/<lp_id> Eth/<ether_port>
6	Link to the LanApplication. set Router/<router_name> Interface/<ip_address> Enet linkToEnetIf La/<la_name>
7	Add the RSVP-TE protocol capability under the interface. Add the <i>RsvpTelF</i> subcomponent under the interface. add Router/<router_name> Interface/<ip_address> RSVPTeIF
8	Enable IP routing on the interface (in this case, OSPF). add Router/<router_name> Interface/<ip_address> Ospfif

--End--




Variable definitions

Variable	Value
<ether_port>	is the number of the Ethernet port. The range is 0 to 7.
<ip_address>	is the 32-bit address assigned to the interface from which the routing information is derived.
<la_name>	is the identifier assigned to the LanApplication.
<lp_id>	is the identifier assigned to the GigE LP.
<netmask>	is the identifier netmask for the interface. It determines the subnet prefix length. (For example, 255.255.255.0)
<router_name>	is the name of the route and is a mnemonic (for example, RTR1).

Procedure job aid

RSVP-TE interface on GigE media component hierarchy





Modifying the RSVP-TE timers

Optionally, modify the value of timers to reduce the amount of control traffic (extend values), or to ensure faster convergence time (reduce values).

When the hello exchange under *RsvpTelf* is enabled, the need for frequent soft state refresh is reduced. It is recommended to enable the hello exchange under all *RsvpTelf* throughout the network and to extend the refresh intervals.

Procedure steps

Step	Action
1	Modify the default timer value for the entire shelf including the <i>RsvpTelf</i> components that use the default <i>sameAsRsvpTe</i> value. Set the <i>refreshInterval</i> value. set Router/<router_name> RsvpTe refreshInterval <refreshInterval_value>
2	Set the <i>refreshKeepMultiplier</i> value. set Router/<router_name> RsvpTe refreshKeepMultiplier <refreshKeepMultiplier_value>
3	Set the <i>helloInterval</i> value. set Router/<router_name> RsvpTe helloInterval <helloInterval_value>
4	Set the <i>helloMultiple</i> value. set Router/<router_name> RsvpTe helloMultiple <helloMultiple_value>
5	Set the <i>slewMax</i> value. set Router/<router_name> RsvpTe slewMax <slewMax_value>
6	Modify the timer values for a particular interface. Set the <i>refreshInterval</i> value. set Router/<router_name> Interface/<ip_address> RsvpTeIF refreshInterval <refreshInterval_value>
7	Set the <i>refreshKeepMultiplier</i> value for a particular interface. set Router/<router_name> Interface/<ip_address> RsvpTeIF refreshKeepMultiplier <refreshKeepMultiplier_value>
8	Set the <i>helloInterval</i> value for a particular interface. set Router/<router_name> Interface/<ip_address> RsvpTeIF helloInterval <helloInterval_value>
9	Set the <i>helloMultiple</i> value for a particular interface.



```
set Router/<router_name> Interface/<ip_address>  
RsvpTeIF helloMultiple <helloMultiple_value>
```

- 10 Set the *slewMax* value for a particular interface.

```
set Router/<router_name> Interface/<ip_address>  
RsvpTeIF slewMax <slewMax_value>
```

--End--




Variable definitions

Variable	Value
<helloInterval_value>	is a value that specifies the default interval between hello messages sent by the LSR. The default is 0.5 seconds. A value of disabled indicates the Hello mechanism is not enabled.
<helloMultiple_value>	is a value that specifies the default minimum number of hello intervals that must pass before the RSVP-TE connection is considered to be down. The default is 3.5 seconds.
<ip_address>	is the 32-bit address assigned to the interface from which the routing information is derived.
<refreshInterval_value>	is the interval (R), in the range 1 to 1800, between the generation of successive PATH or RESV refresh messages to the downstream and upstream LSRs respectively. The default value is 30 seconds.
<refreshKeepMultiplier_value>	is the value (K), in the range 1 to 50, used to calculate the lifetime of PATH state blocks (PSBs) and RESV state blocks (RSBs) states, avoiding their premature loss. The default value is 3. The lifetime value is based both on the value of K and R.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).
<slewMax_value>	The limit value, in the range 1 to 200, on how fast the refresh timer (R) can be increased. The ratio of two successive values of R2/R1 must not exceed 1 + SlewMax. The default value is 30%.

Procedure job aid

RSVP-TE timers component hierarchy





Configuring the RSVP-TE bandwidth allocator

Optionally, configure the RSVP-TE bandwidth allocator parameters for the *RsvpTelf*.

Procedure steps

Step	Action
1	Optionally, set the <i>mediaCapacity</i> for the interface depending on the frame size. set router/<router_name> interface/<ip_address> RsvpTeIF mediaCapacity <mediaCapacity_value>
2	Optionally set the <i>reservableFactor</i> to reserve some capacity for other traffic running over the interface. set router/<router_name> interface/<ip_address> RsvpTeIF reservableFactor <reservableFactor_value>
3	Optionally, set the <i>overbookingFactor</i> to allow over or under reservation of bandwidth for the LSPs. set router/<router_name> interface/<ip_address> RsvpTeIF overbookingFactor <overbookingFactor_value>

--End--




Variable definitions

Variable	Value
<ip_address>	is a 32-bit address assigned to the interface from which the routing information is derived.
<mask>	is a 32-bit identifier for the network mask to be used with the IP address.
<mediaCapacity_value>	is the capacity in kbits/s of the underlying media link for the interface. Calculate this value: $\text{<mediaCapacity_value>} = \frac{(125000000 \text{ Bps} \times \text{framesize in bytes})}{(\text{framesize in bytes} + 32) \times 8/1000}$ <p>The default of 860000 kbit/sec is calculated using a frame size of 200 bytes.</p>
<overbookingFactor_value>	is a percentage that specifies the reservable bandwidth that can be made available for the RSVP-TE bandwidth pool. 100% results in allocations using the exact signalled bandwidth. A value less than 100% allows under subscription of the link. A value more than 100% allows over subscription of the link. The default is 100%.
<reservableFactor_value>	is a percentage that specifies the media bandwidth available for LSP tunnel reservations over the interface. A value of 0 prevents any bandwidth allocation for LSPs. A value of 100 allows RSVP-TE exclusive use of available bandwidth. An intermediate value allows sharing of bandwidth between RSVP-TE and other applications. The default is 50%.
<router_name>	is the name of the router and a mnemonic (for example, RTR1).

Procedure job aid

RSVP-TE bandwidth allocator component hierarchy






LSP configuration on the source LER

Configure the label switched path (LSP) on the source LER in an RSVP-TE network.

LSP configuration on the source LER procedures

This task flow shows you the sequence of procedures you perform to configure the LSP on the source LER in an RSVP-TE network. To link to any procedure, go to [LSP configuration on the source LER procedure navigation \(page 22\)](#).

LSP configuration on the source LER task procedures



MSS 3435 006 AA

LSP configuration on the source LER procedure navigation

- [Configuring the Mpls component \(page 24\)](#)



- [Configuring RSVP-TE LSP tunnels \(page 25\)](#)
- [Customizing an RSVP-TE LSP \(page 26\)](#)
- [Configuring the explicit route \(page 28\)](#)
- [Configuring a reachable address for the LSP \(page 30\)](#)
- [Configuring a standby RSVP-TE LSP and its subcomponents \(page 31\)](#)



Configuring the Mpls component

Configure the *Mpls* subcomponent under *Router* component and configure MPLS parameters.

Procedure steps


Step	Action
1	Add the <i>Mpls</i> component as a subcomponent of the <i>Router</i> component. add Router/<router_name> Mpls
2	Optionally, configure the <i>Mpls</i> component parameters. set Router/<router_name> Mpls mplsRoutePreference <route_pref>
--End--	

Variable definitions

Variable	Value
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).
<route_pref>	is an integral value between 1 and 63. A lesser value specifies a higher preference. The default value of 10 indicates MPLS routes are preferred over IP routing. For more details on selecting route preferences, refer to NN10600-801 <i>Nortel Multiservice Switch 7400/15000/20000 IP Configuration Management</i> .

Procedure job aid

MPLS component hierarchy





Configuring RSVP-TE LSP tunnels

Configure RSVP-TE LSP tunnels to direct incoming IP traffic.

Procedure steps


Step	Action
1	<p>Add an <i>Lsp</i> component under the <i>MPLS</i> component with a destination address and set it to be a primary LSP.</p> <pre>add Router/<router_name> Mpls Lsp/<lsp_id> epa <ip_address>, primaryLsp <lsp_id></pre>
--End--	

Variable definitions

Variable	Value
<ip_address>	is the 32-bit host address of the destination.
<lsp_id>	is the identifier assigned to the LSP with a value from 1 - 65535.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).

Procedure job aid

RSVP-TE LSP tunnels component hierarchy





Customizing an RSVP-TE LSP

Customize selected provisionable attributes under the RSVP-TE *Lsp* component. To configure an explicit route, refer to [Configuring the explicit route \(page 28\)](#). To configure a standby LSP, refer to [Configuring a standby RSVP-TE LSP and its subcomponents \(page 31\)](#).

Procedure steps

Step	Action
1	Optionally, set the bandwidth for the <i>Lsp</i> component. <code>set Router/<router_name> Mpls Lsp/<lsp_id> bandwidth <bandwidth></code>
2	Optionally, set the alarmControl on the LSP to generate an alarm. <code>set Router/<router_name> Mpls Lsp/<lsp_id> alarmControl <alarm_severity></code>
3	Optionally, disable the installation of the LSP FEC(s) into the IP routing database. <code>set Lsp/<lsp_id> addToIpRoutingDatabase false</code>

--End--




Variable definitions

Variable	Value
<alarm_severity>	is the severity value that determines if the <i>LSP</i> component will generate alarms when an LSP goes up or down. It also controls the levels that will be generated. The values are none, major, or critical. The default is none.
<bandwidth>	is a value that specifies the bandwidth requirement for an LSP in kbits/s. The value is <i>clsNoBandwidth</i> , <i>nsNoBandwidth</i> , or a numeric value between 1 and 4294967292. Null service is <i>nsNoBandwidth</i> and uses zero bandwidth. Controlled load service is <i>clsNoBandwidth</i> and uses zero bandwidth. Standby LSPs can use <i>sameAsPrimaryLsp</i> to inherit the bandwidth value from the primary LSP. For inter-operability with third party equipment, use <i>clsNoBandwidth</i> when configuring LSPs without bandwidth requirements.
<lsp_id>	is the identifier assigned to the LSP with a value from 1 - 65535.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).

Procedure job aid

RSVP-TE LSP component hierarchy





Configuring the explicit route

Optionally, configure the explicit route by defining the hops within the *Path* component. If you choose to leave the *pathname* attribute unconfigured, IGP will choose the path on a hop-by-hop basis.

Specify the full path or partial path for each hop. The instance values of the Hop components determine the order of the hops along the LSP path.

Procedure steps

Step	Action
1	Add the explicit route by defining the <i>path</i> component. add Router/<router_name> Mpls Path/<path>
2	Add a <i>hop</i> component under the <i>path</i> component. add Router/<router_name> Mpls Path/<path> Hop/<hop>
3	Define the hop details. set Router/<router_name> Mpls Path/<path> Hop/<hop> ipv4Address <hop_address>, ipv4Prefix <hop_prefix>, mode <hop_mode>
4	Optionally, specify each hop along the path. Repeat the above steps to specify each hop along the LSP path.
5	Set the LSP to use the explicit path. set Router/<router_name> Mpls Lsp/<lsp_id> pathname Router/<router_name> Mpls Path/<path>

--End--




Variable definitions

Variable	Value
<hop>	The identifier assigned to each hop for a specific path with a value from 1 to 50.
<hop_address>	is the IP address of the specific hop address.
<hop_mode>	is the mode of the path, either strict or loose.
<hop_prefix>	is a value from 8 to 32 that specifies IP prefix length of the interface.
<lsp_id>	is the identifier assigned to the LSP with a value from 1 to 65535.
<path>	is the identifier assigned to the path with a value from 1 to 10000.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).

Procedure job aid

Explicit route component hierarchy





Configuring a reachable address for the LSP

Configure a reachable address (RA) for the LSP to act as an additional FEC for the LSP. It is installed in the IP routing database when the LSP establishes. An RA can only be configured when the LSP `addToIpRoutingDatabase` attribute is set to true (default).

Procedure steps

Step	Action
1	Define an <i>IpV4ReachableAddress</i> subcomponent to specify the reachable destination IP address of the LSP. Repeat this step to specify each RA. <pre>add Router/<router_name> Mpls Lsp/<lsp_id> RAddr/ <ipv4Address>, <ipv4Prefix></pre>
2	Optionally, do not allow the LSP to subsume the better matched IP addresses in the routing database table (only applies if RA is not a 32-bit address). <pre>set Router/<router_name> Mpls Lsp/<lsp_id> bestMatchOverride false</pre>


--End--

Variable definitions

Variable	Value
<ipv4Address>	is the 32-bit host IP address of the destination or a network address.
<ipv4Prefix>	is the prefix length of the IP address specified in the <ipv4Address>.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).

Procedure job aid

Reachable address for LSP component hierarchy





Configuring a standby RSVP-TE LSP and its subcomponents

Optionally, configure a hot standby RSVP-TE LSP for an existing primary LSP.

For the standby LSP, only the attributes pathname, bandwidth and alarm control can be customized. All other attributes must be set to sameAsPrimaryLsp and will default to the attribute settings specified for the primary LSP. The exception is ipv4EndPointAddress and it must be set to 0.0.0.0.

Procedure steps

Step	Action
1	Add the standby LSP. <pre>add router/<router_name> Mpls Lsp/<lsp_id> primaryLsp <primaryLsp_id>, addToIpRdb SameAsPLsp, bestMatchOverride SameAsPLsp</pre>
2	Link the standby LSP to the primary LSP. <pre>set router/<router_name> Lsp/<primaryLsp_id> standbyLsp <lsp_id></pre>
3	Optionally, customize the standby LSP. Refer to Customizing an RSVP-TE LSP (page 26) .

--End--




Variable definitions

Value	Value
<lsp_id>	is the identifier of the standby LSP with a value from 1 to 65535.
<primaryLsp_id>	is the identifier of the associated primary LSP.

Procedure job aid

Standby RSVP-TE LSP and its subcomponents component hierarchy





Monitoring and troubleshooting RSVP-TE


Monitor and troubleshoot RSVP-TE to determine the source of errors, isolate problems, and maintain operating efficiency.

For general information about maintenance procedures, see NN10600-550 *Nortel Multiservice Switch 7400/15000/20000 Common Configuration Procedures*.

Monitoring and troubleshooting RSVP-TE LSPs procedures

This task flow shows you the sequence of procedures you perform to monitor and troubleshoot RSVP-TE. To link to any procedure, go to [Monitoring and troubleshooting RSVP-TE LSPs procedures \(page 33\)](#).

Monitoring and troubleshooting RSVP-TE procedures



MSS 3535 014 AA



Monitoring and troubleshooting RSVP-TE LSPs procedure navigation

- [Monitoring RSVP-TE network connectivity \(page 35\)](#)
- [Monitoring LSP setup \(page 37\)](#)
- [Monitoring LSP datapath \(page 39\)](#)
- [Displaying information on LSPs \(page 41\)](#)
- [Locking and unlocking an LSP \(page 43\)](#)
- [Locking and unlocking an RsvpTelf \(page 44\)](#)



Monitoring RSVP-TE network connectivity

Monitor network connectivity to determine if a node has RSVP-TE connectivity to its immediate neighbors. To successfully setup LSPs, RSVP-TE requires all nodes along the LSP route to be RSVP-TE capable with adjacent interfaces configured for RSVP-TE.

Procedure steps

Step	Action
1	List all the RSVP-TE neighbors to the node to determine if the node has RSVP-TE connectivity through its interfaces. 1 Router/<router_name> RsvpTe Nbr/*
2	If there is no neighbor listed for a particular interface, display the local <i>RsvpTelf</i> status to determine if the local <i>RsvpTelf</i> status is enabled. d Router/<router_name> If/<local_ip_address> RsvpTeIf
3	If the <i>RsvpTelf</i> OSI <i>adminState</i> is locked, unlock it operationally or provisionally as required. Refer to Locking and unlocking an LSP (page 43)
4	If <i>RsvpTelf</i> OSI state is unlocked, enabled and active and the <i>HelloState</i> is down, display the control statistics under the associated <i>IfStats</i> component. The <i>rsvpDiscards</i> and <i>lastRsvpDiscardInfo</i> attributes indicate if RSVP-TE message are being discarded by the interface and indicate the type of messages being discarded. If <i>RsvpTelf</i> <i>HelloState</i> is disabled, enable it. Refer to LER configuration in an RSVP-TE network (page 10) d Router/<router_name> rsvp ifStats/<local_ip_address>
5	If the statistics indicate the RSVP-TE message is being discarded on receipt or there is no receipt or discards of the message, repeat step 1 to step 4 for the adjacent neighbor.
6	If the <i>RsvpTelf</i> OSI <i>operationalState</i> is disabled, display the <i>interface</i> to determine if the <i>Interface</i> component is down. If the parent <i>Interface</i> is down, refer to NN10600-801 <i>Nortel Multiservice Switch 7400/15000/20000 IP Configuration Management</i> . d Router/<router_name> If/<local_ip_address>
7	If the <i>interface</i> is enabled, display the OSPF neighbor to check the IP routing connectivity. The local <i>RsvpTelf</i> needs knowledge of the IP address of its adjacent remote interface to be fully enabled. If there is no OSPF neighbor, or the status is not full, then there is no IP routing connectivity. For more information on IP routing connectivity to the neighbor, refer to NN10600-801 <i>Nortel Multiservice Switch 7400/15000/20000 IP Configuration Management</i> . d Router/<router_name> Ospf Nbr/<remote_ip_address>
8	If the <i>Interface</i> OSI <i>operationalState</i> is disabled, display the underlying <i>LanApplication</i> component status.



d **La**/**<la_name>**

- 9 Display the GigE port linked to the Logical Processor (Lp) to determine if the ethernet is configured on the Lp. If the ethernet is not enabled, check the physical link connectivity and LP status.

d **Lp**/**<lp_id>** **Eth**/**<ether_port>**


--End--

Variable definitions

Variable	Value
<ether_port>	is a numeric identifier from 0 to 7 for the ethernet port.
<la_name>	is a identifier assigned to the <i>LanApplication</i> component.
<lp_id>	is a numeric identifier assigned to the GigE Lp.
<local_ip_address>	is the unmasked address assigned to the local interface.
<remote_ip_address>	is the unmasked address assigned to the remote neighbor's interface.
<router_name>	is the name of the router and is a mnemonic (for example, RTR1).

Procedure job aid

RSVP-TE network connectivity component hierarchy





Monitoring LSP setup

Monitor label switched path (LSP) setup to confirm establishment or determine point of failure.

To successfully setup LSPs, RSVP-TE requires that all interfaces along the route of the LSP be RSVP-TE capable. In the case of a strictly routed hop, the specified interface must be RSVP-TE capable. If there is no strict route configured for a particular hop, the interface associated with the Interior Gateway Protocol (IGP)-preferred next hop for the LSP, based on the next loose hop or end-point address, must be configured for RSVP-TE.

For more information, refer to [Identifying LSP failures at the source \(page 46\)](#) and [RSVP-TE Signaling Statistics \(page 50\)](#).

Procedure steps

Step	Action
1	Display the <i>LSP</i> component on the source LSR to confirm that the LSP is established. d Router/<router_name> Mpls Lsp/<lsp_id> status
2	If the status is not established, display the <i>lastTearDownReason</i> to determine the cause of the failure. Refer to , “LSP failure reasons,” (page 51) for an explanation of LSP failure reasons. d Router/<router_name> Mpls Lsp/<lsp_id> tearDown
3	For routing related errors, display the forwarding entry for the gateway of the next hop in the LSP route, using the configured hop or end point address. The local Router interface corresponding to the gateway must be configured with an <i>RsvpTelf</i> subcomponent. Refer to Configuring the RSVP-TE interface on GigE media (page 15) for more information about configuring <i>RsvpTelf</i> under an interface. d Router/<router_name> Fwd/*
4	Display RSVP-TE protocol message exchange statistics for the <i>Rtr RsvpTe</i> component. This action identifies the interface associated with the most recent error or discard and displays the statistics reflecting the exchange of other protocol messages, such as PATH, RESV, and hello across the shelf. d Router/<router_name> RsvpTe statistics
5	Display RSVP-TE protocol message exchange statistics for an individual <i>RsvpTelf</i> interface. The response displays the RSVP error or discard statistics if an <i>RsvpTelf</i> exists for the interface. d Router/<router_name> RsvpTe IfStatistics/ <local_ip_address>



- 6 If there is an *RsvpTelf* interface, the PATH or RESV code and value in the RSVP-TE protocol message exchange statistics provide information on the error. Refer to [MPLS RSVP-TE PATH error codes and values \(page 52\)](#) and [MPLS RSVP-TE RESV error codes and values \(page 55\)](#). It may be necessary to check other nodes along the route to find the point of failure.


--End--

Variable definitions

Variable	Value
<local_ip_address>	is the unmasked address assigned to the local interface.
<lsp_id>	is the identifier assigned to the LSP with a value from 1 - 65535.
<router_name>	is any mnemonic (for example, RTR1).

Procedure job aid

LSP setup component hierarchy





Monitoring LSP datapath

Monitor the LSP datapath to determine if the *RsvpTelf* is transmitting and receiving frames over the LSP, as appropriate. On a source node, the *RsvpTelf* transmits frames. On a tandem node, the ingress *RsvpTelf* receives frames and the egress *RsvpTelf* transmits frames. On a destination node, the *RsvpTelf* receives frames.

For more information, refer to [Transport Statistics \(page 59\)](#).

Procedure steps

Step	Action
1	Display the <i>LSP</i> component on the source LSR to confirm that the LSP is established. If is not established, refer to Monitoring LSP setup (page 37) d Router/<router_name> Mpls Lsp/<lsp_id>
2	Display the operational <i>Rtr RsvpTe Tunnel</i> component data associated with the LSP. d Router/<router_name> Mpls Lsp/<lsp_id> tunnelComponentName
3	Display LSP tunnel data for any node along the LSP route. The <i>incomingInterface</i> and <i>outgoingInterface</i> attributes of the <i>Tunnel</i> component identify the <i>Rtr If</i> component addresses that support the <i>RsvpTelf</i> for the ingress and egress LSP connections on the node. d Router/<router_name> RsvpTe Tunnel/ <src_ler_addr>, <dest_ler_addr>, <lsp_id>, <lsp_index>
4	Optionally, use the ping from the source LER (or a previous hop) to send packets over the LSP. ping -cont -p(<fec>) Router/<router_name> icmp
5	Display the send and receive statistics for an <i>RsvpTelf</i> interface to determine if the egress interface is transmitting and the ingress interface is receiving an equal number of frames. The ingress <i>RsvpTelf</i> interface shows increasing Frames and Octets, the egress <i>RsvpTelf</i> interface shows the same number of outFrames and outOctets. d Router/<router_name> If/<local_ip_address> RsvpTeIf
6	If the <i>RsvpTelf</i> interfaces are not transmitting and receiving an equal number of frames, display the <i>Rtr If</i> components to view the frame discards statistics. d Router/<router_name> If/<local_ip_address>
7	If the <i>RsvpTelf</i> interfaces are not transmitting and receiving an equal number of frames and the <i>If</i> statistics do not indicate IP discards, display the <i>LanApplication Framer</i> component to view the frame discards statistics.



d La/<la_name> Framer


--End--

Variable definitions

Variable	Value
<dest_ler_addr>	is the IP address of destination LER (the EPA).
<fec>	is the IPv4 end point address or the reachable address for the LSP.
<lsp_id>	is the identifier assigned to the provisioned LSP with a value from 1 - 6553.
<la_name>	is the identifier assigned to the <i>LanApplication</i> component.
<lsp_index>	is the LSP index number and is internally assigned. It does not correspond to any other visible component.
<router_name>	is the name of the router and a mnemonic (for example, RTR1).
<src_ler_addr>	is the IP address of source LER.

Procedure job aid

LSP datapath component hierarchy





Displaying information on LSPs

To view information on LSPs, display the operational information on LSP component instances and the related operational components.

Procedure steps

Step	Action
1	View operational information on an <i>Lsp</i> component at the source LER, including the tunnel instance. d Router/<router_name> Mpls Lsp/<lsp_id>
2	View the signaled data for the LSP by displaying the associated <i>Rtr RsvpTe Tunnel</i> component. Issue this command at any multiservice switch along the LSP route. d Router/<router_name> RsvpTe Tunnel/<src_ler_addr>, <dest_ler_addr>, <lsp_id>, <lsp_index>

--End--




Variable definitions

Variable	Value
<dest_ler_addr>	is the IP address assigned to the destination LER .
<lsp_id>	is the identifier assigned to the LSP with a value from 1 - 65535.
<lsp_index>	is the LSP index number and is internally assigned. It does not correspond to any other visible component.
<router_name>	is the name of the router and a mnemonic (for example, RTR1).
<src_ler_addr>	is the IP address assigned to the source LER .

Procedure job aid

Displaying information on LSPs component hierarchy





Locking and unlocking an LSP

Lock and unlock an LSP to affect any *Hop* component changes in the *Router Mpls Path* component specified by the *Lsp pathName*. An Lsp can also be locked to switch to a hot standby Lsp or revert to an IP datapath.

Procedure steps


Step	Action
1	Lock a signaled <i>Lsp</i> component instance. <code>lock Router/<router_name> Mpls Lsp/<lsp_id></code>
2	Unlock a signaled <i>Lsp</i> component instance. <code>unlock Router/<router_name Mpls Lsp/<lsp_id></code>
--End--	

Variable definitions

Variable	Value
<lsp_id>	is the identifier assigned to the LSP with a value from 1 - 65535.
<router_name>	is the name of the router and a mnemonic (for example, RTR1).

Procedure job aid

LSP component hierarchy





Locking and unlocking an RsvpTelf

An RsvpTelf can be locked operationally or provisionally to keep it disabled over resets or switchovers. Locking and unlocking an RsvpTelf forces an LSP to use the new MTU value. LSP connections are based on the current media Maximum Transfer Unit (MTU) when the connection is created. Changes to the media MTU after the connection is created are not reflected in the previously established LSPs. To force the LSP to use the new MTU value, disable then enable the *RsvpTelf* component. Disabling the *RsvpTelf* component automatically clears all LSPs under the interface.

Procedure steps

Step	Action
1	Operationally lock the <i>RsvpTelf</i> to disable the <i>RsvpTelf</i> component. lock Router/<router_name> Interface/<ip_address> RsvpTeIf
2	Operationally unlock the <i>RsvpTelf</i> to enable the <i>RsvpTelf</i> component. unlock Router/<router_name> Interface/<ip_address> RsvpTeIf
3	Provisionally lock the <i>RsvpTelf</i> to stay down over resets and switchovers. set Router/<router_name> Interface/<ip_address> RsvpTeIf adminStatus disabled
4	Provisionally unlock the <i>RsvpTelf</i> to revert back to the default status of enabled. set Router/<router_name> Interface/<ip_address> RsvpTeIf adminStatus enabled

--End--




Variable definitions

Variable	Value
<ip_address>	32-bit address assigned to the interface.
<router_name>	is the name of the router and a mnemonic (for example, RTR1).

Procedure job aid

RsvpTelf component hierarchy





Supporting information for monitoring and troubleshooting RSVP-TE

This section contains supporting information for monitoring and troubleshooting on:

- [Identifying LSP failures at the source \(page 46\)](#)
- [RSVP-TE LSP path tracing \(page 49\)](#)
- [RSVP-TE Signaling Statistics \(page 50\)](#)
- [Transport Statistics \(page 59\)](#)

Identifying LSP failures at the source

If the *operStatus* attribute indicates that the LSP is *idle*, the administrator can refer to the *lastTearDownReason* attribute for information on why the LSP has not been established.

, “LSP failure reasons,” (page 51) lists the *lastTearDownReason* attribute values and their meaning. For more information about the error codes associated with the attribute values, refer to [MPLS RSVP-TE PATH error codes and values \(page 52\)](#).

LSP failure reasons

Lsp failure Reasons (lastTearDownReason)	Meaning	Action
rsvpRoutingProblem	There is no outgoing <i>RsvpTeif</i> for the LSP's next hop.	If the <i>Rtr Mpls Lsp pathName</i> is set, check the <i>Hop</i> components for the specified <i>Rtr Mpls Path</i> (particularly the first <i>Hop</i>).
rsvpLocked	The <i>Rtr Mpls Lsp adminState</i> is locked.	Issue command <i>unlock Rtr Mpls Lsp</i> or provisionally set the <i>operationalState</i> to enabled.
rsvpPathSetupTimeout	The PATH message was successfully sent to the next hop, but a label mapping message was not received within the tolerated setup time interval, and no error message is received to report the failure from downstream.	The PATH message was likely discarded along the route of the LSP by a non-RSVP node. Check the downstream nodes for RSVP-TE configuration and protocol messaging statistics.
rsvpLostPeer	The outgoing <i>RsvpTelf</i> has gone down during or following LSP establishment	Check the outgoing <i>RsvpTelf</i> status.

(1 of 4)



LSP failure reasons (continued)

Lsp failure Reasons (lastTearDownReason)	Meaning	Action
rsvpLostLabel	A RESV refresh timeout has occurred following LSP establishment.	Check immediate next hop LSR for cause of failure, verifying RSVP-TE configuration and protocol messaging statistics.
rsvpResourceUnavailable	Internal resource exhaustion on the origination of the LER.	Check the <i>Lp</i> CPU and memory
rsvpSystemError	Local internal processing or database error.	Check local alarms for failures.
rsvpAdminCtrl	There is insufficient bandwidth to satisfy the LSP requirement.	Check the bandwidth availability indicated by the outgoing <i>RsvpTelf availBw</i> attribute and decrease the <i>Lsp</i> bandwidth accordingly, or decrease or remove the other <i>Lsp</i> component to free bandwidth or set the <i>RsvpTelf</i> overbookingFactor higher to allow overbooking. Alternatively, if the <i>RsvpTelf reservableFactor</i> is not set to 100%, increase it as necessary.
rsvpRcvResvTear	A RESV tear is received from downstream following LSP establishment.	Check downstream (likely terminating) LSR for failure that would result in label withdraw.
rsvpRcvUnsupportedStyle	An invalid style received from downstream following LSP establishment.	Check downstream LSR for reason for protocol failure. Reasons such as incorrectly configured for RSVP-TE. For example, configured for classical RSVP rather than RSPV-TE.
rsvpRcvConflictingStyle	A RESV refresh message is received with a different RESV style from that initially received.	Check downstream (likely terminating) LSR for failure that would result in protocol failure.
rsvpRcvErrNotify	A PATH notification error is received from downstream.	Check the <i>Rtr RsvpTe IfStats lastPathErrorInfo</i> attribute for details using the outgoing <i>Rtr If</i> address. Next, check the downstream LSRs for point of failure.

(2 of 4)



LSP failure reasons (continued)

Lsp failure Reasons (lastTearDownReason)	Meaning	Action
rsvpRcvErrRsvpSystem	A PATH system error is received from downstream.	Check the <i>Rtr RsvpTe IfStats lastPathErrorInfo</i> attribute for details using the outgoing <i>Rtr If</i> address. Next, check the downstream LSRs for point of failure.
rsvpRcvErrTrafficCtrl	A PATH traffic control error is received from downstream.	Check the <i>Rtr RsvpTe IfStats lastPathErrorInfo</i> attribute for details using the outgoing <i>Rtr If</i> address. Next, check the downstream LSRs for point of failure.
rsvpRcvErrTrafficCtrlSys	A PATH traffic control system error is received from downstream.	Check the <i>Rtr RsvpTe IfStats lastPathErrorInfo</i> attribute for details using the outgoing <i>Rtr If</i> address. Next, check the downstream LSRs for point of failure.
rsvpRcvErrUnknownObjClass	A PATH unknown object or C-type error is received from downstream; protocol failure on downstream LSR.	Check downstream LSR RSVP-TE configuration; the node sends only standard objects.
rsvpRcvErrUnknownObjCType	A PATH unknown object or C-type error is received from downstream; protocol failure on downstream LSR.	Check downstream LSR RSVP-TE configuration; the node sends only standard objects.
rsvpRcvErrAdminCtrl	A PATH error is received from downstream indicating insufficient bandwidth to satisfy the LSP requirement.	Check the downstream LSRs for bandwidth availability.
rsvpRcvErrPolicyCtrl	A PATH policy control error is received from downstream; protocol failure on a downstream LSR.	Check downstream LSRs for point of failure.
rsvpRcvErrDestPortConflict	A PATH error reporting unmatched destination port number is received.	The switch does not use port numbers. Check downstream LSRs for point of failure.
rsvpRcvErrSendPortConflict	A PATH error reporting unmatched source port number is received.	The switch does not use port numbers. Check downstream LSRs for point of failure.
(3 of 4)		



LSP failure reasons (continued)

Lsp failure Reasons (lastTearDownReason)	Meaning	Action
rsvpRcvErrApi	A PATH API error is received.	Check downstream LSRs for point of failure.
rsvpRcvErrRoutingProblem	A PATH error reporting failure to route the LSP is received; similar to rsvpRoutingProblem but remotely occurring rather than locally.	If the <i>Rtr Mpls Lsp pathName</i> is set, check routes for all addresses in the configured <i>Path Hop</i> components. If the <i>pathName</i> is left empty, check the IP routing entries for the <i>LSP epa</i> address at every hop along the route.
(4 of 4)		

RSVP-TE LSP path tracing


RSVP-TE offers the ability to extend its signaled messages with LSP route information.

The Record Route Object (RRO) can be included in the RSVP-TE signaling messages to provide a record of the LSP route to any LSR along the path. If the Nortel Multiservice Switch is the originating switch, it always includes the RRO in its path label request. At any node along the LSP route, the upstream and downstream hops of an LSP relative to the node can be displayed. On the switch, the component *Rtr RsvpTe Tunnel* displays the RRO. The label used for each segment may be included in the *ResvRRO*.

, “Example of an LSR RSVP-TE LSP trace using RRO,” (page 55) shows a simple four node topology that illustrates the procedure for operationally tracing the LSP path using the RRO information.



Example of an LSR RSVP-TE LSP trace using RRO



RSVP-TE Signaling Statistics

For an RSVP-TE signaled LSP tandeming through the Nortel Multiservice Switch node, the signaling statistics described in the table [MPLS RSVP-TE statistics \(page 51\)](#), provide evidence as to the cause of failure. By monitoring the *Rtr RsvpTe IfStatistics* PATH and RESV transmitted and received error counters at each interface along the LSP route, you can determine where the failure occurs, and, if not overwritten by the failure of another LSP at the same interface, the error code and value identifying the reason for failure.

The table [MPLS RSVP-TE statistics \(page 51\)](#) lists the protocol throughput and error statistics for the RSVP-TE signaling interface. All are represented by operational attributes under the *Rtr RsvpTe IfStats* component for a particular interface, and also aggregated under *Rtr RsvpTe stats* for all interfaces on the node. All counters are cumulative starting from the creation of the *Rtr Interface RsvpTelf* component for *Rtr RsvpTe IfStats* and the creation of the *Rtr Interface* component for *Rtr RsvpTe stats* and wrap to zero when the maximum value is exceeded. The statistics may be 20 seconds out of date because they are a snapshot of FP-based real time counters.



MPLS RSVP-TE statistics

Statistics	Description
pathMessages	The number of PATH messages sent out and received by the interface.
pathErrorMessages	The number of PATH error messages sent out and received by the interface.
lastPathErrorInfo	Indicates the error code, error value, and timestamp of the PATH error message most recently sent out and received by the interface. For <i>Rtr RsvpTe Stats</i> , the associated interface address is also displayed. Details are outlined in RFC 2205 and 3209, and summarized in the table MPLS RSVP-TE PATH error codes and values (page 52) . A blank display indicates no PATH error message has been sent or received.
pathTearMessages	Indicates the number of PATH tear messages sent out and received by the interface.
resvMessages	Indicates the number of RESV messages sent out and received by the interface.
resvConfirmMessages	Indicates the number of RESV confirmation messages sent out and received by the interface.
resvErrorMessages	Indicates the number of RESV error messages sent out and received by the interface.
lastResvErrorInfo	Indicates the error code, error value, and timestamp of the RESV error message most recently sent out and received by the interface. For <i>RsvpTe Stats</i> , the associated interface address is also displayed. Details are outlined in RFC2205, RFC3209, and summarized in the table MPLS RSVP-TE RESV error codes and values (page 55) . A blank display indicates that no RESV error message was sent or received.
resvTearMessages	Indicates the number of RESV tear messages sent out and received by the interface.
helloMessages	Indicates the number of RESV hello messages sent out and received by the interface.
rsvpDiscards	Indicates the number of sent and received RSVP-TE messages that were discarded.
lastRsvpDiscardInfo	Indicates the message type of the last RSVP-TE protocol message sent and received by the interface and the timestamp of its discard. If there are no discards, this attribute value is left blank.

The RsvpTelf stats attributes include the PATH and RESV error code and values for the last error message(s) sent and received through the interface. The error codes are standardized, documented in classical RSVP RFC 2205



and RSVP-TE RFC 3209. They are described along with their accompanying error values in the tables [MPLS RSVP-TE PATH error codes and values \(page 52\)](#) and [MPLS RSVP-TE RESV error codes and values \(page 55\)](#).

The error values accompanying the RSVP-TE system error code in PATH and RESV messages (identified by error code *rsvpSystemError*) are not standardized and are subsequently implementation-specific.

The PATH/RESV error message contains the IP address of the node or interface originating the error.

In a case where the Nortel Multiservice Switch LER originates a PATH/RESV error message with error code *rsvpSystemError*, the values are interpreted as described in the tables below.

MPLS RSVP-TE PATH error codes and values

Error code	Code description	Value	Value description
admissionControlFailure	Reservation request was rejected by admission control due to unavailable resources.	1	Delay bound specified in PATH message can not be met.
		2	Requested bandwidth is not available.
		> 32768	Implementation-specific; not originated by Multiservice Switch system.
policyControlFailure	PATH rejected for administrative reasons related to policy control; not originated by Multiservice Switch system.	0	
conflictingDestPorts	Sessions for same destination address and protocol have appeared with both zero and non-zero destination port fields in PATH message.	0	
conflictingSenderPorts	Sender port is both zero and non-zero in PATH messages for the same session.	0	
unknownObjectClass	Unknown object class encountered during PATH message decode.	variable	The class number and c-type of the unknown object comprise the error value.
unknownObjectCType	Unknown object c-type encountered during PATH message decode.	variable	The class number and c-type of the unknown object comprise error value.
(1 of 4)			



MPLS RSVP-TE PATH error codes and values (continued)

Error code	Code description	Value	Value description
reservedForAPI	Asynchronously detected error that must be reported to the application via an upcall.	applicati on- specific	
trafficControlError	Traffic control call failed due to the format or contents of the parameters to the request. The PATH message cannot be forwarded, and repeating the call would be futile.	2	Traffic control cannot provide the requested service nor an acceptable replacement.
		4	Bad TSPEC value.
		5	Bad ADSPEC value.
		>32768	Implementation-specific; not originated by Multiservice Switch system.
trafficControlSystemError	A system error was detected and reported by the traffic control modules; not originated by Multiservice Switch system.	impleme ntation- specific	
rsvpSystemError	An error occurred during RSVP-TE processing. The accompanying error value provides implementation-specific information on the error.	30	Internal software error encountered during PATH message processing; a SOFTWARE alarm should accompany this error on the originating node.
		31	A PATH message received is missing an RSVP-TE object mandatory for processing.
		32	A PATH message was incorrectly formatted and could not be processed.
		33	There were insufficient system resources available to process the PATH message. Examples include system congestion preventing internal message send.
		41	A PATH message was received containing an incorrectly formatted session object.
(2 of 4)			



MPLS RSVP-TE PATH error codes and values (continued)

Error code	Code description	Value	Value description
		42	A PATH message was received containing an incorrectly formatted sender template.
		43	A PATH message was received that was intended to terminate a local repair attempt on the interface; Multiservice Switch nodes do not support local repair termination.
		44	A PATH message was received for an existing LSP with a different RSVP hop object.
		45	A PATH message was received to setup an LSP in an existing TE session that has reached the limit on the number of LSPs per Fixed Filter (FF) session.
		other	Implementation-specific; not originated by Multiservice Switch system.
routingProblem	The desired route cannot be followed to establish the LSP.	1	The Explicit Route Object (ERO) is malformed - the initial subobject is missing.
		2	A strict hop specified in the ERO cannot be reached.
		3	A loose hop specified in the ERO cannot be reached.
		4	The first ERO subobject is incorrect.
		5	No route is available to the specified destination. A node may spontaneously originate this error on the loss of an LSP due to interface failure.
		7	The RRO indicated routing loops.
(3 of 4)			



MPLS RSVP-TE PATH error codes and values (continued)

Error code	Code description	Value	Value description
		8	MPLS being negotiated, but a non-RSVP-capable router stands in the path.
		9	MPLS label allocation failure.
		10	The receiver cannot support the L3PID specified in the PATH message; not originated by Multiservice Switch system.
notifyError	Notification of error.	1	Length of RRO causes the PATH message to exceed the interface MTU.
		2	PATH error sent by the receiver in response to a RESV notify error with error value 1 indicating that the RRO grew too large for the MTU; not originated by Multiservice Switch system.
		3	Tunnel locally repaired; not originated by Multiservice Switch system.
		> 32768	Implementation-specific; not originated by Multiservice Switch system.
(4 of 4)			

MPLS RSVP-TE RESV error codes and values

Error code	Code description	Value	Value description
admissionControlFailure	Reservation request was rejected by admission control due to unavailable resources.	3	MTU in RESV FLOWSPEC object is larger than the interface MTU.
		> 32768	Implementation-specific; not originated by Multiservice Switch system.
policyControlFailure	RESV rejected for administrative reasons related to policy control; not originated by Multiservice Switch system.	0	
(1 of 5)			



MPLS RSVP-TE RESV error codes and values (continued)

Error code	Code description	Value	Value description
noPathInfo	The RESV message does not correspond to an existing session with PATH state on this interface.	0	
noSenderInfo	The RESV message identifies an existing session with PATH state, but the flow descriptor does not correspond to a sender in that session.	0	
conflictingResvStyle	The reservation style in the RESV message conflicts with the style of the existing RESV state for that session.	variable	The error value identifies the style of the existing session.
unknownResvStyle	The reservation style in the RESV message is unknown.	0	
conflictingDestPorts	Sessions for the same destination address and protocol have appeared with both zero and non-zero destination port fields in RESV message.	0	
servicePreempted	The service request defined by the style object and the flow descriptor has been administratively preempted.	> 32768	Implementation-specific; not originated by Multiservice Switch system.
unkownObjectClass	Unknown object class encountered during RESV message decode.	variable	The class number and c-type of the unknown object comprise the error value
unknownObjectCType	Unknown object c-type encountered during RESV message decode.	variable	The class number and c-type of the unknown object comprise the error value.
reservedForAPI	Asynchronously detected error that must be reported to the application via an upcall.	application-specific	
(2 of 5)			



MPLS RSVP-TE RESV error codes and values (continued)

Error code	Code description	Value	Value description
trafficControlError	Traffic control call failed due to the format or contents of the parameters to the request. The RESV message cannot be forwarded, and repeating the call would be futile.	5	Bad FLOWSPEC value.
		> 32768	Implementation-specific; not originated by Multiservice Switch system.
trafficControlSystemsError	A system error was detected and reported by the traffic control modules; not originated by Multiservice Switch system.	implementation-specific	
rsvpSystemError	An error occurred during RSVP-TE processing. The accompanying error value provides implementation-specific information on the error.	30	internal software error encountered during PATH/RESV processing.
		31	A RESV message received is missing an RSVP-TE object mandatory for processing.
		32	a RESV message was incorrectly formatted and could not be processed.
		33	There were insufficient system resources available to process the RESV message. Examples include system congestion preventing internal message send.
(3 of 5)			



MPLS RSVP-TE RESV error codes and values (continued)

Error code	Code description	Value	Value description
		34	A RESV message was received that would result in bandwidth sharing between LSPs. Multiservice Switch nodes do not support bandwidth sharing The session employs the SE style and RESV flow descriptor identifies multiple LSPs on the same session through the same interface.
		41	A RESV message was received containing an incorrectly formatted session object.
		51	A RESV message was received containing an incorrectly formatted filter spec object.
		52	A RESV message was received containing an incorrectly formatted flow descriptor.
		53	A RESV message was received for an existing LSP with a different label object.
		other	Implementation-specific; not originated by Multiservice Switch system.

(4 of 5)



MPLS RSVP-TE RESV error codes and values (continued)

Error code	Code description	Value	Value description
routingProblem	The desired route cannot be followed to setup the LSP.	6	The label specified in the RESV message is unacceptable. Possible reasons for rejection: <ul style="list-style-type: none"> the label has already been assigned to another LSP and the node originating this error is merge incapable the implicit null label was assigned, but the node is not capable of doing a penultimate pop for the associated L3PID
		7	The RRO indicated routing loops.
		8	MPLS being negotiated, but a non-RSVP-capable router stands in the path.
		9	MPLS label allocation loops.
notifyError	Notification of error.	1	Length of RRO causes the RESV message to exceed the interface MTU.
		3	Tunnel locally repaired; not originated by Multiservice Switch system.
		> 32768	Implementation-specific; not originated by Multiservice Switch system.
(5 of 5)			

Transport Statistics

Table [MPLS transport statistics \(page 60\)](#) lists the statistics related to the transport of data traffic through RSVP-TE connections on the interface.



MPLS transport statistics

Statistic	Meaning
inFrames	Indicates the accumulated number of frames received.
inOctets	Indicates the accumulated number of octets received.
inFrameDiscards	Indicates the accumulated number of frames discarded on receipt.
outFrames	Indicates the accumulated number of frames sent.
outOctets	Indicates the accumulated number of octets sent.
outFrameDiscards	Indicates the accumulated number of frames discarded on sen.



MPLS overview

Use this information to learn more about multiprotocol label switching (MPLS).

Navigation

- [MPLS technology \(page 61\)](#)
- [Implementation of MPLS in a Multiservice Switch networks \(page 62\)](#)
- [Benefits of MPLS \(page 63\)](#)
- [MPLS operation \(page 63\)](#)
- [Label switched paths \(LSPs\) \(page 66\)](#)
- [MPLS on Multiservice Switch nodes \(page 72\)](#)
- [Traffic engineering with MPLS \(page 72\)](#)


MPLS technology

MPLS is a label-swapping, networking technology that forwards packet traffic over multiple, underlying layer-2 media. This technology integrates layer-2 switching and layer-3 routing by linking the layer-2 infrastructure with layer-3 routing characteristics. Layer-3 routing occurs at the edge of the network, and layer-2 switching takes over in the MPLS network core. See , “MPLS technology,” (page 66).

Essentially, MPLS forwards a packet by swapping labels at each node in its path. MPLS makes it possible to create new label formats without having to change routing protocols. For example, MPLS traffic can include internet protocol (IP), frame relay, ATM, ethernet, and even optical waveforms.



MPLS technology



In its generic concept, MPLS can swap a frame from any kind of layer-2 link to any other kind of layer-2 link. At this stage in the development of its standards, MPLS supports ATM, frame relay, Ethernet, and point-to-point protocol (PPP). Because traffic flow is independent of the MPLS control protocols, MPLS will be able to support routing protocols that have not yet been defined without any need for the underlying forwarding hardware to change.

With MPLS, layer-3 traffic flows take advantage of the layer-2 traffic engineering abilities and quality of service (QoS) performance, without losing the benefit of existing best-effort, hop-by-hop routing.

MPLS is an emerging standard for network-layer packet forwarding, based on a number of signaling protocols proposed by the Internet Engineering Task Force (IETF). Among these protocols are the label distribution protocol (LDP), the multi-protocol extensions to the border gateway protocol (MP-BGP), and the tunnel extensions for the resource reservation protocol (RSVP-TE). The choice of protocol depends on factors such as the location and role of the node. In some cases, a node uses more than one distribution protocol.

Implementation of MPLS in a Multiservice Switch networks

In Nortel Multiservice Switch networks, MPLS transports IP traffic over GigE allowing carriers and large enterprises to send IP data easily across the backbone. MPLS functionality at the control plane allows carriers to use existing hardware to efficiently transport IP traffic. Multiservice Switch nodes run both an IP routing protocol and the MPLS signaling protocol, RSVP-TE. This protocol allows the nodes to establish label-switched paths. Multiple LSPs, with hot standby LSPs, can be configured to the same destination.



Benefits of MPLS

Carrier organizations and large enterprises typically use MPLS in their backbone networks to improve network resource usage. As the key to the future of large-scale IP networks, MPLS provides the following benefits:

- independence of function—In MPLS, the forwarding plane is separated from the routing protocol control plane, so that the MPLS core performs a simple forwarding function completely independent of the packet content. This practice allows policy and routing decisions to be applied only once at the network edge.
- traffic engineering—MPLS channels the operation of IP routing so that traffic can be steered to achieve efficient network resource usage and optimal performance.
- resource control—MPLS allows you to control valuable resources precisely, for example, through the definition of different classes of service.
- network evolution—MPLS is developing into a robust network in which a single, unified protocol operates over multiple, underlying layer-2 technologies.


MPLS operation

MPLS is a forwarding mechanism that works by applying a label to IP traffic entering the network. The label acts as a shorthand representation of the IP packet header. As the traffic moves through the network, MPLS swaps the label at each node on the route, according to a pre-defined label database at that node. At the egress side of the MPLS network, the packet is decapsulated, and continues under the IP routing protocol.

, “MPLS network,” (page 68) shows an MPLS network with a number of nodes. The nodes at the edges of the network are label edge routers (LER). The LER nodes provide ingress and egress functions for IP traffic in the MPLS network. The core nodes are label switched routers (LSR). The LSR nodes provide the high-speed switching functions for the network. The path of data between the MPLS nodes is a label switched path (LSP). An LSP is a unidirectional tunnel through the network.



MPLS network



At the edge of the network

When multiservice traffic arrives at an LER, MPLS applies the initial label to the frame. To do this, the LER analyzes the information in the IP packet/frame relay frame/ethernet/ATM cell header, and classifies traffic according to its destination and class of service characteristics. The destination can be as broad as a router identifier, or it can be as specific as a full 32-bit IP host address for a particular interface.

At the LER, MPLS uses the concept of a forwarding equivalence class (FEC) to map incoming traffic to an LSP. Essentially, a FEC defines a group of packets that are forwarded over the same path with the same forwarding treatment. This means that all the packets with the same FEC can be mapped to the same label.

For each FEC, the LER sets up an LSP through the network to the destination defined by the FEC. After the traffic is assigned a FEC, the LER applies a label based on the label information base (LIB). The LIB maps each FEC to an LSP label that defines the next-hop link.

To forward the packet, the LER looks up the FEC in the LIB, and then encapsulates the packet with the LSP label. The LER then sends the packet out on the next-hop interface defined in the LIB.



In the network core

When a labeled packet arrives at an LSR, the LSR extracts the incoming label and uses it as an index into the LIB. When the LSR finds the appropriate LIB entry, it extracts the corresponding outgoing label and swaps it with the incoming label in the packet. The LSR then sends the packet on the outgoing interface to the appropriate next hop specified in the LIB entry.


Eventually, the packet reaches the edge of the MPLS network. At that point, an LER removes the encapsulating label, and the packet continues to its destination according to conventional IP/frame relay/ethernet/ATM routing or forwarding methods.

In explicit routes

One of the major advantages of MPLS is its ability to direct traffic flow, for example to avoid congestion or to allow the QoS requirements of the traffic to be met. MPLS allows the network operator at the source node to determine an explicit route LSP (ER-LSP) that defines the path the traffic will take. Multiple ER-LSPs, with different quality of service, can be configured to the same destination.

The ER-LSP builds a path from the source to the destination but it does not have to follow the IP forwarding tree. See [ER-LSP \(page 65\)](#). To build this path, MPLS embeds the explicit route into the label request message.

ER-LSP






The loose ER in [Strict and loose ER LSPs \(page 66\)](#) is specified at LER A as {LSR E}. In the illustration, the complete path can be either {LER A, LSR B, LSR D, LER E} or {LER A, LSR C, LSR D, LER E}. In the loose segment between LER A and LSR E, MPLS checks the IP routing tables during call setup to determine the best next hop to the next specified ER hop in the route.

In Nortel Multiservice Switch MPLS, loose ERs are pinned ERs. This means that, after the route is set up, it does not change unless failure occurs, even if the IP routing tables change.

Strict and loose ER LSPs



Label switched paths (LSPs)

For information about label switched paths (LSPs) see the following sections:

- [Creation of LSPs \(page 66\)](#)
- [LSP recovery \(page 70\)](#)
- [Considerations for signaled LSPs \(page 70\)](#)
- [Resource reservation protocol for LSP tunnels \(page 70\)](#)

Creation of LSPs

Before data can transfer over an LSP, the LSP must be set up using RSVP-TE on GigE media. For more information on the RSVP-TE protocol, see [Resource reservation protocol for LSP tunnels \(page 70\)](#). For more information on LSP call setup see the following sections:

- [Call setup for RSVP-TE LSPs \(page 67\)](#)
- [Call setup for ER-LSPs \(page 68\)](#)



Attention: In the diagrams in this section, the node labelling (A, B, C) represents the actual IP addresses used by the software.

Call setup for RSVP-TE LSPs

The figure [Call setup for RSVP-TE LSPs \(page 68\)](#), shows the hop-by-hop LSP setup process. The diagram shows the downstream-on-demand label advertisement mode and the ordered distribution control mode used in the Nortel Multiservice Switch network.


- 1 At LER A, MPLS generates a label request message. LER A determines the link to the next hop (LSR B in the example) from the IP routing table, and sends on a label request message to LSR B.
- 2 At LSR B, MPLS receives the label request. MPLS determines the link to the next hop (LSR D in the example) from the IP routing table, and sends on a label request message. The same process occurs at LSR D.
- 3 The label request message terminates at the destination LER, node F. MPLS at node F sends a label mapping message back to LSR D. The mapping message contains the label for LSR D to use in sending packets to LER F.

In the example, MPLS at LER F sends a message to LSR D containing the label 17.

- 4 MPLS at LSR D receives the mapping message and updates the LIB with the label information for LER F. In the example, MPLS updates the database with 17 as the outgoing label for FEC 20.1.2.3.
- 5 This process continues until the originating LER receives the mapping message and establishes the LSP.



Call setup for RSVP-TE LSPs



MPLS creates label switched paths (LSPs) by mapping network-layer routing information to data link-layer switched paths. MPLS uses a label distribution protocol to set up, maintain, and tear down LSPs. MPLS routes are not supported by other IP routing protocols, such as OSPF, ISIS, and BGP. LSPs are similar to static routes, and do not get exported; they appear only in the local routing table.

For more information on RSVP-TE, see [Resource reservation protocol for LSP tunnels \(page 70\)](#).

Call setup for ER-LSPs


[Call setup for ER-LSPs \(page 69\)](#) illustrates the ER-LSP setup process for a strict ER. The process takes the following steps:

- 1 MPLS at LER A generates a label request message. The message contains an explicit route object that defines the ER path through nodes C and E to LER F.



- At LSR C, MPLS receives the label request message and determines from the ER hop list that the next-hop node is LSR E. Since the route is pre-defined, there is no need to check the IP routing table. MPLS removes LSR C from the path list, and sends the message to LSR E. The process repeats at LSR E.
- At LER F, the request message terminates. MPLS sends a label mapping message back to LSR E. The mapping message contains the label for node E to use in sending packets to LER F. In the example, the label is 13.
- LSR E receives the mapping message, and updates the LIB entry for LER F.
- This process continues until LER A receives the mapping message and establishes the ER.

Call setup for ER-LSPs



Call setup for a loose ER is a combination of the process for a hop-by-hop LSP and the process for a strict ER. The loose ER setup works like the strict ER setup for those segments of the route that have defined end points. In the loose segments, MPLS accesses the IP routing tables to get next-hop information.



LSP recovery

If a failure occurs during LSP setup, the LSR immediately downstream from the failure point releases the LSP to the egress LER. The LSR immediately upstream from the failure point sends a notification message to the ingress LER to tear down the connection.

The ingress LER releases the LSP to the failure point and begins a recovery process. If there is a hot stand-by path configured, the LER shifts the traffic to the stand-by path. Otherwise, the LER attempts to set up a new LSP to the destination. This rerouting attempt is called global repair.

Considerations for signaled LSPs

Signaled LSPs are created through automatic signaling, initiated by the upstream node with downstream nodes assigning MPLS label values. Each node maintains a view of the network topology and uses this view to compute available paths.

Nortel Multiservice Switch nodes support signaled LSPs through RSVP-TE LER functionality on GigE media.

- Load sharing between label switched paths (LSPs) is not supported.
- Setup and holding priority are not supported but are included in the message label request.
- MPLS is considered warm when it comes to supporting Carrier Grade. The addition of MPLS software on a card does not prevent standby behavior in that MPLS packages support hitless software migration (HSM) and equipment protection (EP).

Resource reservation protocol for LSP tunnels

The extensions to Resource ReSerVation Protocol for LSP Tunnels (RSVP-TE) is an MPLS label distribution protocol used for creating LSPs in MPLS networks. Nortel Multiservice Switch nodes provide LER functionality on GigE in an RSVP-TE network for LSP tunnels. LSPs can be used for the implementation of network performance optimization, such as manual routing of LSP tunnels away from network congestion.

All routers in the path of an RSVP-TE signaled LSP must be RSVP-TE capable LSRs, otherwise LSP setup is not possible.

RSVP-TE protocol supports only downstream-on-demand label distribution mode, in which a request to bind labels to an LSP tunnel is initiated by an ingress node through an RSVP PATH message. Subsequently, the labels are allocated downstream and distributed upstream through an RSVP RESV message.



RSVP-TE basic messages

The following is a full list of RSVP-TE signaling messages:

- PATH: message sent downstream (from the source to the destination) to request the setup of the LSP.
- RESV: message sent upstream (from the destination to the source) in response to PATH message, carrying allocated label value.
- PATH_TEAR: message sent downstream to tear down an LSP, reserving both PATH and RESV state.
- RESV_TEAR: message sent upstream to tear down RESV state.
- PATH_ERR: message sent upstream in response to errors when processing a PATH message. PATH_ERR messages can also be originated by a terminating Multiservice Switch LER in local failure that results in LSP connection loss.
- RESV_ERR: message sent downstream in response to errors when processing a RESV message.
- RESV_CONF: message sent by ingress node if requested by egress node in RESV message.

RSVP-TE sessions

An RSVP-TE session may consist of multiple LSP tunnels. The reservation style selected for the session determines if two LSPs share resources. All LSPs that belong to the same session have the same style. The two reservation styles supported by RSVP-TE are:

- Fixed Filter (FF): creates a distinct reservation for traffic from each sender (ingress LSR) that is not shared by other senders.
- Shared Explicit (SE): creates a reservation for traffic from each sender that is shared by the other senders.
 - Nortel Multiservice Switch systems acting as the source LER will always originate an SE request and will respond to an SE request with an SE reservation.
 - Multiservice Switch will respond to an FF request with an FF reservation.

Traffic engineering with RSVP-TE

Traffic engineering controls where traffic flows in order to achieve efficient network resource utilization and network performance optimization. RSVP-TE implements Global Repair, which allows an LSP to retry the setup via an alternative route (if loosely routed) if the LSP goes down. The retry is attempted until a new route becomes available or the original one recovers. Nortel Multiservice Switch systems also support other robustness mechanisms, such as hot standby LSP.



Record Route Object (RRO) capability

The route the LSP takes when the tunnel is established is recorded by the RRO, which is represented by *Rtr RsvpTe Tunnel pathRro* and *resvRro* attributes. This service is enabled if RRO is included in the message received from the downstream or upstream node. Multiservice Switch always includes RRO when originating LSPs.

Explicit route (ER)

RSVP-TE supports both the strict and loose types of Explicitly Routed Label Switched Paths (ER-LSPs). These ER-LSPs are supported as point-to-point only. The ER information is carried in a PATH message within the EXPLICIT_ROUTE object (ERO). Each ERO subobject defines one hop in the ER, using an IPv4 address prefix, a router identifier (as an IPv4 loopback address), or a combination of both, and specifies whether the ER is strict or loose.

Service class to Quality of Service mapping

RSVP-TE uses IntServ parameters to map Quality of Service. There are two Intserv service classes supported by RSVP-TE on a Multiservice Switch: Controlled-Load Service (CLS) and Null Service Type.

Loop detection

Loop detection functionality is supported by RSVP-TE. Loop detection starts when an RRO object is included in the PATH message. In Nortel Multiservice Switch systems, the RRO object is always included in the PATH message.

MPLS on Multiservice Switch nodes

Nortel Multiservice Switch nodes have LER functionality on GigE media and can originate and terminate both ER-LSPs and hop-by-hop LSPs.

MPLS using GigE media

The supporting layer-2 medium for Nortel Multiservice Switch systems as an LER is GigE.

Traffic engineering with MPLS

With the growth of the Internet, carriers need a network infrastructure that is dependable and offers consistent, predictable network performance. The traffic engineering capabilities of MPLS provide a solution for this situation. The cornerstone of the MPLS solution is the ER-LSP, which the network operator can manipulate to control the transport of IP traffic.

For more information, see the following:

- [MPLS QoS \(page 73\)](#)



MPLS QoS

The ER-LSP can be used to map traffic flows onto the network, independently of the layer-3 topology, so that each application receives the QoS it needs. MPLS allows the network operator to configure multiple LSPs to the same FEC destination. Each primary LSP can have up to seven hot standby LSPs.

The figure [MPLS traffic engineering \(page 74\)](#), shows a simple example of MPLS traffic engineering. In the example, a video server is configured at LER A on the ingress side, and a video client is configured at LER F on the egress side. Regular IP traffic runs from LER A to LER F, following a best-effort, shortest path. If the video stream is introduced on this path, the path becomes congested, and the QoS will degrade. With MPLS, the network operator can configure an ER-LSP through LSR B and LSR D. The ER-LSP forces the video traffic to follow the longer route, but maintains the QoS.

To guarantee the service in case of link failures, the network operator can configure a maximum of seven standby LSPs per primary LSP. A standby LSP is an LSP that can take over the traffic carried by the primary LSP, or another standby LSP, if that LSP should fail. The standby LSP can have different attributes from its primary LSP, including bandwidth requirement and path. To maximize the degree of redundancy, it is recommended that the standby LSP take a different explicit route than the primary LSP at every hop.


Standby LSPs can be ordered under their primary LSP by the network operator. The ordering determines the preference for a standby LSP to take over the traffic when a primary LSP fails. In order to provide fast switchover capability, a standby LSP is kept in the established state, and occupies bandwidth along the standby LSP path.

Since the primary LSP is intended to be the preferred LSP for use, the traffic is changed from a standby LSP to the primary LSP whenever the primary LSP is recovered. The traffic is not changed among standby LSPs unless the standby LSP that carried traffic fails.

LSP2 represents a standby LSP path from LER A through LSR C and LSR E to LER F. If a link fails on LSP1, the traffic changes to LSP2, the first standby in the primary LSP's standby list.



MPLS traffic engineering





Procedure conventions

This document uses the following procedure conventions:

- You can enter commands using full component and attribute names, or you can abbreviate them. The commands used in the procedures contain the full component and attribute names in the first instance. In the second instance, the component and attribute names are abbreviated. For more information on abbreviating component and attribute names, see *NN10600-060 Nortel Multiservice Switch 7400/15000/20000 Component Reference*. All component and attribute names are formatted in italics.
- The introduction of every procedure states whether you must perform the procedure in operational mode or provisioning mode. For more information on these modes, see [Operational mode \(page 75\)](#) or [Provisioning mode \(page 76\)](#).
- When you complete a procedure, you can verify your changes and then activate them as the new node configuration. For more information on completing configuration changes and exiting provisioning mode, see [Activating configuration changes \(page 76\)](#).

Operational mode

Procedures contained within this document can either be performed in operational mode or provisioning mode. When you initially log into a node, you are in operational mode. Nortel Multiservice Switch systems use the following command prompt when you are in operational mode:

```
#>
```

where:

is the current command number

In operational mode, you work with operational components and attributes. In operational mode, you can

- list operational components and display operational attributes to determine the current operating parameters for the node
- control the state of parts of the node by locking and unlocking components



- set certain operational attributes and enter commands to perform diagnostic tests

Provisioning mode

To change from operational mode to provisioning mode, type the following command at the operator prompt:

```
start Prov
```

Only one user can be in provisioning mode at a time. Nortel Multiservice Switch systems use the following command prompt whenever you are in provisioning mode:

```
PROV #>
```

where:

is the current command number

In provisioning mode, you work with the provisionable components and attributes that contain the current and future configurations of the node. You can add and delete components, and display and set provisionable attributes. For information on completing the configuration changes, exiting provisioning mode, and returning to operational mode see [Activating configuration changes \(page 76\)](#).

For information on operational and provisionable attributes, see NN10600-060 *Nortel Multiservice Switch 7400/15000/20000 Component Reference*.

Activating configuration changes

Several procedures in this document ask that you complete the configuration changes. When you complete the configuration changes, you are activating the configuration changes, confirming that you want to activate them, and saving the changes. You are instructed to complete the configuration changes only at the end of procedures that you perform in provisioning mode.



CAUTION

Activating a provisioning view can affect service

Activating a provisioning view can result in a CP reload or restart, causing all services on the node to fail. See NN10600-050 *Nortel Multiservice Switch 7400/15000/20000 Command Reference*, for more information.



CAUTION

Risk of service failure

When you activate the provisioning changes (see [step 3](#)), you have 20 minutes to confirm these changes. If you do not confirm these changes within 20 minutes, the shelf resets and all services on the node fail.

- 1 Verify that the provisioning changes you have made are acceptable.

check Prov

Correct any errors and then verify the provisioning changes again.

- 2 If you want to store the provisioning changes in a file, save the provisioning view.

save -f(<filename>) Prov

- 3 If you want these changes as well as other changes made in the edit view to take effect immediately, activate, confirm, and commit the provisioning changes.

activate Prov

confirm Prov

commit Prov

- 4 End the provisioning session.

end Prov

Nortel Multiservice Switch 7400/15000/20000
**Operations: Multiprotocol Label
Switching**

Copyright © 2005 Nortel.
All Rights Reserved.

Publication: NN10600-445
Document status: Standard
Document issue: 7.1S1
Document date: October 2005
Product release: PCR7.1 and up
Job function: Operations
Type: NTP
Language type: U.S. English

NORTEL, the globemark design, and the NORTEL corporate logo are trademarks of Nortel.

