



Acer Aspire Switch 10 SW5-012-18MY

Trackpad Replacement

If the trackpad on your device is unresponsive or stops working, the trackpad may need to be replaced. This guide will help you replace the trackpad.

Written By: Grecia Corrada




INTRODUCTION

If your trackpad is not functioning properly or responding, you may need to replace the trackpad. Before attempting to replace the trackpad, please visit the troubleshooting page and follow any recommendations. The troubleshooting page recommends that you update the trackpad drivers and attempt to disable and enable the trackpad to see if it fixes the problem. If the trackpad is still not responding, please follow the steps below to replace the trackpad.

TOOLS:

- [iFixit Opening Tool](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Trackpad




- Remove the 8, 5.25 mm screws on the back cover using the screwdriver.
- Insert the opening tool into the USB port.
- Carefully remove the back cover with the opening tool.

Step 2




- Lift up on the ZIF connector that secures the ribbon cable using the opening tool.
- Pull the ribbon cable free.

Step 3



- Remove the 4, 2.5 mm screws from the trackpad cover.

Step 4



- Remove the metal piece that secures the trackpad cover in place using the opening tool.

Step 5



- Remove the trackpad using the opening tool and your hands.

To reassemble your device, follow these instructions in reverse order.