



Amazon Fire Game Controller Outer Shell Replacement

Replacing the shell of the Amazon Fire controller.

Written By: Andrew Klopfenstein



INTRODUCTION

This guide will show you how to properly replace the outer shell of the Amazon Fire game controller. This procedure may be necessary when a part of the outer shell becomes damaged, and will remedy both functionality and cosmetic issues.

TOOLS:

- Triangle 2 Screwdriver (1)
- JIS #1 (1)
- iFixit Opening Tools (1)
- JIS #0 Screwdriver (1)

Step 1 — Motherboard




- Use a Triangle #2 screwdriver to remove the six 10 mm screws from the back of the controller.

Step 2




- Pry the two shell pieces from one another from the top orientation with a plastic opening tool.
(i) The weights will fall out.

Step 3



- Disconnect the battery terminal wires and the play, pause, and stop wires from the motherboard.

Step 4



- Use a J1 screwdriver to unscrew the four 7 mm screws from the motherboard.

Step 5




- Lift the motherboard out of the controller casing.

Step 6 — Outer Shell




- Use a JIS #0 screwdriver to remove the two 7 mm screws from the retaining bracket that secures the play, stop, and pause button wiring.

Step 7



- Use a JIS #0 screwdriver to unscrew the 5 mm screws from the LED indicator assembly.

Step 8



- Slide out the triggers and bumpers.

To reassemble your device, follow these instructions in reverse order.