



# Apple Xserve/Mac Pro RAID Card Battery Repair

If you still operate Xserves, you will undoubtably have had to replace all their RAID Card batteries at least once. This guide show you how.

Written By: Dan

Overall Status ● 2 severe events

Battery Status ● Battery failed (other than expired)

Write Cache Status ● Disabled Force On

## INTRODUCTION

Underneath the pretty aluminium box, Apple's RAID Card batteries are just bog-standard lithium polymer cells with some control gear.

When they fail after a year or two in service you can bet the £££ you'll fork out to replace it that the cell isn't dead, but instead has got itself into a stuck state where the RAID card is confused about what to do with it.

In this guide I will outline how to open up the battery and recondition or even replace the cell, at significantly lower cost than buying a new battery.

**Please don't attempt this repair unless you already have a good idea of what you're doing. Any mistakes have the potential to be extremely dangerous.**

### **TOOLS:**

- Constant-Current PSU (1)
- Prying Tool (1)
- Voltmeter (1)

### **PARTS:**

- [\(Replacement 606168 Lithium Cell\)](#) (1)

## Step 1 — Battery fault codes

Overall Status ● 2 severe events  
Battery Status ● Battery failed (other than expired)  
Write Cache Status ● Disabled Force On


- The RAID card battery has various error codes that indicate its condition, which appear in RAID Utility when there's a problem.
- The error codes follow the format "Battery failed (code 0x#0 = XX)", where 'XX' can be a number, usually 17, 18 or 19. Good luck finding out what any of those mean... You may also see "Battery failed (other than expired)".
- In most cases this guide will prove successful regardless of the error code.

## Step 2 — Extract the battery





- If you're working on an Intel XServer you'll need to locate the right disassembly guide that shows you how to remove the battery. This usually means removing the air ducting, fan assy., RAID card and power distribution board. You'll also need a screwdriver to prise the battery from the chassis, just be careful not to bend it.
- For Mac Pro RAID cards you can follow [this guide](#).

## Step 3 — Crack the case



- Now the battery's out, it's time to open it up. ***From this point on you should be extremely careful, as damaging the battery could cause a fire. If the battery starts getting hot, or you slip and damage it, throw it outside immediately.***
- The battery case comprises a base and a lid, held together by some hot glue around the inside. Some *gentle* persuasion with a screwdriver around the edge is all it takes to separate the two pieces.

## Step 4 — Digging deep



- In order to check and recondition the battery's cell we'll need to get at it directly, bypassing the control systems. ***This means we will have NO short-circuit or overload protection, so take extra care.***
- Peel back the black insulation to expose the cell's terminals (***Never let these points become electrically connected***) and check with a voltmeter.
- If you see a voltage greater than about 4V, the RAID Card is charging the battery but it can't tell when it's finished. Proceed to step 5.
- If you see a voltage significantly less than 3.6V, then the RAID Card is not charging the battery. Proceed to step 6.

## Step 5 — Discharging (refreshing) the cell



- Grab an old torch (or flashlight for those over the pond) and pull the light bulb out. This will serve as our load. (Note: This needs to be an incandescent bulb)
- Connect the bulb across the two terminals of the cell **without letting the terminals touch**. (A set of crocodile clip leads makes this a breeze). The bulb should light.
- Connect your voltmeter too and watch the voltage fall. Disconnect the bulb when it reaches around 3.5V and proceed to charging (Step 6).

## Step 6 — Recharging the cell



- If your cell is charged to less than 3.6V, or you've just discharged it, the next step is to recharge it up to around 3.7V where the RAID card should be able to pick up and carry on.
- Use a Constant Current power supply, set to a maximum voltage of 3.7V and a maximum current of around 500mA. Connect the output directly to the cell's terminals and switch on. **Monitor the cell's temperature while charging and reduce the current if it starts getting warm to the touch.**
- Once 3.7V is reached, allow the current to drop below 100mA and switch off the power supply. The battery is now charged and ready to go back on the RAID card.

## Step 7 — Reconnecting the battery



- Ensure the cell's terminals are covered by the black insulation and replace the cover. We'll glue it back on when we're sure the cell is working.
- Now reinstall the battery onto the RAID card and fire up the machine. If all has gone well, the RAID card will start charging the battery and after a few hours switch to "Fully Charged".
- If after refreshing / recharging the battery the RAID utility still reports an error, first double check the voltage of the cell and consider trying steps 5/6 again. If this doesn't work the cell is beyond repair and will need to be replaced.

## Step 8 — Replacing the cell (if required)



- If you have been unable to recondition the cell to a state where the RAID card will accept it, the cell will need to be replaced. (It is also possible the RAID card is faulty, but it's much more likely to be the battery)

- Purchase a "606168" Rechargeable Lithium cell from your supplier of choice. If you can get one with offset terminals like the original cell then

it'll make replacement a lot easier, but most have symmetrical terminals.

- Unless you have a battery tab welder, you'll need to solder the new battery in place. Don't dwell for too long or the cell will heat up. The new cell should come already charged, so follow Step 7 to reinstall the battery.

---

If you see a green battery symbol in RAID utility then the repair has been a success! You can now glue or tape the battery back together and enjoy hopefully another year or two of service from it.