



# Corsair Katar DPI Sensor Replacement

This guide will show how to replace the DPI sensor in a Corsair Katar mouse.

Written By: Margaret Loughren




## INTRODUCTION

If the DPI (dots per inch) sensor inside your Corsair Katar mouse is not operating correctly, this guide will show you how to replace it.

### TOOLS:

- JIS #0 Screwdriver (1)
- iFixit Opening Tools (1)

## Step 1 — Corsair Katar Disassembly



⚠ Unplug your mouse before starting.



- Flip the mouse over so the bottom is facing up.

## Step 2




- Remove the three skates on the bottom of the mouse using the plastic opening tools.
- ⓘ Skates will be very sticky.

## Step 3



- Use the JIS 0 screwdriver to remove the four 5 mm screws on the bottom of the mouse.

## Step 4





- Detach the bottom of the mouse from the upper shell.

**⚠** Remove the shell slowly so as not to damage the white DPI cable inside the mouse.

- Use the plastic opening tool to detach the white DPI sensor cable from its port.


**i** Alternatively, you can use your hand to remove the DPI sensor cable by wiggling it out of the port.

## Step 5 — DPI Sensor



- Use the JIS 0 screwdriver to remove the two 5mm screws holding the DPI sensor.

## Step 6



- Lift the DPI sensor away from the mouse shell.

To reassemble your device, follow these instructions in reverse order.