



Dell Inspiron 15 5578 2-in-1 Display Assembly Replacement

Written By: Terrence15




INTRODUCTION

In this guide, we will be showing you how to remove and replace the Display Assembly.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Open the Display




⚠️ **WARNING:** Before working inside your computer, read the safety information that shipped with your computer and follow the steps in [Before Working Inside Your Computer](#). After working inside your computer, follow the instructions in [After Working Inside Your Computer](#).

- Turn the computer over and open the display to 180-degree angle.


⚠️ **CAUTION:** Place the computer on a soft and clean surface to avoid scratching the display.

Step 2 — Placing the Computer Down




- Place the computer on a flat surface with the display facing down.

Step 3 — Remove the Screws




- Remove the screws that secure the display assembly to the palm rest and keyboard assembly.

Step 4 — Remove the Antenna Cables




- Remove the antenna cables from the routing guide on the palm rest and keyboard assembly.

Step 5 — Lifting the Display Assembly



- Lift the display assembly off the palm rest and keyboard assembly.


Step 6 — Align the Screw Holes



 CAUTION: Place the computer on a soft and clean surface to avoid scratching the display.

- With the display facing down, align the screw holes on the display hinges with the screw holes on the palm rest and keyboard assembly.

Step 7 — Replace the Screws



- Replace the screws that secure the display assembly to the palm rest and keyboard assembly.
- Turn the computer over and close the display.