




# Fujifilm X20 Disassembly and sand removal

These instructions will show how to disassemble the Fujifilm X20.


Written By: Christian



 **TOOLS:**

- T1 Torx Screwdriver (1)
- Small Phillips Head Screwdriver (1)
- Tweezers (1)

## Step 1 — Screws on the bottom



- Remove the battery and the SD-Card.
- Remove the three marked screws from the bottom of the camera.

## Step 2 — Finding the screws



- Remove four pieces of leatherette from the front and the back of the camera. Lift the edge of the leatherette and pull. The material itself is quite sturdy and the glue will still be good if you re-apply the pieces after you are finished.

## Step 3 — Screws on the back 1



- Remove two screws from the left side of the camera
- Remove three screws from the right side of the camera
- Remove the screw between the Q and the DISP/BACK button.

## Step 4 — Screws on the back 2



- Remove the screw hiding below the rubber-pad.

## Step 5 — Screws on the front




- Remove two screws from the left side of the camera.
- Remove two screws from the right side of the camera
- Remove nine screws from the front of the camera.

## Step 6 — Remove the bottom cover




- You can now remove the plastic base cover.
- Below you will see two more screws. Please remove them as well.

## Step 7 — Remove the back cover



- Now the two metal covers will get loose. Start by removing the back-cover containing the LCD.
- Open the connector holding the FPC (the orange wiggly thing) and remove it.
- You open the connector by lifting the little clip on the opposite side of the orange FPC (second picture). Then you can pull out the orange FPC.

## Step 8 — Insides 1




- Remove two screws (red).
- Disconnect the FPC on the left side (green rectangle). You have to open the lever.
- Remove the copper foil from the upper part, but do not remove it completely (pink rectangle).
- The small round part on the bottom is the beeper. Free the connecting wire from the white duct tape. The beeper itself is glued in his place and can easily be removed by pulling.
- On the left side is one FPC left. This connector can not be opened, the FPC must be removed by pulling (blue-ish rectangle)

## Step 9 — Inner parts



- Finally! You can move the steel part away and by opening the last remaining FPC connector on the main PCB you can remove this steel thing completely.

## Step 10 — Cameras ready, prepare the flash.



**⚠️ Cameras ready, prepare the flash. You will now access the flash capacitor. This can be dangerous. If you are not sure, do not continue.**

**⚠️** The capacitor for the flash can hold dangerously high voltages. I measured 260V across the terminals 2hrs after disconnecting the battery. Either monitor the voltage with your multimeter until it is safe or discharge the capacitor using a resistor of adequate wattage. **Do not short circuit the terminals of the capacitor.**


- Remove the screw below the white plastic.
- Remove the lower FPC as well. This connector does not have a lever. Remove the cable by pulling.
- You can now remove the little PCB from the housing.

## Step 11 — Remove the top cover




- Ok, only two steps, then the top-cover can be removed.
- First, remove the marked FPC from its connector. This leads to any button or wheel on the silver top part.
- Then you can remove the silver top cover by pulling.
- The big capacitor will still be attached.

## Step 12 — Disconnecting the main PCB




- Separate the right PCB by disconnecting the remaining three FPCs.
- This part (PCB and containing plastic) can now be removed as well.

## Step 13 — Separate the lens from the body



- The lens is screwed with four big screws to the body.
- Two screws on the bottom are easily accessible
- One screw on the top left is also easy to reach.
- The fourth screw is a bit hidden under two FPCs. You don't have to remove these FPCs to remove this screw.



## Step 14 — Removing the sand.



Do you still remember why I opened the camera in the first place? Because I could not turn the lens any more due to sand.

- I found some sand lodged between the big and the little gear shown on the picture. I turned the lens so that the opening pointed down and carefully turned the lens back and forth. A very small amount of sand fell out but it was enough to get things going again.

## Step 15 — HELP



- Two pictures showing a) the parts and b) the screws and their position.

To reassemble your device, follow these instructions in reverse order. Please pay attention to the following steps:

- On the PCB with the big capacitor you have to push the FPC in. There is no lever on the socket.
- On all other sockets, open the lever first, slide in the FPC and close the socket.
- Be careful with the thick wires going to the flash, They may keep the flash from opening. Try this out before closing the camera.
- Don't forget to secure the beeper and his wire.
- Also remember to glue on the copper foil.