



# Governor Adjustment

Small Gas Engine Governor Adjustment

Written By: Aaron Correya



## INTRODUCTION

Adjusting the governor helps maintain a steady engine speed no matter the terrain and other conditions that could effect the engine workload. While the manufacturer highly recommends against this, it may be necessary to keep your engine running well.

### TOOLS:

- Large Needle Nose Pliers (1)

## Step 1 — Governor Adjustment



**⚠** Before starting, make sure the engine isn't running and is not hot.

- Using needle-nose pliers, carefully unhook the spring from the end opposite the air filter.

## Step 2



- Use the needle-nose pliers to either lengthen or shorten the hook at the end of the spring.
- i** If your engine is stalling or refusing to start, try shortening the spring. This will enable more fuel to reach the engine at idle. If the engine is bogged down when running and you hear liquids splashing, try lengthening the spring.

## Step 3



- Carefully re-hook the spring on the arm it was disconnected from.

To reassemble your device, follow these instructions in reverse order.