




Lenovo Yoga 2 11" Speakers Replacement

This guide will show you how to safely remove faulty speakers and replace them.


Written By: Peyton Leeson



 **TOOLS:**

- [T5 Torx Screwdriver \(1\)](#)
- [Magnetic Project Mat \(1\)](#)
- [Phillips #0 Screwdriver \(1\)](#)
- [Tweezers \(1\)](#)

Step 1 — Back Panel



- With a T5 Torx screwdriver, remove ten 6.35 mm screws from the back of the laptop.

Step 2




- Carefully separate back panel from laptop.

Step 3 — Speakers




- Once you complete the prerequisite guide, locate the two speakers.

Step 4





- Using a Philips 00 Screwdriver, remove the four 4.762mm screws that hold the speakers in place (two for each speaker).

Step 5



- Locate and carefully detach the clips that connect each speaker to the computer.

Step 6



- Now that the speakers are completely free from the computer, you are able to remove each speaker and replace it.

To reassemble your device, follow these instructions in reverse order.