




# Memorex CD Alarm Clock Radio PCB Board Replacement

This guide will show you how to replace a PCB board in the Memorex CD Alarm Clock Radio.

Written By: Aubrey Frank



## INTRODUCTION

Removing the PCB board requires a Phillips #1 screwdriver with at least a 15 cm shaft and a set of tweezers. Make sure there are no batteries in the device and that it is not plugged in before starting the procedure.

### TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)
- [Tweezers \(1\)](#)

## Step 1 — Memorex CD Alarm Clock Radio Disassembly




- Locate the 'OPEN' tab on the battery compartment.
- Pull the tab upwards and remove the cover using your finger.
- Remove the batteries.

## Step 2






- Locate the screws on the bottom of the device that hold the upper and lower halves together.
- Remove the (5) 19mm screws.
- Grasp the top and bottom and gently pull apart.

## Step 3 — PCB Board




- Remove the (5) 7mm screws with a Phillips #1 screwdriver and a pair of tweezers.
- *(i)* Using a magnetic tip screwdriver will prevent screw loss.

## Step 4



- Locate the wiring harness.
- Disconnect the wiring harness using the tweezers.

## Step 5



- Remove the PCB board from the device.
- Replace the broken motherboard with a new PCB board.

To reassemble your device, follow these instructions in reverse order.