



Microsoft Band 2 Screen Replacement

Replacing a broken or damaged screen on the Microsoft Band 2.

Written By: Chris Syracuse



INTRODUCTION

This guide will cover how to remove the screen of the Microsoft Band 2 smartwatch. If the display is blank or dim it may be advantageous to consider replacing the screen on the Band 2.

TOOLS:

- [Heat Gun](#) (1)
- [Spudger](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Tweezers](#) (1)

Step 1 — Screen



 Wear proper gloves when using a heatgun.

- Use a heatgun to melt the adhesive beneath the screen. Heat the metal around edges of the screen.
-  Avoid heating the rubber watch band as it will quickly melt.
-  Heating the LCD screen may damage it. Avoid this procedure unless you intend to replace the screen.

Step 2



- Use a [spudger](#) and plastic [opening picks](#) to pry the screen away from the Band 2.

Step 3



- Use metal tweezers to gently detach the orange press-fit (or "pop") connector.

To reassemble your device, follow these instructions in reverse order.