



Microsoft Surface Pro 3 Kickstand Replacement

If your Microsoft Surface Pro 3 kickstand has broken off or is no longer holding the device up as it should, use this guide to replace it.

Written By: Sarah Westberg



INTRODUCTION

If your kickstand has worn out or broken and is no longer supporting your device, use this guide to replace it. You may need to replace the kickstand due to normal wear-and-tear or an accidental drop. The process is very simple and doesn't require taking the Surface Pro 3 apart. You're just removing and replacing the kickstand itself.

TOOLS:

- [T5 Torx Screwdriver](#) (1)

PARTS:

- [Surface Pro 3 Kickstand](#) (1)

Step 1 — Kickstand




- Lift the kickstand to a 90° angle to expose the hinge screws.

Step 2



- Remove the four 3.5 mm T5 screws—two on each side.

Step 3



- Wiggle the kickstand gently back and forth to disengage the two lightly-adhered tabs connecting the center of the kickstand to the main body.
- Remove the kickstand from the back cover of the Surface Pro 3.

To reassemble your device, follow these instructions in reverse order.