



Microsoft Surface Pro 5 Kickstand Replacement

This guide will show you how to replace the kickstand of your Microsoft Surface Pro 5.

Written By: Sarah Westberg



INTRODUCTION

The kickstand of your Microsoft Surface Pro 5 is a convenient feature of the device, but if it breaks off or stops holding your tablet upright, you may want to replace it. Follow this guide to replace the kickstand of your Microsoft Surface Pro 5. This is a quick and easy repair that will greatly improve the usability of the Surface Pro 5.

TOOLS:

- [T3 Torx Screwdriver](#) (1)

PARTS:


- [Surface Pro 5 Kickstand](#) (1)

Step 1 — Kickstand



- Lift the kickstand about 90° to reveal the hinges.

Step 2



- Remove the four 2.7 mm T3 Torx screws, two from each hinge.

Step 3



- Lower the kickstand to about a 15-30° angle from the device.
- Gently pull the kickstand away from the device, rocking left to right to disengage the adhesive tabs connecting the kickstand to the device.

 During reassembly, be sure to reinsert the two adhesive tabs into the slots on the back of the device before installing the screws in the hinges.

To reassemble your device, follow these instructions in reverse order.