



# Nike SportWatch GPS LCD Screen Replacement

This guide will allow you to remove and replace the LCD screen on the watch, in the event that it is broken or cracked.

Written By: Zainab Hussein



This document was generated on 2019-10-02 08:16:03 AM (MST).

## INTRODUCTION

These step by step instructions will allow you to easily remove the LCD screen on the watch and replace it with a new one.

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #000 Screwdriver](#) (1)

## Step 1 — LCD Screen




- First, place the watch upside down so the back of the watch is exposed. Unscrew the six size #000 5 mm long screws located on the back panel using a size 000 Phillips head screwdriver.

## Step 2




- Carefully separate the watch by pulling the band away from the main board.

## Step 3



- Then, unscrew the two main board size #000 2.5 mm long screws using a size 000 Phillips head screwdriver.

## Step 4



- Carefully use the blue plastic opening tool to pry the main board out of the front panel.


**⚠** Make sure to be gentle so the ribbon cable that connects to the band does not break, it is fragile and is not removable.

## Step 5




- Use the blue plastic removal tool once again to carefully remove the screen.

## Step 6



- Pull the plastic piece that is highlighted in the picture out from the back of the screen.

## Step 7



- For reassembly, make sure the highlighted area in the picture, goes over the black plastic piece that was removed in the previous step.

To reassemble your device, follow these instructions in reverse order.