




# Ninja Mega Kitchen System BL770 Button Replacement

How to replace the Ninja Mega Kitchen System BL770 buttons.

Written By: Tommee Walker



## INTRODUCTION

This guide will demonstrate how to replace any of the push button switches on the circuit board. Each button has four solder pads to desolder. When replaced these must be in the correct orientation in order for the device to work. For soldering help, follow the [How to Solder and Desolder Connections](#) guide.

## TOOLS:

- [Phillips #2 Screwdriver](#) (1)
- [Soldering Iron](#) (1)
- [T10 Torx Screwdriver](#) (1)

## Step 1 — Circuit Base



- Remove the five screws (13mm long, 6mm head) attaching the Base Cover using a Phillips screwdriver (Ph2).
- Remove the two screws (13 mm long, 6mm head) attaching the Base Cover using a T10 screwdriver.

## Step 2




- Carefully remove the second layer from the base. You will not need a screwdriver for this step.

## Step 3





- Remove the 2 screws (13mm, 6mm head) connected to the plastic piece holding down the power cord.
- Then remove the additional 4 screws (13mm, 6mm head) and 2 screws (11mm, 5mm head) securing the base.
- Carefully lift the base up from the rest of the blender.

## Step 4



- Remove 4 screws (11mm, 4mm head) connecting the circuit board to the base.

## Step 5 — Button



- Locate which button you wish to replace.
- On the back of the circuit board from the button, there are four solder pads with the designation "SW" followed by a number.

To reassemble your device, follow these instructions in reverse order.