




Samsung Gear Fit Screen Replacement

This guide will cover removing and replacing the screen of the Samsung Gear Fit.

Written By: Nathan Powell



 **TOOLS:**

- [Heat Gun \(1\)](#)
- [iFixit Opening Picks set of 6 \(1\)](#)
- [Tweezers \(1\)](#)
- [iOpener \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Watch Band



- Place your thumbs on the ends of the screen.
- Push the watch outward while pulling the band away from the watch.

Step 2 — Screen




 Heating the device with a hair dryer may warp the screen or damage the device. It is preferable to use an iOpener for this step.

 For step-by-step instructions on using an iOpener, see the [iOpener Instructions](#).

- Use a hair dryer, heat gun, or an iOpener to heat the Gear Fit for 1-2 minutes until it is hot to the touch.

Step 3



! The screen is connected to the device by a ribbon cable on the left side with the power button facing you. Do not try to completely separate the screen from the device yet, and be careful.


- Gently pry the screen loose using a plastic opening tool.
- *i* If the screen doesn't easily come loose, more heating may be required

Step 4




- Using tweezers as a lever, pry the inner assembly out of the external casing.
- This will be harder than removing the screen. Moderate force may be required.

Step 5



- Disconnect the ribbon cables connecting the screen to the motherboard by lifting their metal connectors up off of the board with tweezers.

Step 6



- Gently peel the screen assembly up and away from the device using tweezers.

To reassemble your device, follow these instructions in reverse order.