



# Samsung WB2100 Back Cover Assembly Replacement

This is a prerequisite guide to take off the back cover assembly.

Written By: Mason Ricks



## INTRODUCTION

This is a prerequisite guide to take off the back cover assembly.

### TOOLS:

- **Phillips #000 Screwdriver** (1)
- **Spudger** (1)



## Step 1 — Back Cover Assembly



- Remove the 7 screws on the outside of the camera
  - Two 5 mm PH000 screws on the right side of the camera body
  - Four 3mm PH000 screws on the bottom and the left side of the camera body.
- Use the plastic spudger to push the back casing out. Start from the right side and work your way clockwise around the case.

*(i)* The HDMI / AV tab might fall out. this is supposed to happen as it is not screwed into place in the back casing.

## Step 2



- Disconnect the set of wires from the back casing to the motherboard. Do this by using the plastic spudger to flip the black tab up and the wires will pull out.
- Unscrew the four 3 mm and two silver 1 mm PH000 screw from the green logic board

To reassemble your device, follow these instructions in reverse order.