



SteelSeries Arctis Pro Plus GameDAC Volume Control Wheel Replacement

This guide will show how to replace the volume control wheel located on the SteelSeries Arctis Pro Plus GameDAC headset.

Written By: Kyle Chang



This document was generated on 2020-01-14 07:21:06 AM (MST).

INTRODUCTION

If the volume control wheel is not rotating properly or adjusting the volume, follow this guide to access and replace the wheel mechanism.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [Soldering Iron](#) (1)

Step 1 — Headset Ear Cushions



- Lift the edge of the cushion and pull out slightly.
- Work your way around the cushion until it comes off completely.
- Repeat for the other cushion.

Step 2 — Headset Circuit Board



- Remove the three 5mm screws with a Phillips #0 driver head on the headphone with the microphone.

Step 3



- Lift the speaker off the headset to expose the circuit board.


⚠ Be careful not to lift the speaker too quickly or too forcefully to prevent the wires from being pulled out of their connections.

Step 4




- Remove the three 5mm screws using a Phillips #0 driver head.

Step 5





- Lift the circuit board out of the plastic housing.
- *i* Press in on the volume wheel while pulling on the circuit board to help maneuver the circuit board out of the housing.

Step 6 — Headset Volume Control Wheel




- Remove the 5mm screw using a Phillips #000 driver head.

Step 7



- Pull on the wheel to remove it from the circuit board.

Step 8



- Flip over the circuit board and desolder the five pins to remove the wheel mechanism from the circuit board.

ⓘ For help desoldering connections, follow this useful guide on [How To Solder and Desolder Connections](#).

⚠ Use caution when soldering. The heated tip may cause damage to the board or burn you.

To reassemble your device, follow these instructions in reverse order.