



Toshiba Qosmio X505-Q860 RAM Replacement

This guide helps a user to remove the RAM sticks so that they can replace them.

Written By: Jonathan Kizzia



INTRODUCTION

If your laptop is booting to the BIOS screen and it is not because of a faulty hard disk drive, then use this guide to replace the RAM sticks.



TOOLS:

- [Spudger](#) (1)
 - [JIS #0 Screwdriver](#) (1)
-

Step 1 — Battery



⚠ Turn off laptop before starting.


- Flip the switch on the right to the unlocked position.

Step 2




- Hold the switch on the left and pull the battery up towards you, using the marked tab, to take it out.

Step 3 — RAM



- Use a JIS #0 screwdriver to remove the three 4.8mm long screws that secure the RAM cover.
- Lift the cover off using the indent for leverage.

Step 4



- Use a spudger or your fingers to push the RAM brackets outwards until the RAM pops up.
- Once the RAM stick is angled up, pull it out along the angle.
- ① Repeat this step for the lower ram card.

To reassemble your device, follow these instructions in reverse order.

