



# iBook G4 12" 800 MHz-1.2 GHz Rear Display Bezel Replacement

Written By: Andrew Bookholt



## INTRODUCTION

This guide is an internal private guide that serves as a prereq.

### TOOLS:

- [1.5mm Hex Screwdriver](#) (1)
- [Spudger](#) (1)

## Step 1 — Rear Display Bezel



- Use a 1.5mm hex screwdriver to remove the two hex screws on either side of the display (four screws total).

- *i* If you don't have a 1.5mm hex driver, you can probably get these screws out with a T6 Torx screwdriver. However, if you use a T6 Torx driver you'll be more likely to strip the screws.

## Step 2



- Use your thumbs to slightly separate the rear bezel from the front bezel.
- *i* It is helpful to hold the opposing corner of the display stationary to aid in flexing the rear bezel away from the display.

## Step 3



- Insert the flat end of a spudger into the gap between the front and rear bezels.
- Rotate your spudger until it is parallel to the front face of the display.
- Run the spudger around the perimeter of the display to separate the rear bezel from its retaining clips.

## Step 4



- Lift the rear bezel off the display.

To reassemble your device, follow these instructions in reverse order.