

TELEPRINTER 1000 KSR CONFIGURATION WORKSHEET

Feature/Sequence	Factory Setting	Key Used	User Setting
-------------------------	------------------------	-----------------	---------------------

Select factory settings See User's Manual I

User Preference

Bell volume	1	G	_____
Key click	0	K	_____
Auto repeat	1	R	_____
Last character view	1	Z	_____

Page

Clear vertical margins	None	Shift and 7	_____
Clear vertical tabs	None	Shift and 3	_____
Clear horizontal margins	None	7	_____
Clear horizontal tabs	None	3	_____
Set lines per inch (vertical pitch)	6	V *	_____
Set form length	66	F *	_____
Set top of form	1	4	_____
Set top margin	1	Shift and 5 †	_____
Set vertical tabs	See User's Manual	Shift and 1 †	_____ _____ _____ _____
Set bottom margin	66	Shift and 6 †	_____
Set characters per inch (horizontal pitch)	10	H ‡	_____
Set left margin	1	5 †	_____
Set horizontal tabs	See User's Manual	1 †	_____ _____ _____ _____
Set right margin	132	6 †	_____

Select with Local Line Feed

Select with space bar

* Changing vertical pitch or form length clears the top and bottom margins.

† Tabs and margins should be cleared before new ones are set.

‡ Changing horizontal pitch clears the left and right margins.

Feature/Sequence	Factory Setting	Key Used	User Setting
Communication Compatibility			
Receive baud rate	1200	0	_____
Transmit baud rate	1200	Shift and 0	_____
Auto answerback	0	A	_____
Buffer size	1	B	_____
Print character set	1	C	_____
Auto disconnect	1	D	_____
Local echo	0	E	_____
Auto new line	1	J	_____
Auto line feed	0	L	_____
Modem	1	M	_____
National Character Set	1	N	_____
Alternate Character Set	1	O	_____
Parity	1	P	_____
HDX initial call state	0	Q	_____
Secondary channel	0	S	_____
Break action	1	U	_____
Printer new line character	1	W	_____
XON-XOFF	1	X	_____
Alternate keypad	0	Y	_____
Disconnect sequence	0	.	_____
Select line		LINE/LOCAL	<u>LINE</u>
Store settings	None	Shift and 9	_____

Enter ANSWERBACK
See User's Manual
for procedure