



# How to clean a rusting Microwave

Rust can appear after a few years inside a microwave, particularly to the area the tray rollers run over. This guide covers cleaning and applying touch up paint to the affected areas.

Written By: Tristan Hill



## INTRODUCTION

Rust can appear after a few years inside a microwave, particularly to the area the tray rollers run over. This guide covers cleaning and applying touch up paint to the affected areas.



### TOOLS:

- [wire wool](#) (1)
- [small paint brush](#) (1)
- [Small flat screwdriver](#) (1)



### PARTS:

- [small tin of enamel paint](#) (1)

## Step 1 — prepare



- an enamel paint is required but it is not special for microwaves, e.g. the small tins used for modeling will do
- unplug the microwave!

## Step 2 — remove the rust



- remove the glass tray and roller ring
- rub the affected area with wirewool
- wipe away any debris with a dry cloth



### Step 3 — apply the paint



- shake the tin
- apply a thin coat with the brush
- give the paint at least 6 hours to dry
- apply 1 or 2 more coats as appropriate

### Step 4 — replace tray



- make sure paint is fully dry and interior is aired