



# Oral-B Vitality O-Ring Seal Replacement

This guide will show you how to remove the top of the handle and replace the O-Ring seal.

Written By: Grady Bennett



## INTRODUCTION

Electric toothbrushes have one or more O-rings to prevent water from entering the handle and damaging electric parts in the handle. If the O-ring wears out, you'll see water seeping through the handle during use.



### TOOLS:

- [Slip Joint Pliers](#) (1)
- [iFixit Opening Tools](#) (1)



### PARTS:

- [O-rings](#) (1)  
15/16" ID, 1/16" Width  
*Water- and Steam Resistant Food Grade  
EPDM O-Ring, McMaster-Carr PN: 9561K23*

## Step 1 — O-Ring Seal



- Remove the the brush head from the handle.

## Step 2



- Using the pliers, rotate the head base 90 degrees counterclockwise and remove core from the handle.

## Step 3



- Using a spudger, remove the old O-Ring from the white head.
- ⓘ Replace with, McMaster-Carr PN:9561K23. O-Ring: 15/16" ID, 1/16" Width. Food and Steam Resistant Food Grade EPDM O-Ring.

To reassemble your device, follow these instructions in reverse order.