



# Quick Antenna Connection Check for Delphi MyFi XM2GO

If no reception is received, the antenna connections may be disconnected. This guide presents a quick way to check the connections.

Written By: Scott Byer





## TOOLS:

- [Spudger](#) (1)
-

## Step 1 — Removing Delphi MyFi XM2GO Battery Cover



- Turn over the Delphi MyFi XM2GO Device on its back to start the cover-removal process.

## Step 2



- Locate the large button on the top back of the device.
- Press this button at the top while making a firm grip on the battery cover.
- As the button is pressed, move the cover towards the bottom of the device.
- The battery removal tab may pop up during the cover removal process.



### Step 3 — Removing Delphi MyFi XM2GO Battery



- Holding the device, grab the tab with thumb and index finger.
- Pull down on the tab to move the battery block a few millimeters towards the bottom of the device to unlock the latch at the top.
- After the latch at the top is disengaged, pivot the battery away from the back and the battery will be free.

### Step 4 — Quick Antenna Connection Check for Delphi MyFi XM2GO



- Under the battery is a magnetic mat, shown in red, that shields battery interference with the reception of the XM Satellite antenna.
  - This mat is stuck to the back of the device like a sticker and can be removed.
- ⚠ CAUTION: Do not operate the device without this magnetic shield.

## Step 5



- On the bottom left side of the magnetic mat, the corner can be lifted up to reveal the U.FL antenna connector. A spudger or your fingernails can be used to pry up the corners.
- These U.FL antenna connections are standard for most portable devices and WiFi cards. They may become detached through use and may be checked if no reception is present.
- Lift up the corner and notice the two connectors going to the PCB.

## Step 6



- Both of these connectors must be firmly attached to the PCB. Try pressing them firmly to make sure they are making full contact.



## Step 7



- On the top right corner, the magnetic mat can be lifted up to check another U.FL connector as with the 3rd step.
- This mat can be pressed down again to secure after checking the connector.

## Step 8



- Try pressing down on the U.FL connector, as seen in this picture, to ensure a secure connection.

To reassemble your device, follow these instructions in reverse order.