



Remington MB4040 Zoom Wheel Replacement

Use this guide to replace the zoom wheel.

Written By: Cameron Carnahan



INTRODUCTION

The zoom wheel controls the position of the blade guard, which then determines how much hair will be removed when trimming.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Small Needle Nose Pliers](#) (1)
 - [Tweezers](#) (1)
 - [Heavy-Duty Spudger](#) (1)
-

Step 1 — Remove Blade Assembly



- Press the black button below the blade to remove the blade.

Step 2 — Remove Back Cover Hardware




- Place the device so the back of the product is facing up.
- Remove the two 11.0 mm PH00 screws from the black plastic housing at the bottom of the device.

Step 3 — Remove Front Cover Hardware




- Remove the chrome plated plastic piece by using the plastic opening tool to pry it from the housing assembly.
- Remove the small clear plastic piece that covers the zoom wheel numbers.

Step 4 — Front Cover (cont.)




- Remove the two 16.0 mm PH00 screws from the front cover.
- Use the blue plastic opening tool to pry apart the two halves of the device.

Step 5 — Blade Button Removal




- Remove the black blade button and the two 10.0 mm springs, which are sandwiched between the cover assembly halves.
- ⓘ The blade button is sandwiched between the halves and the two springs may fall out when the halves are separated.

Step 6 — Remove screws attaching the zoom wheel




- Remove the two 11.0 mm PH00 screws that attach the zoom wheel to the plastic housing.

Step 7 — Remove Zoom Wheel Assembly



- Remove zoom wheel assembly from housing using fingers.
 - ⚠ Gently remove zoom wheel assembly because the red and black wires are attached and can easily be broken.
 - ℹ This assembly also houses the motor.
- Remove the small black piece of plastic surrounding the zoom wheel. This will be referred to as the slider.
- ☑ When reassembling, make sure the pins on the slider are aligned inside the grooves of the wheel.

Step 8 — Wheel removal



- A pin holds the wheel in place. Using a spudger (preferable metal) and a pair of pliers or tweezers remove the pin to unseat the wheel.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-23 09:40:31 PM (MST).

