



Removing Delphi MyFi XM2GO Battery

This guide demonstrates removing the user-removable Lithium Ion battery.

Written By: Scott Byer



Step 1 — Removing Delphi MyFi XM2GO Battery Cover



- Turn over the Delphi MyFi XM2GO Device on its back to start the cover-removal process.

Step 2



- Locate the large button on the top back of the device.
- Press this button at the top while making a firm grip on the battery cover.
- As the button is pressed, move the cover towards the bottom of the device.
- The battery removal tab may pop up during the cover removal process.

Step 3 — Removing Delphi MyFi XM2GO Battery



- Holding the device, grab the tab with thumb and index finger.
- Pull down on the tab to move the battery block a few millimeters towards the bottom of the device to unlock the latch at the top.
- After the latch at the top is disengaged, pivot the battery away from the back and the battery will be free.

To reassemble your device, follow these instructions in reverse order.