

KS-20490 RECTIFIERS
48 VOLTS, 400 AMPERES
OPERATING METHODS

1. GENERAL

1.001 This addendum supplements Section 169-742-301, Issue 1. Place this pink sheet ahead of Page 1 of the section.

1.002 This addendum is issued to add a note concerning proper operation of the DC OUTPUT switch. This addendum does not affect the Equipment Test List.

2. CHANGES TO SECTION

2.001 On Page 4, 3.01 *Normal Operation*, before *Caution 1*, add the following:

Note: For proper operation of the S1 DC OUTPUT switch, depress the PUSH TO

OPERATE lever on the handle and rotate the handle about 1/4 inch in the direction of the new position. Then, release the lever and rotate smartly into the desired position (lever will automatically lock when the switch is aligned).

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement