

DIMENSION[®] PBX
DCTS FEATURE TEST
IDLE LINE PREFERENCE

CONTENTS

1. GENERAL	3. IDLE LINE PREFERENCE TEST
2. TEST SET UP	4. RESTORATION

<u>1. GENERAL</u>	3.5 At Set-I go off-hook.
1.1 This test section provides testing information for Idle Line Preference.	3.51 I-USE lamp for next Idle Line lighted.
1.2 <u>Idle Line Preference</u> automatically connects the station user to an idle line upon going off-hook. If no line is idle, the user receives reorder tone.	3.511 Dial tone heard.
	3.512 Status Lamp associated with Line Seized is lighted steadily.
<u>2. TEST SET-UP</u>	3.6 At Set-I go on-hook.
2.1 Connect Electronic Telephone Set to circuit selected with Idle Line Preference. This set will be referred to as Set-I in the testing procedure.	3.61 I-USE and Status Lamps go off.
2.2 Connect Electronic Telephone Sets to circuits with assigned station lines on Set-I.	3.7 Place Station to Station calls until all lines on Set-I are busy. Answer at telephone sets other than Set-I. Status Lamp at Set-I for line called lighted steadily.
<u>3. IDLE LINE PREFERENCE TEST</u>	3.8 At Set-I go off-hook.
3.1 At Set-I verify that all I-USE lamps are off.	3.81 Reorder tone received.
3.2 At Set-I go off-hook.	3.811 All I-USE Lamps are off.
3.21 I-USE lamp for Idle Line lighted.	3.9 Hang up Set-I and all telephone sets used to busy lines on Set-I.
3.211 Dial tone heard.	3.91 Status Lamps at Set-I go out.
3.212 Status Lamp associated with line seized is lighted steadily. (note line seized).	<u>4. RESTORATION</u>
3.3 At Set I go on-hook.	4.1 Determine requirements for next test and disconnect telephone sets not required.
3.31 I-USE and Status Lamps go off.	
3.4 Place a Station to Station call to idle line seized in Par. 3.21 and answer at a telephone set other than Set I. Status Lamp at Set I for line called lighted steadily.	

Manager, Denver PBX PECC

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

Printed in U.S.A.