


- Notes:- 1. If filter is not provided connect Yellow lead from Y of dial to Y housing contact spring instead of to Filter Bracket Terminal.
 2. Four conductor, inside or duct wire. } Local Wiring
 3. Pair inside or duct wire. }

Fig. 3—D-159603 or D-159604 Coin Collector—Anti-Sidetone Connections




Note: If filter is not provided connect yellow lead from Y of dial to Y housing contact spring instead of filter bracket terminal.

In No. 50 Type upper housings these terminals are designated W, Y, YY, BB and BK-YY respectively.

Fig. 4—D-96589 or D-96719 Coin Collector—Anti-Sidetone Connections

3. LOCAL BATTERY TALKING, COMMON BATTERY SIGNALING STATIONS—CONNECTIONS



Note: If filter is not provided connect yellow lead from Y of dial to Y housing contact spring instead of to Filter Bracket Terminal.

Fig. 5—D-159603 or D-159604 Coin Collector—Anti-Sidetone Connections