



# iPhone 6 Plus iSclack Opening Procedure

Prereq for display assembly.

Written By: Walter Galan



---

# INTRODUCTION

Prereq for display assembly.



## TOOLS:

- [iSclack](#) (1)
-

## Step 1 — iSclack Opening Procedure



- ❗ The next two steps demonstrate using the [iSclack](#), a great tool for safely opening the iPhone 6 Plus that we recommend for anyone doing more than one repair. **If you aren't using the iSclack, skip down two steps.**
- If the plastic depth gauge is attached at the center of the iSclack, remove it now—it's not needed for larger phones like the iPhone 6 Plus.
- Close the handle on the iSclack, opening the suction cup jaws.
- Place the bottom of your iPhone in between the suction cups.
- ❗ Position the iSclack's upper suction cup against the display, near the home button.
- Open the handles to close the jaws of the iSclack. Center the suction cups and press them firmly onto the top and bottom of the iPhone.
- ❗ If your display or back glass is badly cracked, [covering it with a layer of clear packing tape](#) may help the suction cups adhere. The iSclack also includes two pieces of tape for this purpose.

## Step 2



- Hold onto your iPhone securely and close the handle of the iSclack to separate the suction cups, pulling the front panel up from the rear case.
- ⓘ The iSclack is designed to safely open your iPhone enough to separate the pieces, but not enough to damage any of the display cables.
- Peel the two suction cups off your iPhone.
- **Skip the next three steps and continue on to Step 7.**

To reassemble your device, follow these instructions in reverse order.