

# Policy Control, Number of Gx Session Rejections Reached

Ericsson Service-Aware Policy Controller

Operating Instructions

## **Copyright**

© Ericsson AB 2018. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

## **Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

## **Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document [Trademark Information](#).

# Contents

1	Alarm Description	1
2	Procedure	2
2.1	Handle Alarm Policy Control, Number of Gx Session Rejections Reached	2





# 1 Alarm Description

This alarm is raised when the number of session rejections exceeds its corresponding configured threshold value.

The alarm is associated to the gxCcasRejected measure.

The main attributes of the alarm are the following:

Table 1 Alarm Attributes

Attribute Name	Attribute Value
Alarm Type Id	GxSessionRejectionsReached
Major Type	193
Minor Type	7077890
Specific Problem	Policy Control, Number of Gx Session Rejections Reached.
Severity	Minor
Source	ManagedElement=1, SystemFunctions=1, Pm=1, PmJob=policyControlFunctionThresholdsJob, MeasurementReader=gxCcasRejected_mr:PolicyControlFunction=1, Network=1, DiameterNodes=1, DiameterNode=<diameterNodeId>
Probable Cause	100549
Event Type	Quality of Service
Additional Text	The number of Gx requests indicating authorization rejected in a specific given granularity period exceeds the configured threshold value
Last Event Time	YYYY-MM-DDTHH:mm:ss<time zone>



## 2 Procedure

### 2.1 Handle Alarm Policy Control, Number of Gx Session Rejections Reached

#### Prerequisites

- Before starting this procedure, ensure that you have read the following documents:
  - For information about Handling Alarms, refer to [Handling Alarms](#).
- Before starting this procedure, ensure that the following tool is available:
  - Ericsson Command Line Interface (ECLI).
- No conditions are required.

#### Steps:

#### Steps

1. Check that the threshold (`thresholdHigh` and `thresholdLow` attributes of the object indicated by source alarm field before ":" character) is configured according to the needs. More information in [Measurements](#).
2. Check the configuration of IP-CAN Session Access Control, refer to [Configuration Guide for Access and Charging Control \(Gx\)](#).
3. If the alarm does not cease, consult the next level of maintenance support. Further actions are outside the scope of this procedure.