

Configure Login Failure Delay

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Change Login Failure Delay	1
2.2	Remove Login Failure Delay	2





1 Description

This instruction describes how to configure login failure delay for user authentication. The login failure delay value controls how long the delay is in seconds after an unsuccessful authentication until the next authentication attempt can be performed. There is also an operating system internal random variation in the delay to prevent systematic attack scenarios.

2 Procedure

2.1 Change Login Failure Delay

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The user has the System Security Administrator role.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to `UserManagement` Managed Object (MO), for example:
`>dn ManagedElement=1,SystemFunctions=1,SecM=1,UserManagement=1`
2. Enter Config mode:
`(UserManagement=1)>configure`
3. Set the login failure delay as required, for example, to 12 seconds:
`(config-UserManagement=1)>loginFailureDelay=12`
4. Commit the setting:
`(config-UserManagement=1)>commit`
5. Verify the `loginFailureDelay`:



```
(UserManagement=1)>show loginFailureDelay
```

The following is an example output:

```
loginFailureDelay=12
```

2.2 Remove Login Failure Delay

Steps

1. Navigate to `UserManagement` MO, for example:

```
>dn ManagedElement=1,SystemFunctions=1,SecM=1,UserManagement=1
```

2. Enter Config mode:

```
(UserManagement=1)>configure
```

3. Delete login failure delay:

```
(config-UserManagement=1)>no loginFailureDelay
```

4. Commit the setting:

```
(config-UserManagement=1)>commit
```

5. Verify the `loginFailureDelay` is deleted:

```
(UserManagement=1)>show loginFailureDelay
```

The following is an example output:

```
loginFailureDelay=[]
```