

# eVIP, Configuration Fault

## DESCRIPTION

**Copyright**

© Ericsson AB 2015, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Event Description</b>	<b>1</b>
<b>2</b>	<b>Handle eVIP, Configuration Fault</b>	<b>2</b>
<b>3</b>	<b>Configuration</b>	<b>2</b>
<b>4</b>	<b>Subscription</b>	<b>2</b>





# 1 Event Description

The eVIP, Configuration Fault event is reported when Transport Management detects a faulty configuration. This occurs in the following situations:

- A faulty configuration is entered.
- Transport Management starts, or restarts, with a faulty configuration.
- An Abstract Load Balancer (ALB) or a Front-End Element (FEE) is activated with a faulty configuration.

Transport Management issues a stateless alarm (an event) when a faulty configuration is detected. All alarm listeners receive this event, even those who did not enter the faulty configuration, or are unaware that a reconfiguration attempt has occurred.

The configuration faults are divided into the following two types:

- Syntax faults, for example, a malformed IP address is used. This type of fault can be detected immediately when the configuration is entered.
- Semantic faults. The configuration is syntactically correct but cannot be processed by Transport Management. The fault is detected later when Transport Management is notified to read the new configuration.

Table 1 eVIP, Configuration Fault Event Attributes

Attribute Name	Attribute Value
Major Type	193
Minor Type	2129526884
Managed Object Class	<Managed Object (MO) where the fault was detected>
Managed Object Instance	<Distinguished Name of the MO where the fault was detected>
Event Type	communicationsAlarm (2)
Probable Cause	x736UnspecifiedReason (418)
Specific Problem	eVIP, Configuration Fault
Additional Text	Fault in eVIP Configuration
Perceived Severity	critical (3)



## 2 Handle eVIP, Configuration Fault

### Steps

1. Delete the MO where the fault was detected.

**Note:** This is only necessary if it was a semantic fault.

2. Recreate the MO with correct configuration.
3. Activate the MO (ALB or FEE) if necessary.
4. Is the problem solved?

**Note:** If the problem is not solved, the alarm comes back when the MO is recreated.

Yes: Proceed with Step 7.

No: Continue with the next step.

5. Perform data collection, refer to [Data Collection Guideline](#).
6. Consult the next level of maintenance support. Further actions are outside the scope of this document.
7. Job is completed.

## 3 Configuration

Not Applicable.

## 4 Subscription

Not Applicable.