

# Check Alarm Status

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	Check Alarm Status	1



Check Alarm Status



# 1 Description

This instruction describes how to check the alarm status. The alarm status can be checked as part of preventive maintenance or problem resolution activities. In such situations, a detailed view of the active alarms in the managed element is required.

## 2 Procedure

### 2.1 Check Alarm Status

#### Prerequisites

- No documents are required.
- No tools are required.
- The following condition must apply:
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

#### Steps

1. Navigate to the **Fm** managed object, for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,Fm=1
```

2. Show the alarm list:

```
(Fm=1)>show
```

3. Show the details of an alarm, for example:

```
(Fm=1)>show FmAlarm=1
```

The following is an example output:



```

FmAlarm=1
  activeSeverity=CRITICAL
  additionalText="The number of files exceeded threshold level <thresholdHigh>
    in ManagedElement=1, SystemFunctions=1, FileM=1, LogicalFs=1, FileGroup=1"
  eventType=Other
  lastEventTime="2017-04-20T10:59:11.137+02:00"
  majorType=193
  minorType=131073
  originalAdditionalText="The number of files exceeded threshold level <thresholdHigh>
    in ManagedElement=1, SystemFunctions=1, FileM=1, LogicalFs=1, FileGroup=1"
  originalEventTime="2017-04-20T10:59:11.137+02:00"
  originalSeverity=CRITICAL
  probableCause=343
  sequenceNumber=36
  source="ManagedElement=1, SystemFunctions=1, Fm=1, FmAlarmModel=FileManagement, =>
    FmAlarmType=FileMNoOfFilesExceeded"
  specificProblem="File Management, Number of Files in FileGroup Exceeded"

```

#### 4. Show the detailed alarm status:

```
(Fm=1)>show-table -m FmAlarm -p fmAlarmId,source,activeSeverity,specificProblem
```

The following is an example output:

fmAlarmId	Source	activeSeverity	specificProblem
1	ManagedElement=1, SystemFunctions=1, Fm=1, FmAlarmModel=FileManagement, => FmAlarmType=FileMNoOfFilesExceeded	critical	File Management, Number of Files in FileGroup Exceeded
2	ManagedElement=NODE06ST, SystemFunctions=1, => Brm=1, BrmBackupManager=SYSTEM_DATA, => BrmBackupScheduler=SYSTEM_DATA	major	BRM, Scheduled Backup Failed
10	ManagedElement=NODE06ST, Conn=conn1, => Stack=CSCFRF, Host=LABSPT0FFCHA2.ericsson.se	warning	Diameter, Link Disabled