

# Lock Backup Scheduler

---

## OPERATING INSTRUCTIONS

## **Copyright**

© Ericsson AB 2014, 2015. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

## **Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

## **Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>





# 1 Introduction

This document describes how to lock the backup scheduler. It prevents scheduled backups from occurring. The scheduler can be locked to disable periodic backups during maintenance windows.

If the backup scheduler is locked, it must be unlocked before scheduled backups can run again, refer to *Unlock Backup Scheduler*.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- Attribute `adminState` is UNLOCKED.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.





## 2 Procedure

To lock the backup scheduler:

1. Navigate to the *BrmBackupScheduler* managed object, for example:

```
>dn ManagedElement=NODE06ST,systemFunctions=1,BrM=1,BrmBackupManager=SYSTEM_DATA,BrmBackupScheduler=SYSTEM_DATA
```

2. Enter Config mode:

```
(BrmBackupScheduler=SYSTEM_DATA) >configure
```

3. Lock the backup scheduler:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >adminState=LOCKED
```



### Attention!

Risk of data loss or data corruption.

Locking the backup scheduler cancels any ongoing scheduled backup.

**Note:** The value of the `adminState` attribute cannot be cleared by the `no adminState` CLI command

4. Commit the change:

```
(config-BrmBackupScheduler=SYSTEM_DATA) >commit
```

5. Verify that the backup scheduler is locked:

```
(BrmBackupScheduler=SYSTEM_DATA) >show
```

The following is an example output:

```
BrmBackupScheduler=SYSTEM_DATA
  adminState=LOCKED
[...]
  schedulerState=DISABLED <read-only>
[...]
```