

Cancel Backup and Restore Operation

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2014, 2015. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

| | | |
|----------|---------------------|----------|
| 1 | Introduction | 1 |
| 1.1 | Prerequisites | 1 |
| 2 | Procedure | 3 |



Cancel Backup and Restore Operation



1 Introduction

This document describes how to cancel a backup and restore operation.

1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

1.1.1 Conditions

The following conditions must apply:

- A backup and restore operation is in progress.
- The backup and restore name is known.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.





2 Procedure

To cancel a backup and restore operation:

1. Navigate to the *BrMBackupManager* Managed Object (MO), for example:

```
>dn ManagedElement=NODE06ST,SystemFunctions=1,BrM=1,BrmBackupManager=SYSTEM_DATA
```

2. Select the appropriate action:

- Cancel a create operation, delete operation, or import operation: Proceed with Step 3.
- Cancel a restore or export operation: Proceed with Step 6.

3. Cancel the create operation, delete operation, or import operation:

```
(BrmBackupManager=SYSTEM_DATA) >cancelCurrentAction
```

The system returns output `true` or `false`.

4. Verify that the operation was canceled:

```
(BrmBackupManager=SYSTEM_DATA) >show -v
```

Note: It can be required to enter the command several times until `result=SUCCESS` is shown in the progress report.

5. Proceed with Step 9.

6. Navigate to the *BrmBackup* MO, for example:

```
(BrmBackupManager=SYSTEM_DATA) >BrmBackup=PERF_BACKUP_NAME1_20140428_175907
```

7. Cancel the restore or export operation:

```
(BrmBackup=PERF_BACKUP_NAME1_20140428_175907) >cancelCurrentAction
```

The system returns output `true` or `false`.

8. Verify that the operation was canceled:

```
(BrmBackup=PERF_BACKUP_NAME1_20140428_175907) >show -v
```

Note: It can be required to enter the command several times until `state=CANCELLED` is shown in the progress report.



9. After an operation is successfully canceled, the progress report shows the following when a create operation has been canceled:

```
actionName="CREATE" <read-only>
additionalInfo
  "Cancel Current Action Request was invoked by the =>
operator."
[...]
  result=FAILURE <read-only>
  resultInfo="Backup Object [PERF BACKUP_NAME1 =>
20140428_175907] was successfully deleted" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when a delete operation has been canceled:

```
actionName="DELETE" <read-only>
additionalInfo
  "Cancel Current Action Request was invoked by the =>
operator."
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when an import operation has been canceled:

```
actionName="IMPORT" <read-only>
additionalInfo
  "Cancel Current Action Request was invoked by the =>
operator."
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when a restore operation has been canceled:

```
actionName="RESTORE" <read-only>
additionalInfo
  "CANCEL_PHASE is completed"
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

The progress report shows the following when an export operation has been canceled:

```
actionName="EXPORT" <read-only>
additionalInfo
  "CANCEL_PHASE is completed"
[...]
  result=FAILURE <read-only>
  resultInfo="CANCEL_PHASE is completed" <read-only>
  state=CANCELLED <read-only>
```

If an error occurs during the execution of the action, attribute `reportProgress` shows `result=FAILURE` and `resultInfo` shows the cause of the failure. For more details, check the backup error list document.

For more information on the progress report, refer to *View Progress Report*.