

# Show Authentication Method Order

---

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Description</b>	<b>1</b>
<b>2</b>	<b>Procedure</b>	<b>1</b>
2.1	View Authentication Method Order	1



Show Authentication Method Order



# 1 Description

This instruction describes how to view the order in which the authentication methods are applied upon user login to the node.

The order is stored in the MO class `authenticationOrder`.

The value of attribute `authenticationMethodOrder` consists of a list of authentication methods and their applying priorities. The list is initially empty and values are added to it upon method registration.

The `authenticationMethodOrder` list consists of a structure that stored data related to the given authentication method.

The value of attribute `methodReference` contains the DN reference to the method in question.

The value of attribute `orderNumber` contains the priority for the method in question.

# 2 Procedure

## 2.1 View Authentication Method Order

### Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
  - The user has the System Security Administrator role.
  - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

### Steps

1. Navigate to *AuthenticationOrder* Managed Object (MO), for example:



```
>dn ManagedElement=1,SystemFunctions=1,SecM=1,UserManagement=1,AuthenticationOrder=1
```

## 2. View the Authentication Method Order:

```
(AuthenticationOrder=1)>show -v
```

The following is an example output:

```
AuthenticationOrder=1
  authenticationOrderId="1"
  userLabel=[] <empty>
  authenticationMethodOrder[@1] <read-only>
    methodReference="ManagedElement=1,SystemFunctions=1,SecM=1,⇒
UserManagement=1,LocalAuthenticationMethod=1" <read-only>
    orderNumber=1 <read-only>
    userLabel=[] <empty> <read-only>
  authenticationMethodOrder[@2] <read-only>
    methodReference="ManagedElement=1,SystemFunctions=1,SecM=1,⇒
UserManagement=1,LdapAuthenticationMethod=1" <read-only>
    orderNumber=2 <read-only>
    userLabel=[] <empty> <read-only>
```