

Configure Legal Notice

OPERATING INSTRUCTIONS

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Description	1
2	Procedure	1
2.1	Configure Legal Notice	1





1 Description

This document describes how to configure the legal notice for Operation and Maintenance (O&M) users. The legal notice is managed by SecM user management and it is displayed when O&M users access the node.

Note: Depends on the client capability and configuration if the message is presented to the (O&M) user.

2 Procedure

2.1 Configure Legal Notice

Prerequisites

- No documents are required.
- No tools are required.
- The following conditions must apply:
 - The user has the System Security Administrator role.
 - The new legal notice text is known.
 - An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.

Steps

1. Navigate to the *UserManagement* managed object, for example:

```
>dn ManagedElement=NODE06ST, SystemFunctions=1, SecM=1, UserManagement=1
```

2. Enter Config mode:

```
(UserManagement=1) >configure
```

3. Set the legal notice text, for example:



```
(config-UserManagement=1)>legalNotice="Only authorized  
users are allowed to access this system.\nTo use the  
system you must agree to the group policies."
```

Note: \n can be used as a line break.

4. Commit the setting:

```
(config-UserManagement=1)>commit
```

5. Verify the legalNotice:

```
(UserManagement=1)>show legalNotice
```

The following is an example output:

```
legalNotice="Only authorized users are allowed to access this syst
```