

NUMA 0

| | | |
|----------|----|----|
| Core 0: | 0 | 24 |
| Core 2: | 2 | 26 |
| Core 4: | 4 | 28 |
| Core 6: | 6 | 30 |
| Core 8: | 8 | 32 |
| Core 10: | 10 | 34 |
| Core 12: | 12 | 36 |
| Core 14: | 14 | 38 |
| Core 16: | 16 | 40 |
| Core 18: | 18 | 42 |
| Core 20: | 20 | 44 |
| Core 22: | 22 | 46 |

NUMA 1

| | | |
|----------|----|----|
| Core 1: | 1 | 25 |
| Core 3: | 3 | 27 |
| Core 5: | 5 | 29 |
| Core 7: | 7 | 31 |
| Core 9: | 9 | 33 |
| Core 11: | 11 | 35 |
| Core 13: | 13 | 37 |
| Core 15: | 15 | 39 |
| Core 17: | 17 | 41 |
| Core 19: | 19 | 43 |
| Core 21: | 21 | 45 |
| Core 23: | 23 | 47 |

CPU color codes

Tenant VM

OVS

Host OS and vCIC